V2 Bluetooth speaker

specification

Panel indicator



Operation instruction

Serial number	Button/USB	Function definition	Operation instruction	Prompt tone	Light effect/indicator light
1	电源键	Bluetooth Pairing/Long press to shutdown	Bluetooth pairing: Long press the power button for 3S, the speaker will enter the Bluetooth pairing state, and the pairing is successful, and the speaker will prompt "Pairing success". Shutdown: Long press the power button for 15S, the speaker will prompt "Shutdown" and shutdown.	Bluetooth pairing: "Pairing mode" Pairing success: "Pairing success" Shutdown: "Shutdown"	Bluetooth pairing: Blue light flashes quickly and the light is always on after pairing is successful. Shutdown: The blue light is always on for 3 seconds and then turns off.
2	开机键	Power on/off	Power on: Long press the power button for 3S, the speaker will prompt "Power on" and enter the Bluetooth pairing state. Power off: When the blue light flashes, the speaker is in the Bluetooth pairing state, and the power button is pressed for more than 3 seconds, the speaker will prompt "Shutdown" and shutdown.	-	Power on: Blue light flashes quickly, and the light is always on after pairing is successful. Power off: The blue light is always on for 3 seconds and then turns off.
3	USB	Charging port	Charging port: Connect the charging cable to the charging port, the speaker will prompt "Charging" and the red light is always on. When the battery is fully charged, the red light is always on.	Charging: "Charging" Fully charged: "Fully charged"	Charging: Red light is always on. Fully charged: Red light is always on.
4	AUX	Aux port	Aux port: Connect the audio cable to the Aux port, the speaker will prompt "Aux mode" and enter the Aux mode.	Aux mode: "Aux mode"	-
5	音量键	Volume/play	Volume: Short press the volume button, the speaker will prompt "Volume" and the volume will be adjusted. Play/pause: Short press the play button, the speaker will prompt "Play" or "Pause".	Volume: "Volume" Play/pause: "Play" "Pause"	-
6	TWS/RESET	Tws pair/Restore factory settings	TWS pairing: Short press the TWS button, the speaker will prompt "TWS pairing" and enter the TWS pairing state, and the pairing is successful, the speaker will prompt "TWS pairing success". Restore factory settings: Long press the TWS button for 15S, the speaker will prompt "Restore factory settings" and restore the factory settings.	TWS pairing: "TWS pairing" TWS pairing success: "TWS pairing success" Restore factory settings: "Restore factory settings"	TWS pairing: Blue light flashes quickly and the light is always on after pairing is successful. Restore factory settings: The blue light flashes 3 times and then turns off.
7	USB 5	Mobile charging	Mobile charging: Connect the charging cable to the USB port, the speaker will prompt "Charging" and the red light is always on. When the battery is fully charged, the red light is always on.	-	Charging: Red light is always on. Fully charged: Red light is always on.
8	TF	Memory card	Memory card: Insert the memory card into the card slot, the speaker will prompt "Memory card mode" and enter the memory card mode.	Memory card mode: "Memory card mode"	Memory card mode: Blue light flashes quickly and the light is always on after pairing is successful.
9	Pairing button	Mic pickup	Mic pickup: Connect the microphone and the speaker, the microphone can be used for karaoke.	Mic pickup prompt tone: "Microphone connected"	Mic pickup: The blue light is always on for 3 seconds and then turns off.
10	Reduce volume	Volume reduction	Volume reduction: Short press the volume button, the speaker will prompt "Volume" and the volume will be adjusted. Previous song: Short press the previous song button, the speaker will prompt "Previous song" and the previous song will be played.	Volume: "Volume" Previous song: "Previous song"	Volume: Blue light flashes quickly and the light is always on after pairing is successful.
11	Power button	Power on/off	Power on: Long press the power button for 3S, the speaker will prompt "Power on" and enter the Bluetooth pairing state. Power off: When the blue light flashes, the speaker is in the Bluetooth pairing state, and the power button is pressed for more than 3 seconds, the speaker will prompt "Shutdown" and shutdown.	Power on: "Power on" Power off: "Shutdown"	Power on: Blue light flashes quickly and the light is always on after pairing is successful. Power off: The blue light is always on for 3 seconds and then turns off.
12	Play button	Pause/play	Pause/play: Short press the play button, the speaker will prompt "Pause" or "Play" and the music will be paused or played.	Pause/play: "Pause" "Play"	-
13	Lamp effect button	Lamp effect	Lamp effect: Short press the lamp effect button, the speaker will prompt "Lamp effect" and the lamp effect will be adjusted.	Lamp effect: "Lamp effect"	-
14	TWS/RESET button	TWS/Reset	TWS pairing: Short press the TWS button, the speaker will prompt "TWS pairing" and enter the TWS pairing state, and the pairing is successful, the speaker will prompt "TWS pairing success". Reset: Long press the TWS button for 15S, the speaker will prompt "Reset" and reset.	TWS pairing: "TWS pairing" TWS pairing success: "TWS pairing success" Reset: "Reset"	TWS pairing: Blue light flashes quickly and the light is always on after pairing is successful. Reset: The blue light flashes 3 times and then turns off.

Bluetooth connection:
1. Long press the power button for 3S, switch to Bluetooth mode, open the phone Settings, search for "Soundtik V2" in Bluetooth, click Connect, the connection is successful, and then start playing audio through Bluetooth
* Bluetooth connection valid distance is 10 meters*

Bluetooth disconnect:
1. Click the "TWS" button to disconnect Bluetooth, or in the phone Settings, click Disconnect

TWS Interconnection:
1. Both speakers have been powered on, and in the Bluetooth unpaired mode, long press the "TWS" interconnection key of one speaker. 3S will enter the TWS mode and perform automatic pairing, and there will be a pure prompt tone if the pairing is successful.
2. Turn on the Bluetooth of the mobile phone to search for the pairing name "Soundtik V2" and click Connect. If the connection is successful, the two speakers can play songs at the same time;
* The effective distance of TWS interconnection is 6-8M.*

Speaker charging:
1. With DC5V power supply, connect the speaker and adapter, you can charge the speaker, full charge time is expected to take 4-5H
Restore factory Settings:
1. Hold down the TWS key for 15S. The speaker will shut down and restore factory Settings.

Product parameter:
Bluetooth version: 5.3
Rated power: 2X10W
Battery capacity: 4400mAh/7.4V
Charging time: 4-5H
Usage time: 12H(50% volume without lights)
Bluetooth distance: 10 meters

Warm reminder:
1. Please read the instructions carefully and use the product according to the operation instructions 2. Please use or store the product at room temperature 3. Do not use this product near heat sources, such as radiators, heaters or other heating instruments 4. To protect your hearing and extend the service life of the product, do not turn the volume to the maximum for a long time
5. Please choose a charger that has passed the formal manufacturer and safety certification to charge the product
6. It is recommended to fully charge the product before use for the first time. If you do not use the product for a long time, please fully charge the product every 3 months to avoid battery damage;

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.