FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Technical Parameters

Version	V4.2	Distortion rate	≤10%
Wireless name	A6	SNR	70dB
Transmission distance	≥10M	Power Supply	5V/600mA
Output power	5W	Bulid-in high efficiency lithium battery	3.7V/1800mA
Horn parameters	Φ52MM 4Ω5W		

Warranty Card

Applicable for

* Since buying date,the user enjoys one year free repair services under normal use.After one year,will be charged according to each component part cost.
* In case change component part,will be charged according to our company's component part cost list.
* The following situations without free repair services in warranty period

  1)Damage caused by natural earthquake,rat disaster,and unnormal use.

  2)Damage caused in transportation,fall,and unproper storage.

  3)Consumable component,such as spare parts,batteries,light bulbs,etc.

  4)Warranty information records is not complete,no purchase date, no buying shop seal,etc.

  5)Featured using environment,such as humidity,sulfur area, high salty and on board,etc,easy corrosion area.

  6)Using not according to the instructions.

  7)Special offer.
* When return to factory for repair,the user should make sure the product packed properly to avoid any damage during transportation.
* Factory not responsible for the damages caused by the users themselves unproper disassemble.

Important

Thank you for purchasing our products.

To guarantee your rights,please fill in this form properly,Thank you

Name	
Address	
Telephone	
Invoice number	
Purchase date	
Item number	
Dealers	Note:this field requires the dealer's seal!

Warning:please keep this warranty paper for repair presentation.

Attention

In order to use the speaker correctly, ensure the good performance of the speaker, please read carefully and observe below:

* Please do not impact the mainframe seriously
* Please do not contact benzene, diluent and other chemicals
* Please do not close to the magnetic and electric field
* Please avoid directly lighting and heating appliances
* Please do not repair, disassemble, transform by users themselves

A6

Flame Atmosphere Lamp Wireless Speaker



Please read carefully before use

Operation method



Attention

* Please do not charge the lamp under the temperature of 0℃-40℃.
* Not recommended for charging while using.
* Please pull off the usb cable after a full charge.
* Please do not charge the lamp with high -humidity situation.

Power input

* Put the USB cable into the lamp, when charging the indicator is red, when full charging the indicator off

Operation method

Installation instructions



▶ (The pole is not included in standard accessories. To be ordered separately)

Instructions



ON/OFF key: press this button for 2 seconds to turn on/off the Wireless Speaker; quick press invalid; Speaker in searching action when blue indicator flash fast, indicator light turns on when speaker be connected Successfully.

\+ Next song/V+ key: in Wireless mode press quick will go to the next song, long press to increase the volume(when reach the maximum volume, the speaker will say “di di”),(press + - together to cancel the pairing)

— Last song/V- Key: in Wireless mode press quick will go to the last song, long press to decrease the volume

▶II Play/pause Key: press quick to play/pause, long press is invalid

Short press to turn on the flame lamp mode,then short press to switch to the normal mode,long press to changs the light brightness,and then short press to turn off the light.