

R: XXX-XXXXXX

# User manual

Packing list

charging case



earphone

(L/M/S,earbuds with M)

How to wear

Select fittable ear caps for earbuds,insert L/R earbuds into ear (as photo)

## Power on/off

Open charging case,remove earbuds to power on automatically(Led flash).



## Paring

Earbuds are paired by factory default.Touch twice to reset pairing earbuds during disconnected status,led indicator light 5s,earbuds connected

Earbuds during disconnected status ,indicator flashing,select pairing mode on devices(such as mobilephone).Disconnected more than 5mins,earbuds will off automatically.



## How to use

Power on insert earbuds close the charging case
Power off insert earbuds close the charging case
Answering incoming call Touch L/R twice
Hang up call Touch L/R twice
Reject incoming call Long press L/R twice
Play/Pause Touch L/R twice
Volume -- quick tap,release then long press L 2s
Volume + quick tap,release then long press R 2s
Next song Long press L/R twice
Previous song Long press L/R twice
Switch ANC touch L/R 4 times
Switch EQ mode touch L/R 3 times
Switch Chinese/English power on during disconnected status touch 3times
Restore factory setting power on during disconnected status touch twice

Lock the sleep mode:Switch to sleep mode,only left answer/hang up and switch EQ mode,other function will be loecked.Unlock other function,pls switch EQ mode to music/game mode.

| | L | | R |
|---|---|---|---|
| **Power On** | Open the case when earbuds inside the case | | |
| **Power Off** | Put the earbuds into the charging case | | |
| **Answer Call** | x2 | or | x2 |
| **Hang Up Call** | x2 | or | x2 |
| **Reject Call** | Press and hold 2s | or | Press and hold 2s |
| **Play/Pause** | x2 | or | x2 |
| **Volume -** | x1 and hold | | |
| **Volume +** | | | x1 and hold |
| **Previous Track** | Press and hold | | |
| **Next Track** | | | Press and hold |
| **ANC/Transparency** | x4 | or | x4 |
| **Music/Game/Sleep** | x3 | or | x3 |

Low battery prompt

1、
Working status and battery prompt of charging case:

| | status | Led (Red led) | Led ( White LED) |
|---|---|---|---|
| charging | charging | Flashing 0.5Hz | off |
| | fully charged | lighting 60s | Off |
| discharging | discharging | off | on |
| | Low battery (10%) | off | Flashing 1Hz |



2、Earbuds ‘s indicator will quick flash and say”low battery,pls charge”when battery <10%.Calls will back to mobilephone during earbuds on calling and off.

Note:Earbuds don’t have low battery prompt and voice during sleep mode.

## How to charge

Place earbuds into charging case and close it.
Earbuds is charging through the case,the indicator of earbuds is lighting.
The indicator of earbuds is off when fully charged.



Charging the case

Chartging the case,the LED indicator flash Red,when fully charged,LED indicator is red 60s and off.

support Type-C charging



# Specification

Bluetooth version： 5.2

Support： A2DP.1.2/ AVCTP.1.4.1/ AVDTP/ HFP.1.8

Codec： AAC,mSBC

Frequency： 2.402 GHz-2.480 GHz

Signal to noise ratio： ⩾90dB

Transmission distance： 10m

Battery capacity： 35mA （Rechargeable Li battery）

Talking time： 5hours

Play time： 4 hours

Standby time： 130 hours

Charging time： 1 hours

Size： 22*22*15mm

Weight： 3.2g

Speaker unit： 6mm,16 ohm

requency response： 20Hz-20k Hz

Waterproof grade： IPX4

Charging case

Charging case capacity： 250mA/3.7V

Input： 5V/1A

Size： D51.0*27.5mm

Weight： 29.9g

**FCC Requirement**

Any changes or modifications not expressly approved by the party responsible for compliance could
void the user’s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two
conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause
undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device,
pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection
against harmful interference in a residential installation. This equipment generates, uses, and can
radiate radio frequency energy, and if not installed and used in accordance with the instructions,
may cause harmful interference to radio communications. However, there is no guarantee that
interference will not occur in a particular installation. If this equipment does cause harmful
interference to radio or television reception, which can be determined by turning the equipment off
and on, the user is encouraged to try to correct the interference by one or more of the following
measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is
connected.
- Consult the dealer or an experienced radio/TV technician for help.