THE GUIDELINE FOR LED FLEX LIGHT MOTIF

Model No.: LED(TT)-T-S14-10L-15Ft-29V-WW+MU-Z

Input Rating: 120V AC, 60Hz, Output Rating: 29V DC, 0.082A

IMPORTANT SAFETY INSTRUCTIONS

A) READ AND FOLLOW ALL SAFETY INSTRUCTIONS

b) Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
c) This seasonal use product is not intended for permanent installation or use.
d) Do not mount or place near gas or electric heaters, fireplace, candles or other similar sources of heat.
e) Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
f) Do not let lamps rest on the supply cord or on any wire.
g) Unplug the product when leaving the house, when retiring for the night, or if left unattended.
h) This is an electric product-not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where small children can reach it.
i) Do not use this product for other than its intended use.
j) Do not hang ornaments or other objects from cord, wire, or light string.
k) Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
l) Do not cover the product with cloth, paper or any material not part of the product when in use.
m) This product is equipped with non-replaceable lamps. Do not twist lamps. And if non-replaceable lamps burn out or damaged, do not try to repair or replace it, it shall be discarded.
n) Read and follow all instructions that are on the product or provided with the product.

WARNING: When using outdoor use portable lighting products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

READ ALL INSTRUCTIONS

(a) Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuits or outlet to be used for the outdoor use flexible lighting product. Receptacles are available having built-in GFCI protection for this measure of safety.

(b) Max. connectable 5 sets.

HOW TO INSTALL PARTY LIGHT

(a) Before installing into the desired location fully uncoil the party light and connect it to the supplied adapter to ensure that it is operating correctly
(b) Inspect your new party light to ensure there are no cuts in the insulation or exposed wires.
(c) Ensure the partylight and the cable between the adapter and the party light does not present a tripping hazard when installed
(d) Use cable ties or others to secure the party light in position. Never use nails or other sharp fasteners inserted through the party light orleadercable to secure in position.
(e) The party light and cable should not be passed over any sharp objects that could wear through the insulation.
(f) Once the party light is installed into position, plug the leader cable into the adapter.
(g) Ensure the wired end cap is connected with the female connector of last set.
(h) After ensuring power point is in OFF position, plug the adapter into the power point and turn on.



FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/ TV technician for help.