RF425說明書

尺寸: H 125 X W 525 mm

PANTONE BlackC黑色



步驟1.
如左圖說明
橫向彈簧折

RF425 Wireless Keyboard and Mouse Combo

Product overview



A Left Button
B Right Button
C Scroll Wheel
D Power Switch
E USB Receiver

Product Specification

Model: RF425 Wireless Keyboard and Mouse Combo

KEYBOARD

- Connection: 2.4G Wireless Connection
- Dimension: (L)435*(W)123*(H)20.5mm
- Net Weight: 439g±5g
- Working range: 10M
- Receiver type:USB Receiver
- Standby hours:2000 hours
- Working time:360 hours of typing
- Power:Two AAA battery (not Included)
- Keyboard sleep mode: after 30 minutes of not use

System Requirement: Windows XP, Windows 7, Windows 8, Windows 10, Mac OS

MOUSE

- DPI: 1600
- Dimension:107.4*61.2*36.5mm
- Net Weight: 50g±5g
- Working range: 10M
- Mouse sleep mode: after 8 minutes of not use
- System Requirement: Windows XP, Windows 7, Windows 8, Windows 10, Mac OS

Package include

- 1 x wireless keyboard
- 1 x wireless mouse
- 1 x USB receiver (under the mouse)
- 1 x manual

2.4G wireless mode connection

- 1.Install the appropriate battery on the keyboard and mouse
- 2.The keyboard will be powered on automatically after the battery is installed
- 3. Turn on the keyboard and mouse.
- 4. Plug the USB dongle into your device.
- 5. The keyboard and mouse will connect to your device automatically.

If USB dongle doesn't connect to your device automatically, please reference below:

KEYBOARD

1. Turn on the keyboard.
2. Please hold ESC and press K key, the num lock indicator will slowly flashes.

Then plug the USB receiver into your device within 15 seconds.

If connect successfully, the num lock indicator will flash 5 times and off.

MOUSE

1. Turn on the mouse
2. Plug the USB receiver into your device.
3. Please press scroll wheel and right button together then connect to pair.

Key and Function

Key	Windows system	Mac OS system
F1 ◀X	Mute	Mute
F2 ◀)	Volume down	Volume down
F3 ◀))	Volume up	Volume up
F4 ◀◀	Prev. Track	Prev. Track
F5 ▶II	Play/Pause	Play/Pause
F6 ▶▶	Next Track	Next Track
F7 +	Decrease the brightness	Decrease the brightness
F8 +	Increase the brightness	Increase the brightness
F9	Select all	Select all
F10	Copy	Copy
F11	Paste	Paste
F12	Cut	Cut
Esc	Please hold FN and press ESC key to turn on/off FN function.	

Troubleshooting

1.If the keyboard and mouse have lag problem, please check if the battery is low.
2.Keyboard will switch to mac / win mode automatically according to your device.
3.On mac mode, there is no num lock key on standard mac keyboard. However, you may choose "system Preferences", then go to "Accessibility" - "Mouse & Trackpad" and look for an option called "Enable Mouse Keys" to enable num lock.

安全聲明

開始使用前請講閱讀以下事項並講保留此聲明作為未來之依據。
請勿摔落或撞擊您的鍵盤/滑鼠。
請勿在強烈震動環境下使用您的鍵盤/滑鼠，因為震動可能損毀您的鍵盤/滑鼠。
請勿用任何方式拆解或改裝您的鍵盤/滑鼠，自行拆解或改裝您的鍵盤/滑鼠將造成，您的保固失效，或有可能造成短路。
請勿使用您的鍵盤/滑鼠於潮濕的環境中，液體滲入鍵盤/滑鼠中將可能造成產品損壞或有可能導致短路。
請勿將金屬特質插入滑鼠主體中。
開始使用前請講閱讀以下事項並講保留此聲明作為未來之依據。
經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率，加大功率或變更原設計之特性之功能。
低功率射頻電機之使用不得影響飛航安全及干擾合法通信，經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前述合法通信，指依電信法規定作業之無線電通信。
低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.