
ABOUT DEVICE



01 / SHORTCUT KEYS

Fn + Q	Switch to Bluetooth device 1
Fn + W	Switch to Bluetooth device 2
Fn + E	Switch to 2.4GHz wireless connection mode
Fn + R	Switch to USB connection mode
Fn + F12	Invoke the on-board configuration profile

02 / INDICATOR LIGHTS

K610w

Indicator Light	Normal Indicator State *	Wireless Connection State Indicator **
①	Number Lock Indicator Light	
②	Caps lock indicator	Bluetooth device 1 connection status indicator
③	Scroll Key Lock Indicator	Bluetooth device 2 connection status indicator
④	Configuration profile indicator	2.4GHz wireless connection status indicator
⑤	Battery indicator	

K620w

Indicator Light	Normal Indicator State *	Wireless Connection State Indicator **
②	Caps lock indicator	Bluetooth device 1 connection status indicator
③	Scroll Key Lock Indicator	Bluetooth device 2 connection status indicator
④	Configuration profile indicator	2.4GHz wireless connection status indicator
⑤	Battery indicator	

* When K610w/K620w is successfully connected and functions normally, the indicator lights should also work normally.

** When K610w/K620w is pairing a wireless connection, the corresponding indicator light flashes slowly.

When K610w/K620w is paired but cannot connect, the corresponding indicator light flashes slowly. Please check if the device to be connected is functioning normally.

When switching between wireless connections, the corresponding indicator light will flash for 3 seconds and then revert back to its normal indicator status.

03 / WIRELESS SWITCH



CONNECTION SPECIFICATIONS

KEYBOARD 610w	
BLUETOOTH	Frequency range: 2402MHz~2480MHz Transmitter power: < 1 dBm
2.4GHz WIRELESS	Frequency range: 2402MHz~2480MHz Transmitter power: < 2 dBm
RECEIVER	
2.4GHz WIRELESS	Frequency range: 2402MHz~2480MHz Transmitter power: < 3.5dBm
KEYBOARD 620w	
BLUETOOTH	Frequency range: 2402MHz~2480MHz Transmitter power: <-1 dBm
2.4GHz WIRELESS	Frequency range: 2402MHz~2480MHz Transmitter power: < 1 dBm
RECEIVER	
2.4GHz WIRELESS	Frequency range: 2402MHz~2480MHz Transmitter power: < 5.5dBm

BLUETOOTH CONNECTION

1 Turn on wireless switch.



2



Enter Bluetooth mode by pressing FN+Q/W.

3


The corresponding indicator light flashes quickly upon initial use. Search for K610w/K620w on a device that supports Bluetooth low energy technology and complete the pairing according to the on-device prompts. The corresponding indicator light will be on for 3 seconds and then revert back to the normal indicator status. If re-pairing is needed, long press FN+Q/W for 3 seconds until the indicator light flashes quickly, and then users can proceed with re-pairing.

2.4GHz WIRELESS CONNECTION

1 Turn on wireless switch.



2 Plug in the wireless receiver.




3



Press FN+E to enter 2.4GHz wireless connection mode, after which the device will connect automatically. The indicator light will be on for 3 seconds and then revert back to the normal indicator status.

USB WIRED CONNECTION

1 Plug in the USB cable.



2



Press FN+R to enter USB wired connection mode.

LEARN MORE

Check out www.durgod.com and download "Durgod Zeus Engine" to get:

- The latest firmware updates
- Entire key customization
- Macro editing function
- On-board and cloud storage of configuration profiles
- The latest information on Durgod products

WeChat Weibo

Zhuhai Hekoi Technology CO.,LTD
Room 101,No.2 Building,No.6,Fenglian 3 Road,Nanping,Technology & Industry Park,Xiangzhou District,Zhuhai City,China
Service Email:service@durgod.com Support Email:support@durgod.com
Copyright © 2017 Zhuhai Hekoi Technology CO.,LTD. All rights reserved. Copyrights or trademarks are the property of their respective owners. This manual is for reference only. None part constitutes any form of commitment.

REGULATORY AND COMPLIANCE INFORMATION

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interfere by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

Hereby, Zhuhai Hekoi Technology LTD.,CO declares that the radio equipment type DURGOD K610/K620w Wireless Mechanical Keyboard and Infinite Wireless Receiver are in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: http://www.durgod.com

CAUTION!

(1) Risk of fire or explosion or defeat the safeguard of equipment if the battery is replaced by an incorrect type. Replace only with the same or equivalent type.

(2) Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

(3) High or low extreme temperatures or low air pressure at high altitude that the battery can be subjected to during use, storage or transportation.

(4) Leaving the battery in an extremely high temperature and/or low air pressure surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

REGULATORY AND COMPLIANCE INFORMATION

Canada Statement

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the thefollowingtwo conditions:
(1) This device may not create interference, and
(2) This device must accept any interference,including interference that may cause undesired operation of the device.
L' emetteur/recepteur exempt de licence contenu dans le present appareil est conforme aux CNR d' Innovation, Sciences et Developpement economique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisee aux deux conditions suivantes :
(1) l' appareil ne doit pas produire de brouillage;
(2 L' appareil doit accepter tout brouillage radioelectrique subi, meme si le brouillage est susceptible d' en compromettre le fonctionnement.
The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.
Le dispositif rencontre l'exemption des limites courantes d'evaluation dans la section 2.5 de RSS 102 et la conformite a l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformite de rf.

Hereby, Zhuhai Hekoi Technology CO.,LTD declares that the radio equipment type DURGOD K610/K620w Wireless Mechanical Keyboard and Infinite Wireless Receiver are in compliance with Directive 52 2017 No.1206.The full text of the UK declaration of conformity is available at the following internet address:http://www.durgod.com

保修服务卡

产品型号

购买日期

用户姓名

联系电话

通讯地址/邮编

产品S/N码

质量检验合格

DURGOD

厂 商:珠海华罡电子科技有限公司
地 址:珠海市香洲区南屏科技园新天一路6号南裕丰大厦8楼

保修服务指南

感谢您对DURGOD(杜伽)的信任与支持

DURGOD将为您提供一年的产品免费保修服务，请为提自装改本保修服务卡，以维护您的合法权益。如需服务或技术支持，请咨询相关经销商或与我们联系。

我们承诺

对保修期间内及在保修服务范围内的产品，DURGOD将按照本服务政策进行维修，更换或退货在合理的时间内免费为您客户品的正常使用功能;对超出保修期限保修服务范围之外的产品，DURGOD将按照本服务政策提供有偿维修服务。

保修服务时须提供

1. 申请保修的DURGOD产品及附件。
2. 有效的购买凭证。

质保不包含一下原因导致的问题和损坏：

1. 产品正常使用磨损。
2. 由于人为原因造成的损坏，包括但不限于跌落、挤压、碰撞造成的损坏,进液体浸泡, 化学品腐蚀, 异物进入内部造成的损坏。
3. 因使用, 保养, 维护不当造成的损坏。
4. 产品被任何未经授权方拆除, 维修, 私改等去除, 涂改等难以辨认等。
5. 产品超出保修期。
6. 因不可抗力损坏。

了解设备



01 / 快捷键

Fn + Q	切换蓝牙设备 1
Fn + W	切换蓝牙设备 2
Fn + E	切换2.4G无线模式
Fn + R	切换USB模式
Fn + F12	调用板载配置文件

02 / 指示灯

K610w

指示灯	正常指示状态 *	无线连接状态 **
①	数字键区指示灯	
②	大小写指示灯	蓝牙设备1连接状态指示灯
③	锁键 Scroll 指示灯	蓝牙设备2连接状态指示灯
④	配置文件指示灯	2.4G 无线连接状态指示灯
⑤	电量指示灯	

K620w

指示灯	正常指示状态 *	无线连接状态 **
②	大小写指示灯	蓝牙设备1连接状态指示灯
③	锁键 Scroll 指示灯	蓝牙设备2连接状态指示灯
④	配置文件指示灯	2.4G 无线连接状态指示灯
⑤	电量指示灯	

* 有关K610w/K620w 正常键盘操作可以参考相关说明书，如开启插入后可能会开启。

** 当您连接模式发生可能时候亮时，指示灯快闪。
当连接模式发生时间过长或者连接模式断开，指示灯慢闪，此时请检查所有待连接设备是否正常。
当您连接模式之间切换之后，指示灯将关闭3秒，进入正常指示状态。

03 / 开关按钮



连接距离

键盘 610w	
蓝牙	频率范围:2402MHz~2480MHz 发射功率:< 1 dBm
2.4GHz无线	频率范围:2402MHz~2480MHz 发射功率:< 2 dBm
接收器	
2.4GHz无线	频率范围:2402MHz~2480MHz 发射功率:< 3.5dBm
键盘 620w	
蓝牙	频率范围:2402MHz~2480MHz 发射功率:<-1 dBm
2.4GHz无线	频率范围:2402MHz~2480MHz 发射功率:< 1 dBm
接收器	
2.4GHz无线	频率范围:2402MHz~2480MHz 发射功率:< 5.5dBm

蓝牙设备连接

2 支线开关处于ON的状态。

3



FN+Q / W进入蓝牙模式。


4

首次进入蓝牙模式,对应的指示灯将闪,在支持蓝牙组功能技术的设备上搜索设备,搜索设备将会完成配对,对应指示灯变亮3秒后恢复正常指示状态,如需重新配对,长按FN+Q/W 3秒重新对应指示灯快闪,即可重新进行配对。

2.4G 无线连接

1 无线开关处于ON的状态。

2 插上无线接收器。




3



FN+E进入2.4G无线模式,设备自动完成连接,对应指示灯常亮3秒恢复正常指示状态。

USB有线连接

1 插上USB数据线。



2



FN+R进入USB模式。

获取更多

访问http://www.durgod.com,下载DURGOD ZEUS ENGINE,您将获得:

- 最新的固件升级
- 全键盘按键自定义
- 宏编辑功能
- 配置文件板载存储与云存储
- 最新的产品资讯

WeChat Weibo

珠海华罡电子科技有限公司
珠海市香洲区南屏科技园新天一路6号南裕丰大厦8楼
客服电话:400-6744-010
客服邮箱:service@durgod.com
技术支持:support@durgod.com
版权所有©2017 珠海华罡电子科技有限公司 保留所有权利。未经许可,不得以任何形式复制或传播本手册的任何部分,不承担任何责任。

保修服务卡

产品型号

购买日期

用户姓名

联系电话

通讯地址/邮编

产品S/N码

质量检验合格

DURGOD

厂 商:珠海华罡电子科技有限公司
地 址:珠海市香洲区南屏科技园新天一路6号南裕丰大厦8楼

DURGOD

K610w/K620w

QUICK START GUIDE

—

用 户 指 南