说明书尺寸：70*90mm
说明书材质：105克双铜纸
印刷颜色：同文档颜色

正面

反面

Mibro Earbuds S1
User Manual

mibro

Thank you for choosing our product, hope the fashionable appearance and high quality stereo can enrich your life.

Note: Please fully charge it with the charging case before the first use when you receive the product.

Identifying Key Parts



1. Charging Pin
2. Touch Multi-function Button(MFB)
3. Main Microphone
4. Noise Reduction Microphone
5. LED Indicator
6. Charging Pin
7. Charging Box Battery Indicator

Charging

When charging, the light on the side of the charging case will flicker in a circle, and the light will stay on constantly after being fully charged.

- Charging when the indicator light flashes.
- When all four indicators are on, the battery is fully charged.

Getting Starts



①Slide the charging box upwards, and the Earbuds will automatically turn on and into the bluetooth pairing mode.

② Open the Bluetooth of your phone system, search the Bluetooth name "Mibro Earbuds S1", click the device name and complete the pairing.

③ Take out the earbuds and wear it. You will hear a "beep" sound, indicating that both ears are connected and music can be played.

Getting Off

The earbuds turn off automatically if:

① You put earbuds back to the charging case.
② When earbuds leave the charging case, but haven't connect to any devices within 5 minutes.
③ When the earphone battery is low (please charge it in time).

For above situation, please press and hold the MFB for 5 seconds to Power On.

Functions

You can operate MFB to get certain functions as below:

1.Power On/Off
In the on/off state, long press for 5 seconds to switch off/on.

2.Play / Pause
When playing music, double-click MFB(R or L) to pause , double-click again to resume.

3.Previous Track /Next Track
When playing music, press and hold MFB(L) for 2 seconds to previous track, press and hold MFB(R) for 2 seconds to next track.

4.Volume Increase Or Decrease
When playing music, Click MFB(L) once to decrease the volume, Click MFB(R) once to increase the volume.

5.Start voice assistant
In the Bluetooth connection state, Quick triple hit MFB(L or R) to activate the voice assistant.

6.Answer/End a call
When there' s an incoming call,double-click MFB once to answer ,you can end it by double-click MFB again.

7.Reject An Incoming Call
When there's an incoming call press and hold the MFB for 2 seconds to reject.

Safety Rules

- Avoid dripping and dropping.
- Use original or certified cables.
- Never disassemble or modify your earbuds for any reasons to avoid any damages and dangers.
- Keep the earbuds dry and do not submerge it in water.
- Keep out of reach of children, small parts included may be a choking hazard,and avoid using the LED indicator close to the eyes of children or animals.
- Do not use this earbuds during a thunderstorm to avoid irregular function and increased risk of the electric shock.
- Clean with a dry, soft lint-free cloth, do not use harsh chemicals or strong detergents to clean.
- The product shall not be exposed to excessive hot or wet.

Hearing Safety

- To avoid hearing damage, do not listen for long time at high volume.
- Do not turn the volume so high that you're unable to hear your surroundings.
- Do not use earbuds while driving.
- You should use with caution or temporarily discontinue using in potentially hazardous situations.

Name and content of hazardous substances

Part name	Hazardous substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Earbuds	✕	○	○	○	○	○
Battery	○	○	○	○	○	○
Charge Box	✕	○	○	○	○	○
Charge Cable	○	○	○	○	○	○

This table is prepared in accordance with SJ/T 11364-2014.

○ Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB/T 26572.
✕ It means that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit specified in GB/T 26572.

This product meets the ROHS environmental protection requirements: there is no mature technology in the world to replace or reduce the lead content of some electronic components of circuit components, steel and copper alloys.

Performance failure and after sales regulations

Name	Performance fault table
Earbuds	1. The earbuds is silent during use. 2. During the call, the other party cannot hear the sound. 3. Unable to charge, the charging indicator is not on.

Non warranty regulations

1. Wear and dirt caused by users' use, such as scratches and color changes; As well as damage caused by contact with chemical reagents, sharp objects, falling, extrusion and deformation.
2. Unauthorized maintenance, collision, misuse, negligence, abuse, water ingress, accidents, and failures caused by the use of non-standard accessories of the product.
3. Tearing, altering labels, forging anti-counterfeiting marks, etc.
4. Damage caused by force majeure.
5. Non compliance with performance faults listed in the performance fault table.

If you need after-sales service, please contact Mibro customer service:
Website: www.mibrofit.com
customer service: 400-0908-508

Attention:
The illustrations of products and accessories in the manual are schematic diagrams for users' reference only. Due to the update and upgrading of this product, the actual product may be different from the schematic diagram. Please take the actual product as the standard.

● Mibro brand owns the final right to interpret the goods.

FAQ

Q: The earbuds is silent while another is sound.
A: 1. It may be that both earbuds can not be connected normally. In extreme cases, this kind of situation will occur. Please put the earbuds back into the charging box, take it out and reconnect it after 8 seconds of reset.
2. It may be that the silent earbuds is dead. Please put both earbuds back into the charging box and fully charge them before taking them out for reuse.

Q: The earbuds didn' t responsive when I get them from the charging case, it can' t turn on automatically.
A: Please check the power of charging case, if there is no power the earbuds can' t turn on automatically or you can manually turn it on (long touch MFB for 2 seconds).

Q: I have established connection with my smartphone, but I am not hearing any sounds?
A: Please make sure that you have turned up the volume of both devices Smartphone requires you to set up the Bluetooth earbuds as an audio output devices before transmission of sound. Please check the instruction of your smartphone for details. If you are using a music player or other Bluetooth devices, please make sure it supports A2DP stereo music profile.

Q: Why the connection is not stable and cuts out intermittently?
A: Please make sure there are no obstacles between the earbuds and your Bluetooth device; please make sure there is no radio or WiFi interference nearby.

Q: The sound is not very clear or the caller cannot hear my voice clearly.
A: Please adjust the volume on your phone and earbuds. Make sure there is no source of interference nearby. Stay close to your smartphone check if there's any improvement.

Parking List

Charging Box X1，Earbuds X2，Charging cable X1，User Manual X1

Basic Parameters

Earbuds Basic Parameters:

BT Model	XPEJ003
BT Version	V5.0
BT Range	≤10m(33ft
Battery Capacity	35mAh (Per Earbuds)
Charging Time	About 1.5 hours
Play Time	About 5 hours
Stand By	About 60 hours
Input	5V ⎓ 150mA
Battery Type	Lithium ion polymer
Weight	About 3.8g (Per Earbuds)
Waterproof	IPX5

Charge Box Basic Parameters:

Battery Capacity	600mAh
Input	5V ⎓ 500mA
Output	5V ⎓ 150mA
Charging Time	About 4 hours
Battery Type	Lithium ion polymer
Weight	About 45.8g

Manufacturer:
Zhenshi Information Technology (Shanghai) Co., Ltd.
Address:
Room 4015, Building 2, No. 588, Zixing Road, Minhang District, Shanghai

mibro

Mibro Earbuds S1
用户手册

mibro

感谢您购买本产品。使用前请仔细阅读并严格遵循使用说明和注意事项并妥善保 管,以备查阅。

温馨提示：当您收到本产品后，请在首次使用前先充电。

产品图解



1. 耳机充电接触点
2. 触摸式多功能按键
3. 耳机指示灯
4. 通话麦克风
5. 降噪麦克风
6. 耳机充电接触针
7. 电量指示灯

产品充电

请于首次使用前将耳机入盒。连同充电盒连接充电线充满电。

- 充电盒的指示灯闪烁表示正在充电中；
- 当四颗指示灯全亮时表示电量已充满。



启动蓝牙

① 向上滑开充电盒，耳机将自动开机并进入蓝牙配对模式；

② 打开您的手机系统蓝牙，搜索蓝牙名称"Mibro Earbuds S1",点击设备名并完成配对；

③ 取出两只耳机并佩戴好，会听到"嘟嘟"声，表明双耳已正常连接，可以正常播放手机音乐。

关闭蓝牙

以下情况之一耳机将自动关机

① 耳机放回充电盒，并合上盖子；
② 从充电盒中取出后5分钟内没有设备连接；
③ 耳机电量低时（请及时充电）。

以上情况，请手动长按耳机触摸按键约5秒可开机。

功能使用

可使用多功能触摸按键获得以下某种功能：

1、开/关机
开/关机状态下，长按5秒可实现关/开机。

2、播放/暂停
音乐播放状态下，双击暂停播放，再次双击恢复播放。

3、上一曲/下一曲
播放音乐时，长按2秒左耳（L）多功能按键可切换至上一曲；
长按2秒右耳（R）多功能按键可切换至下一曲。

4、音量加/减
播放音乐时，单击左耳（L）多功能按键音量减小；
单击右耳（R）多功能按键音量增加。

5、启动语音助手
蓝牙连接状态下，快速三击多功能触摸按键（L或R），启动语音助手。

6、接听来电/结束通话
来电时，双击（L或R）多功能按键可接听来电，再次双击可挂断本次来电。

7、拒接来电
当有来电时，长按任一耳机2秒。

安全事项

- 请勿挤压或者碰撞，避免跌落；
- 请使用原装或经过认证的充电线；
- 请勿自行拆卸/修改耳机，以防损坏或危险；
- 请保持耳机干燥，切勿丢入水中；
- 远离儿童，以避免有可能伤害儿童的意外情况；
- 请勿在雷电天气使用耳机以防意外情况；
- 请使用干软布擦拭，避免使用刺激性化学物质强力洗涤剂清洗；
- 请勿在严重高温/潮湿/腐蚀性环境下使用本产品。

听力保护

- 请勿长时间在高音量状态下使用，以防损害听力；
- 请勿将声音调整过大以防听不到周围声音；
- 请勿开车时使用。

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
耳机主体	✕	○	○	○	○	○
电　池	○	○	○	○	○	○
充 电 盒	✕	○	○	○	○	○
充 电 线	○	○	○	○	○	○

本表格依据SJ/T 11364-2014的规定编制。

○ 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
✕ 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

本产品符合RoHs环保要求：目前国际上尚无成熟技术可替代或减少电路组件的部分电子组件，铜及铜合金的铅含量。

性能故障及售后条例

名称	性能故障表
蓝牙耳机	1. 使用过程中耳机无声； 2. 通话过程中，对方听不到声音； 3. 无法充电，充电指示灯不亮。

非保修条例

1. 因用户使用造成的磨损甚可，如刮痕，颜色改变的；以及接触化学试剂、尖锐物体碰伤、掉落挤压变形等人为损坏的情况；
2. 未经授权维修、碰撞、误用、跌落、湿用、进水、事故，以及使用非本产品标准配件造成故障的情况；
3. 撕毡、涂改标贴、伪造防伪标识等情况；
4. 因不可抗力造成的损坏；
5. 不符合性能故障表内所列性能故障的情况。

若有售后服务需求，请联系Mibro客服：
网　　址：www.mibrofit.com
客服电话：400-0908-508

注意：
说明书中的产品、配件等插图均为示意图，仅供用户参考，由于本产品的更新升级，产品实物与示意图可能会有差异，请以实物为准！

● 商品最终解释权归Mibro品牌所有！

FAQ/疑难解答

问：耳机一边有声一边无声。
答：1. 可能是耳机之间无法正常连接，极端情况下才会出现此类情况，请将耳机放回充电盒内，6秒复位后取出重新连接使用；
2. 可能是无声耳机没电，请将双耳放回充电盒内充满电再取出重新使用。

问：耳机从充电盒取出后未自动开机。
答：请首先检查充电盒电量。若充电盒没电，耳机取出时将无法自动开机。此时可手动开机（手动触摸多功能按键约8秒）。

问：连接着蓝牙设备时听音乐并浏览网页时，网页音频将同时播放。
答：请将状态都会如此，与手机软件有关，可关闭网页音频，无需担心。

问：已经和手机连接但是没有任何声音。
答：首先请确保耳机和手机并且均已开启且未设置在最低音量。智能手机有时要求先设置蓝牙耳机为音频输出设备，此操作可查询智能手机使用说明。若使用音乐播放器或其他蓝牙设备，请确保设备支持A2DP音乐文件。

问：打电话时声音不清晰或对方无法听到我的声音。
答：调大耳机及手机音量，靠近手机并确保周围无强烈干扰信号。

问：为什么蓝牙连接不稳定或间歇性断开。
答：请确保耳机与设备间没有障碍物，请确保周围无强烈WIFI或磁场干扰。

包装明细

充电盒 x1个、耳机 x2个、充电线 x1条、说明书 x1本

产品参数

耳机基本参数：

蓝牙名称	XPEJ003
蓝牙版本	V5.0
传输距离	≤10m/33ft
电池容量	35mAh (每只耳机)
充电时间	约1.5小时
通话时间	约5小时
待机时间	约60小时
输入参数	5V ⎓ 150mA
电池类型	锂离子聚合物
耳机重量	约3.8g (每只耳机)
防水级别	IPX5

充电盒基本参数：

电池容量	600mAh
输入参数	5V ⎓ 500mA
输出参数	5V ⎓ 150mA
充电时间	约4小时
电池类型	锂离子聚合物
盒子重量	约45.8g

制造商：瓶十信息科技(上海)有限公司
地　址：上海市闵行区紫星路588号2楼4015室

mibro

1　2　3　4　5　6　7　8　9

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.