User Manual

Dual-Mode Mouse

(Wireless Priority Bluetooth)

Model: WMB100

Bluetooth Mode Usage

1.Turn on the mouse power, then press and hold the DPI button (or simultaneously press the left button, right button, and scroll wheel button) for 3 seconds.
2.Turn on your Bluetooth device and search for the corresponding Bluetooth device name.
3.Click to connect and wait for about 2 seconds to start using.

2.4G USB Wireless Mode Usage

1.Remove the USB receiver from the mouse and plug it into the computer.
2.Turn on the mouse power. After the indicator light on thebottom flashes briefly, it will stay on, indicating that the connection is successful and the mouse is ready to use.

Notes

1.This product uses 2.4G wireless priority technology. When connecting via Bluetooth, do not insert the USB receiver into the device, as the mouse will prioritize the 2.4G wireless connection.

2.When switching from wireless to Bluetooth mode, please remove the USB receiver, then turn the mouse off and on again. Press and hold the DPI button (or simultaneously press the left button, right button, and scroll wheel button) for 3-5 seconds to enter Bluetooth mode.

3.When switching from Bluetooth to 2.4G USB receiver mode, insert the USB receiver, then turn the mouse off and on again. Wait for 3-5 seconds for it to connect.

Precautions and Recommendations

1.Handle the product with utmost care to preventa ccidental dropping or mishandling.Store in a cool, dry place and ensure that the deviceis not exposed to extreme heat or moisture.

2.Avoid any form of rough handling, mistreatment, damage, dropping,orimproper manipulation of theproduct.

3.Do not insert foreign objects into the slot under anycircumstances.t.

4.Store the USB receiver at the bottom of the mouse toprevent misplacement.

5.Prevent any contact between the device and liquids at all times.

6.Do not attempt to disassemble or repair the unit byyourself; seek professional assistance if needed.

Specification

Material: ABS

DPI: Adjustable - 800 / 1200 / 1600

Connectivity: Bluetooth + 2.4GHz Wireless

Button Lifespan: 3 Million Clicks

Power Source: 2 × AAA 1.5V Batteries

Compatibility: Desktop, Laptop, Internet TV

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.