Pall

b one plus

PRODUCT INTRODUCTION

PRODUCT USER MANUAL

ONE TURN ON / OFF THE BLUETOOTH EARPHONE

TURN ON

Method 1: Take the earphones out from the charge case, the earphones will turn on automatically and the LED indicator of the earphones flashes in Red and Blue rapidly.

Method 2: Long Press Multi-function button for 2s to turn on the earphones, and the led indicator of the earphones flashes in Red and Blue rapidly.

Note: The earphones can not turn on under charging.

TURN OFF

Method 1: Long press Multi-Function button for 4s to turn off the earphones, the led indicator of the earphones will be off after flashing 3 times in RED.

Method 2: Put the earphones into the charge case to turn off.

Note:

1) If you do not pair it with any Bluetooth device after taking the earphones out of the charge case, it will turn off after about 3 minutes

2) If the earphones are paired with each other, long press Multi-Function button of any earphone for 4s to turn off.

TWO TWS PAIRING (CONNECT 2 EARPHONES TOGETHER)

Take the earphones out of the charge case, both earphones will automatically pair with each other together with the LED indicator of host earphone flash in Red and Blue rapidly, and the other one flash in blue slowly.

Note: If the earphones paired unsuccessfully, long press Multi-Function button of both earphones for 5s, the led indicator of the earphones flash in Blue one time, then turn on both earphones,they will pair with each other automatically.

THREE PAIR BOTH EARPHONES WITH THE BLUETOOTH DEVICE

Follow up above steps to turn on the earphones, activate Bluetooth on your mobile device, select the **"B-One Plus"** from the list of available Bluetooth devices.

Once paired successfully, you will hear a message indication "Connected" and the LED on both earphones will be off.

FOUR Button function

PLAYING MUSIC

Previous song : Short press the MF button of left Earpod 2 times will return you to the previous track.
Next song : Short press the MF button of right Earpod 2 times will take you to the next track.
Increase Volume : Short press the MF button of right Earpod 3 times to increase the volume.
Decrease Volume : Short press the MF button of left Earpod 3 times to decrease the volume.
Pause/Play : Short press the MF button of one Earpod will resume the music.

MAKE A CALL

Answer an incoming call : Short press Multi-Function button one time
Reject an incoming call : Long press Multi-Function button
End the call : Short press Multi-Function button one time

VOICE ASSISTANT:

Activate the voice assistant: Short press the Multi-Function button of any earphones for 1.5s to activate the SIRI voice assistant function, only IOS system supported.
Close the voice assistant: Short press again the Multi-Function button of any earphones for 1.5s to close the SIRI voice assistant function, only IOS system supported.

FIVE CHARGING INSTRUCTION

Put the Bluetooth earphones into the charge case to begin charging the earphones, the led indicator on the earphones turn red to indicate the battery is being charged. When the battery is fully charged, the led light will light up in blue, then off.

SIX Care and Maintenance

ATTENTION

1.Please kindly read this user manual before using the product carefully, and keep it for future reference.
2.Please charging the product battery fully when first use.
3.If do not use the product exceed 2 weeks, please charging it.
4.Please only use the supplied cable to charging the product and certified adaptor.
5.If the earphone can not be paird with mobile phone, please check first if the earphone was in bluetooth mode; if the earphone unable paired with mobile phone device, please turn off the earphone first ,then turn on and make sure it is in bluetooth pairing mode; If the mobile phone didn' t reponse, please reboot the mobile phone; If the earphone didn' t reponse, please reboot the earphone or recovery default setting.

CAUTION

- Do not use the product at excessive volume levels or long time, as damage to hearing may occur.
- Do not charging the earphone with current exceed 2A, the battery might get damaged.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.