Internal Use

oraimo
smart accessories

WRAP
-OBS-40S-

Please read this Guide carefully before using the product

PACKAGE CONTENTS

Wireless Speaker x 1



Type-C Charging Cable x 1



Welcome Guide x 1

PRODUCT OVERVIEW

1. Power / Play/Pause
2. Volume Up/Next Track Button
3. Volume Down/Previous Track Button
4. 3.5mm AUX Input
5. Memory Card Slot
6. Type-C Charging Port
7. LED Indicator



BASIC PRODUCT SPECIFICATIONS

BT Version: V5.1

Range: 10m

Music Play Time: Up to 10 hours

Battery Capacity: 1500mAh

Charging Input: Type-C

Frequency Response: 90Hz-20KHz

Audio Output: 5W

USING YOUR SPEAKER

1. Power on / off



Long press the Power button for 1 second

LED Ring Indicator		Status
○	Steady white for 1s	ON
☼	Flashing white for three times then lights off	OFF

- The speaker will automatically turn off after 10 minutes if no device is connected.
- If the speaker is not used for more than 30 minutes while connected, it will automatically turn off.

2. Pair with your device



LED Ring Indicator		Status
☼	Slow flashing blue	Pairing mode
●	Steady blue	Connected to a device

- When turned on, the speaker will automatically connect to the last connected device if available. Otherwise the speaker will enter pairing mode.
- Having a connection problem? Remove "oraimo Wrap" from your device's BT list and ensure the speaker is within 1 meter from the device. Start pairing process again. For the best sound quality, make sure there is a clear line of sight between the connected device and the speaker.

3. Charge the speaker

LED Ring Indicator		Status
●	Steady red	Charging
○	Steady white	Fully charged

- Use the included Type-C cable to charge the speaker and charge the speaker fully before first use.
- Disconnect your speaker from the charger when fully charged. Do not charge your speaker for extended periods.
- It has voice prompt when the battery is low.



4. Battery Power Level

Long press + and − button for 2 seconds at the same time to check current battery power level, the corresponding voice prompt will be heard.

LED Ring Indicator		Status
●	Steady red	Low battery
●	Steady orange	Medium level battery
○	Steady white	High level battery

5. Connected via AUX



- Upon detecting that a device is connected via AUX port, the speaker will enter AUX Mode. When the connection is successful, a voice prompt will be heard.

6. Connected via Memory Card



- Upon detecting that a device is connected via Memory Card port, the speaker will enter Memory Card mode. When the connection is successful, a voice prompt will be heard.
- Double press ◁ to enter Memory Card mode under the Bluetooth mode if no AUX connection.

7. Connected via FM

Double press ◁ to enter FM mode under the Memory Card mode, or double press ◁ to enter FM mode under the Bluetooth mode without Memory Card connection.
When the connection is successful, a voice prompt will be heard.



- The speaker will enter Memory Card mode or Aux-in mode only they are detected to be connected. The sequence of speaker playing mode is Bluetooth mode, Memory Card mode, FM mode and Aux-in mode if the Memory Card and Aux-in input are both detected.

CONTROLS

✱ · ▯		
◁	Short press once	Play/Pause
−	Short press once	Volume down
	Long press for 1 second	Previous track
+	Short press once	Volume up
	Long press for 1 second	Next track
📻		
◁	Short press once	Search radio station
−	Short press once	Volume down
	Long press for 1 second	Previous station
+	Short press once	Volume up
	Long press for 1 second	Next station
⌁		
◁	Short press once	Mute/Umute
−	Short press once	Volume down
+	Short press once	Volume up
Others		
◁	Double short press	Swich mode among BT/ Mrmory Card/FM/Aux-in mode
◁ −	Long press the two button at the same time for 2 seconds	Disconnect and re-enter paining mode

ATTENTION

- To preserve battery lifespan, fully charge at least once every 45 days.
- Use original or certified cables.
- Do not expose to chemical liquids.
- Do not disassemble.
- Avoid dropping.
- Avoid extreme temperatures.

TROUBLE SHOOTING

Symptom	Solution
Battery does not charge	• Make sure you are using the oraimo's original USB cable. • Connect the USB cable to a different USB power supply. • Connect to a different AC (mains) power source.
Speaker does not pair with mobile device	• On your mobile device, turn the BT feature off and then on. Remove your speaker from the BT history on your device. Pair your device again.
No sound	• On your mobile device, turn the BT feature off and then on. Remove your speaker from the BT history on your device. Pair your device again. • Increase the volume on your speaker, your device and music source.
No sound from a cabled device	• Power on the device and play music. • Increase the volume on your speaker and device. • Connect a different device.
Poor sound quality	• Use a different music source. • Pair with a different device. • Increase the volume on the device. • Check device audio settings.
Poor sound quality from a cabled device	• Increase the volume on your speaker and device. • Connect a different device. • Check device audio settings.

CONSIDERATE HINTS

1. Do not turn up the volume to a fair high level constantly as this could shorten the service life of this product or impair your hearing.
2. When encounter any fault during operation, please cut off the power supply and disconnect the Type-C cable to prevent further damage to the product or other components.
3. The wireless transmission range or connectivity could be affected by low battery power. In that case, please recharge immediately.

CUSTOMER SERVICE

365 DAYS WARRANTY oraimo

365 DAYS WARRANTY

✉ **Email:** service@carlcare.com

Portable Wireless Speaker
Model: OBS-40S
Hereby, ORAIMO TECHNOLOGY LIMITED.
Declares that this Portable Wireless Speaker is in compliance with the essential requirements and other relevant provisions of directive

FCC Caution:
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

CAUTION
1.Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instructions.
– disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
– leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
– a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
2.The product shall only be connected to a USB interface of version USB2.0
3.EUT Temperature: : -10℃ ~ +50℃

Operating Frequency:
BT: 2402-2480MHz

Modulation mode:
GFSK, π/4-DQPSK, 8DPSK

EU DECLARATION OF CONFORMITY
In accordance with EU Directives and Regulations
Company name: ORAIMO TECHNOLOGY LIMITED

ADDRESS: FLAT N 16/F BLOCK B UNIVERSAL INDUSTRIAL CENTRE 19-25 SHAN MEI STREET FOTAN NT HONGKONG

as the manufacturer here by declares under our sole responsibility that the, Product(s): Portable Wireless Speaker

Model name: OBS-40S
is in conformity with the essential requirements of the RE Directive 2014/53/EU:

Radio Article 3.2	ETSI EN 300 328 V2.2.2 (2019-07)
EMC Article 3.1(b)	ETSI EN 301 489-1 V2.2.3 (2019-11) ETSI EN 301 489-17 V3.2.4 (2020-09);
Safety Article 3.1(a)	EN IEC 62368-1:2020+A11:2020
Health Article 3.1(a)	EN 50663:2017, EN 62479:2010

An EU Type Examination Certificate for this Product was issued in accordance with Annex III (Module B) of the 2014/53/EU Radio Equipment Directive by Bay Area Compliance Laboratories Corp. (2014/53/EU Radio Equipment Directive Notified Body Identification Number 1313)

Signed on behalf of ORAIMO TECHNOLOGY LIMITED

(Signature of authorized person)
Nengyong.wu
Manager
Date: 2022-06-21

nengyong. wu

WARRANTY CERTIFICATE

Name :	
Address :	
Tel. No. :	
Date of purchase : (dd/mm/yy)	
Store name :	
Warranty period :	

WARRANTY TERMS & CONDITIONS

- All quality-related defects on items sold directly by oraimo or oraimo's authorized resellers are covered by an extensive warranty, starting from the date of purchase.
- oraimo's limited warranty is restricted to the country of purchase. The limited warranty is void on items taken outside the country they were originally bought in or shipped to directly from an authorized online purchase.
- This warranty covers only original oraimo products. It is not applicable to normal wear and tear, or any defects arising from damage caused by misuse of this product.
- Warranty is for the primary product only nor transferable. Any free additional product(s) are not covered in this warranty.
- If the product fails regardless of usage in compliance with the instruction manual and other written precaution, replacement will be provided free of charge.
- To claim the warranty, contact the services team from the platform or store where you bought from.

For more information, please visit:

www.oraimo.com

@oraimo accessories