AI Simultaneous Language Translator

Instruction Manual

Key description

On/Off button

Power On: Long press the power button until the screen turns on.

Shut Down: Press the power key for more than 2s, Press "Power off "to turn off the device.

Reboot: Press "Reboot" to restart the device.

Volume key: Adjust the volume "+/- ".

BACK key:Return to main menu.

System Language: English,Spanish,German,Italian,French, Russian,Polish,Chinese Simplified,Chinese Traditional, Japanese,Thai,Vietnamese,Korean,Arabic,etc.



Voice Translation (Online mode)

1.Make sure connect to personal WiFi /Hot-spot successfully,click the "Voice" translation icon to enter translation interface first.
2.Select "Mother tongue language " in the upper left icon,then select "Foreign language" in the upper right icon. As shown below.
3.Long press and hold the "Mother tongue input key" or "Foreign language input key" to speak. After you finish speaking and releasing the key,the translator will automatically translate.

Note:
1.This function needs to be used in a private network, NOT support secondary authentication WiFi,such as airport WiFi and public WiFi.
2.Click the speaker icon on the screen to play the voice repeatedly
3.The clearer the voice input is, the more accurate the recognition is.The maximum input time is one minute.

Offline Translation Mode

1.The "Offline translation" mode can be used in an environment without network.
2.Select "Mother tongue language"in the upper left icon , then select "Foreign language" in the upper right icon. As shown below.
3.Long press and hold the "Mother tongue input key" or " Foreign language input key" to speak .After you finish speaking and releasing the key,the translator will automatically translate.



Photo Translation Mode

1.This mode allows you to take a photo and translate the text featured on it.
2.Click the"Photo translation" icon,select the original language you want to take a photo, and select other language you want to translate on the top right.
3. Take a picture of the text you want to translate by pressing the middle round icon on the screen, the text of picture will be translated after 3~5 seconds.
4.Click"Text"on the top to see translation text,click the yellow or blue speaker to broadcast the language.



Note:
1.This function can be used in the environment with or without network.
2.Try to shoot and translate in horizontal or vertical text.
3.Make sure the image quality is good enough to ensure proper text detection.
4.Click the picture at the bottom left corner ,and click on the top icon to delete it.

Recording Translation Mode

1.Click the "Recording" icon,Click + icon to select the translation mode. There are three recording modes for optional.
2.Select the translation of original text /The original/The translation modes.Select the language you want to record and translate on the top bar.
3.Click the speaker button on the screen, the timer will start to record and the text will appear on the screen. Then click "Save recording".



Note:
1.Click the "Play icon" below to play the input voice
2.Click the "Pencil icon" to clean the recording file and free up space
3.The clearer the voice input, the more accurate the translation.

Simultaneous Interpretation

1.Click "Interpret" icon and click "Enter" on the screen ,this function can be converted into corresponding text and translated while speaking.
2.It can also be shared with others,please scan the QR code on the screen by Wechat,Facebook,Google etc., it will be translated to other device simultaneously.

Mobile group chat translation

1.This function can create a remote chat room: set your name, select your language, and "Click to Create" to generate a QR code. Take a photo of the QR code and send it to your friends for scanning, and you can click " Star " to enter the chat room.
2.When your friends entering the chat room, they need to set a name and language.
3.In the chat room, you can speak in your own native language, you just need to press and hold the"Mother tongue input key" to speak, your language will be automatically translated into your friends native language on the screen.
The same,when your friends speak,their contents will be automatically translated into your own native language on the screen.

Note:
1.This function needs to be used in a private network,NOT support secondary authentication WiFi,such as airport WiFi and public WiFi.
2.Participants must scan the QR code ,sharing the QR code with the other party through social media, then enter the chat room.

Conference Mode

This function requests two or more devices,click the "Conference" icon.
To create a new conference,press Start and input your name and select your language then press Input.
The device will generate a code to share with other participants.
The participants can enter the code and press Join, then enter name and select language and press Input to start.

Input Mode

Enter text in the bottom bar to translate your target language,this function only support English and Chinese currently.

Learning Mode

This mode allows you to practise the pronunciation of the words you have translated.This mode must be connected with WiFi network.

SOS Mode

Included different countries emergency call numbers.

Tool Mode

Included Dictionary,Clock,Exchange Rate.

Favorites Mode

This mode is used to collect words and sentences or video that can be reviewed frequently.

Setting Mode

WiFi setting,Brightness,System Language,Speed,Sound, Front,Time Zone,Switch input method,Date and time, Update,etc.

Bluetooth

After turning on the Bluetooth to switch button, you can set the Bluetooth device you want to link to achieve various expansion functions

Note:Charging Power

*This product are not equipped with a power charger.
*User could use the attached cable and their own charger.
*Power charger must be conformed to the CE/UL certifications.
*Input:100-240V~50/60Hz 0.2A ,Output: 5V==1A standard power supply.

FAQ

How is the accuracy of device?
In daily dialogue,accuracy rate is up to 98%.

How to operate and speak properly to make sentence more accurate?
. Press the button 1~2 second properly and then speak. Release the button after you finish.
.Please try to speak standard language and avoid using a mantra or a slang.
.Speak consistently ,clearly,naturally. Avoid multiple pauses or merge statements.
.Try to avoid professional terminology words.

If the product crashed while it's working?
. Press and hold the power button over 15 seconds,then release button to see if its screen works or not.

If the product can't connect to WiFi?
.Make sure the device has connected to WiFi (2.4G mode) and enter the correct password.Or try to connect to your hot spot of cellphone for test.
.WiFi network requires web page login, such as hotels, airports and public places are not supported.

If the product can't be turned on?
.To check if device has run out of battery,please charge it above half an hour ,then press power button about 3-5 second to turn on again.

If product can't be charged?
.To Check if it is a properly matched power adapter.
.To Check that the wires and connectors are properly connected.

Warranty

.To prevent fire or shock hazard,disconnect your device from the power source when cleaning.Use a soft ,clean cloth to clean it.
.This product does not have waterproof design. Please do not use it in splashing water or other environments that may cause water ingress.
.Do not disassemble this product and its accessories by yourself.
.This product is covered by our 1 year warranty program

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

人工智能 · 同声即时翻译机

使用指南

主机按键说明

开机：长按电源键 2s 以上，屏幕亮启开机动画至翻译界面，即可正常使用

关机：长按电源键 2s 以上，屏幕弹出 Power off/Reboot 图标选择 Poweroff 键，设备关机。

音量键：调整音量大小，单击**右侧+**按键增加音量；单击**右侧-**按键减小音量至最低即静音模式。

重启：长按电源键，屏幕显示 Power off/Reboot 图标，按 Reboot 键，设备重启。

返回键：点按返回键，可返回上一级功能

主菜单包含主要功能：在线翻译，离线翻译，拍照翻译，手机群聊，同声传译，录音翻译，多国会议，世界钟，汇率换算，SOS，语言学习，输入翻译，AI，实用工具（词典，口语学习，单词库）收藏夹，设置

语音翻译

连接上Wifi，选择语音翻译，长按母语翻译键或者外语翻译键即可实现多个国家的语言之间相互翻译，如下图所示

温馨提示：
1.该功能需要在有网络的环境下使用
2.点击显示屏喇叭按钮或者点击喇叭按钮可对语言重复播放
3.母语输入键对应左边翻译语种，外语输入键对应右边语种
4.语音录入越清晰识别越准确，最大录入一分钟时长

离线翻译

离线翻译模块可在没有网络的环境下使用，如下图所示：

温馨提示：
1.该功能**可以在**没有网络的环境下使用
2.点击显示屏喇叭按钮或者点击喇叭按钮可对语言重复播放
3.母语输入键对应左边翻译语种，外语输入键对应右边语种
4.语音录入越清晰识别越准确，最大录入一分钟时长

拍照翻译

点击拍照翻译图标，调整要翻的目标语种，将屏幕的窗口对准要翻译的内容，点拍照功能后等待**几**秒会出现要翻译的内容，

该模块摄像头对准需要翻译的字体进行拍照翻译，**多国**语种**可以进行选择**，点击黄色或者蓝色喇叭可对语种进行播报

温馨提示：
1.该功能**部分**语种需要在有网络的环境下**才**可以使用
2.该功能拍照越清晰翻译越准确
3.点击左下角图片可对该图片进行删除

录音翻译

单击右上角的"新建录制"选项可实时录制。选择自己录制的语言。点击右方开始录制按钮，有一边录制在屏幕上面会出现相对应的文字，然后点击保存翻译选择自己想翻译的语种即可完成翻译

温馨提示：
1.该功能需要在有网络的环境下使用
2.点击下方播放按钮可对录入语音进行播放
3.点击铅笔按钮可以对录音文件进行删除释放空间
4.语音录入越清晰翻译越准确，

同声传译

功能简介：
该**功能**可以**边说话便转成**对**应**文字**并**翻译、**同时也**可以分**享给他人**
使用说明：
1.按一下翻译**键开始说话**，根据屏幕提**示**语种，**说**完**再**按一下翻译**键停止**。
2.一分**钟时长**后自**动停止**。
3.点**开右上角二维码**用**手机扫描**可分**享给**好**友同传**

手机群聊

此功能可创建聊天室、设置好名字、选择好语种后点击创建聊天会生成一个二维码、把二维码拍照发送给其他人进行扫描，即可进入聊天室（进入聊天室时需要设置名字和语种）在聊天室内可以用自己设置的母语进行聊天、对方发来的文字会自动转变成自己的母语。

温馨提示：
1.该功能需要在有网络的环境下使用
2.对方发**送来的文字可以进行播报**
3.**参**语者可以**通过扫描二维码**，或者用**手机拍照此界面**，**通过社交软**件分**享给**对方**识别二维码**后进入**聊天室**。

口语学习

该模块是一款针对英语日常用语进行播放，用户可对该语句进行跟读，以查看自己的发音是否流利 完整，准确以及总分情况结合评测情况改进不足的地方，更好的提升口语水平。

单词库

单词库是一款针对英语单词学习的背单词软件，涵盖小初高中词汇、四六级核心词汇、考研、雅思、托福、GRE核心词汇**等**，同步英式美式发音。以答题的形式增强记忆，已达到记忆单词的目的

AI助手

点击语音查询图标进入此模块，:需在WiFi网络良好的情况下使用。可以实现AI语音识别，实现简单人机交互。

收藏夹

该模块是用于收藏学员经常忘记一写单词和句子或者视频资料等。在扫描界面，语音翻译界面或者口语评测界面和词典界面，点击五角星按钮后进行收藏，后续复习可直接打开进行使用观看。再次复习进行加强记忆

翻译使用温馨提示：

为了确保翻译品质及语句完整性，按下翻译键后，请于听到提示音1秒后再说出想翻译的语句。请用正常语速连贯地说话，请勿在讲话过程当中多次停顿，或者两句话并成一句说，以上情况均容易造成翻译不准请尽量避免。

请尽量避免口头禅或当地语

产品使用注意事项

使用翻译机进行充电时，翻译机发热属于正常现象。产品元件含金属、塑料以及内部敏感的电子元件。如果被摔、焚烧、刺穿、挤压或接触化学液体，有可能导致损坏。

维修：
请勿拆卸翻译机和尝试自行修理，如出现损坏，故障或者接触到液体，请联系售后客服。

使用环境：
避免在温度过高或过低的环境下使用翻译机，避免长时间日照而导致机身出现不良反应。请注意将翻译机及电源适配器放在通风良好的环境，避免金属腐蚀。

充电：
使用附带线缆及电源适配器;或者符合国家 3C 认证 input:100-240V~50/60HZ0.2A输出Qutput:5V==1A 标准的电源适配。请认真检查电源适配器制造商以查明是否符合要求操作温度:翻译机适合在温度介于-10°~55°的环境中工作，如果工作环境超过了温度范围，翻译机有可能导致故障，并且缩短电池寿命，请避免在阳光直射、过热、过冷、极度潮湿的环境下使用。

安全警告和说明

智能语音翻译机是经形式认证合格的低功率频设电器，非经许可，公司、商号或使用者均不得擅自变更电池，加大用电功率或变更原设计的功能特性。本产品不适合 14 岁以下儿童单独使用，请在家长陪同下使用。
在信号使用之前，请勿影响飞航安全及干扰合法通讯，经发现有干扰现象时应立即停用，直至无干扰后方可使用。
不遵循安全说明，有可能导致的火灾、电击、受伤或损坏翻译机或其他财物。
在遇到使用问题或维护之前，请先阅读安全使用条例信息。

有害物质说明

本产品在设计和生产时，采用了易降解，易回收，利用利用率高的环保材料、技术工艺，遵循电子信息产品有害物质或元素控制国家标准和行业标准，达到了《电子信息产品污染控制管理办法》的环保要求。

防水性能声明：
本产品不具有防水设计，请勿在溅水或其他易导致产品进水的环境使用。

保修条款：
1.本三包条款仅适用于公司在中国境内销售的产品。
2.本三包条款适用于从公司或其认可的经销商处购买该产品的消费者。
3.退机、换机和免费维修服务，应凭有效产品发票和有效的三包凭证办理。
4.以上三包条款如与国家相关法律法规有冲突以国家发布的三包条款为准

维护与保养注意事项

1.不可自行拆开本产品及其配件，当本产品或配件出现故障时，请申请售后。
2.使用中如遇异常现象，请长按电源键直到本产品关机，这样可以解决一般的故障。
3.应保持本产品的清洁，当笔壳沾上汗液、灰尘等污渍，请使用清洁干燥的软布擦拭。
4.清洁本产品前，请先将本产品关机。

权利声明

1.未经本公司书面，严禁以任何形式修改、复制、分发、传播本手册部分内容或全部内容。
2.在任何情况下，办公司均不承担对任何意外事件，数据或其他地方造成的直接或间接的损失的责任。
3.本手册所有图片仅供参考，如有不符请以实物为准
4.操作系统仅支持官方升级，如有用户自己刷非官方系统导致安全风险和损失用户负责。

常见疑难

1、	产品不能启动？	·检查电池电量是否有电，插入充电线对产品进行充电。 ·长按电源键，松开后，确定开机画面是否正常开启。
2、	语音识别不准确？	·请按下按键听到提示音后再说话，说完后请松开按键。 ·请说标准语言，避免使用口头禅 ·说话请连贯，清晰，自然，避免多次停顿或合并语句。
3、	无法连接 WIFI？	·确保正常连接到 WIFI，并输入正确的密码。 ·目前暂不支持酒店、机场、公共场合等需要网页登录的 WIFI 源。
4、	不能正常充电？	·检查是否为正确匹配的电源适配器。 ·检查电线及接口是否正常连接。
5、	如何正确保养产品？	·在不使用的情况下请按关机键停用翻译机。 ·避免在-10°~55°的温度范围外使用。 ·本产品不防水，请勿将产品投入水中。

1、**相**关产品不配**备充**电**器**，**充**电**器由消消费者**自行配**备**。
2、自行配**备**的**充**电**器**应符**合标**准**要求**。
3、**提示消费者**自行配**备**的**充**电**器**如不**能**符**合要求**时可**能存**在的安全风险
4、**消费者若**使用电源**适配器充**电，**则**应**购买**配**套**使用**获得 CCC认证并满足标**准的电源**适配**器