Band26(824-849) QPSK BW=1.4MHz Channel=27033 RB Size=1 Position=#0



Band26(824-849) QPSK BW=10MHz Channel=26840 RB Size=1 Position=#0



Band26(824-849) QPSK BW=10MHz Channel=26915 RB Size=1 Position=#0

Band26(824-849) QPSK BW=10MHz Channel=26990 RB Size=1 Position=#0



Band26(824-849) QPSK BW=15MHz Channel=26865 RB Size=1 Position=#0



Band26(824-849) QPSK BW=15MHz Channel=26915 RB Size=1 Position=#0

Band26(824-849) QPSK BW=15MHz Channel=26965 RB Size=1 Position=#0



Band26(824-849) QPSK BW=3MHz Channel=26805 RB Size=1 Position=#0



Band26(824-849) QPSK BW=3MHz Channel=26915 RB Size=1 Position=#0



Band26(824-849) QPSK BW=3MHz Channel=27025 RB Size=1 Position=#0



Band26(824-849) QPSK BW=5MHz Channel=26815 RB Size=1 Position=#0



Band26(824-849) QPSK BW=5MHz Channel=26915 RB Size=1 Position=#0

Band26(824-849) QPSK BW=5MHz Channel=27015 RB Size=1 Position=#0



Band41 16QAM BW=10MHz Channel=39700 RB Size=1 Position=#0



Band41 16QAM BW=10MHz Channel=40620 RB Size=1 Position=#0



Band41 16QAM BW=10MHz Channel=41540 RB Size=1 Position=#0



Band41 16QAM BW=15MHz Channel=39725 RB Size=1 Position=#0



Band41 16QAM BW=15MHz Channel=40620 RB Size=1 Position=#0



Band41 16QAM BW=15MHz Channel=41515 RB Size=1 Position=#0



Band41 16QAM BW=20MHz Channel=39750 RB Size=1 Position=#0



Band41 16QAM BW=20MHz Channel=40620 RB Size=1 Position=#0

Band41 16QAM BW=20MHz Channel=41490 RB Size=1 Position=#0



Band41 16QAM BW=5MHz Channel=39675 RB Size=1 Position=#0



Band41 16QAM BW=5MHz Channel=40620 RB Size=1 Position=#0



Band41 16QAM BW=5MHz Channel=41565 RB Size=1 Position=#0



Band41 QPSK BW=10MHz Channel=39700 RB Size=1 Position=#0



Band41 QPSK BW=10MHz Channel=40620 RB Size=1 Position=#0



Band41 QPSK BW=10MHz Channel=41540 RB Size=1 Position=#0



Band41 QPSK BW=15MHz Channel=39725 RB Size=1 Position=#0



Band41 QPSK BW=15MHz Channel=40620 RB Size=1 Position=#0

Band41 QPSK BW=15MHz Channel=41515 RB Size=1 Position=#0



Band41 QPSK BW=20MHz Channel=39750 RB Size=1 Position=#0



Band41 QPSK BW=20MHz Channel=40620 RB Size=1 Position=#0



Band41 QPSK BW=20MHz Channel=41490 RB Size=1 Position=#0



Band41 QPSK BW=5MHz Channel=39675 RB Size=1 Position=#0



Band41 QPSK BW=5MHz Channel=40620 RB Size=1 Position=#0



Band41 QPSK BW=5MHz Channel=41565 RB Size=1 Position=#0



Band66 16QAM BW=1.4MHz Channel=131979 RB Size=1 Position=#0



Band66 16QAM BW=1.4MHz Channel=132322 RB Size=1 Position=#0



Band66 16QAM BW=1.4MHz Channel=132665 RB Size=1 Position=#0



Band66 16QAM BW=10MHz Channel=132022 RB Size=1 Position=#0



Band66 16QAM BW=10MHz Channel=132322 RB Size=1 Position=#0



Band66 16QAM BW=10MHz Channel=132622 RB Size=1 Position=#0



Band66 16QAM BW=15MHz Channel=132047 RB Size=1 Position=#0



Band66 16QAM BW=15MHz Channel=132322 RB Size=1 Position=#0



Band66 16QAM BW=15MHz Channel=132597 RB Size=1 Position=#0



Band66 16QAM BW=20MHz Channel=132072 RB Size=1 Position=#0



Band66 16QAM BW=20MHz Channel=132322 RB Size=1 Position=#0

Band66 16QAM BW=20MHz Channel=132572 RB Size=1 Position=#0



Band66 16QAM BW=3MHz Channel=131987 RB Size=1 Position=#0



Band66 16QAM BW=3MHz Channel=132322 RB Size=1 Position=#0



Band66 16QAM BW=3MHz Channel=132657 RB Size=1 Position=#0



Band66 16QAM BW=5MHz Channel=131997 RB Size=1 Position=#0



Band66 16QAM BW=5MHz Channel=132322 RB Size=1 Position=#0



Band66 16QAM BW=5MHz Channel=132647 RB Size=1 Position=#0



Band66 QPSK BW=1.4MHz Channel=131979 RB Size=1 Position=#0



Band66 QPSK BW=1.4MHz Channel=132322 RB Size=1 Position=#0



Band66 QPSK BW=1.4MHz Channel=132665 RB Size=1 Position=#0



Band66 QPSK BW=10MHz Channel=132022 RB Size=1 Position=#0



Band66 QPSK BW=10MHz Channel=132322 RB Size=1 Position=#0



Band66 QPSK BW=10MHz Channel=132622 RB Size=1 Position=#0



Band66 QPSK BW=15MHz Channel=132047 RB Size=1 Position=#0



Band66 QPSK BW=15MHz Channel=132322 RB Size=1 Position=#0

Band66 QPSK BW=15MHz Channel=132597 RB Size=1 Position=#0



Band66 QPSK BW=20MHz Channel=132072 RB Size=1 Position=#0



Band66 QPSK BW=20MHz Channel=132322 RB Size=1 Position=#0



Band66 QPSK BW=20MHz Channel=132572 RB Size=1 Position=#0



Band66 QPSK BW=3MHz Channel=131987 RB Size=1 Position=#0



Band66 QPSK BW=3MHz Channel=132322 RB Size=1 Position=#0



Band66 QPSK BW=3MHz Channel=132657 RB Size=1 Position=#0



Band66 QPSK BW=5MHz Channel=131997 RB Size=1 Position=#0



Band66 QPSK BW=5MHz Channel=132322 RB Size=1 Position=#0



Band66 QPSK BW=5MHz Channel=132647 RB Size=1 Position=#0



Band71 16QAM BW=10MHz Channel=133172 RB Size=1 Position=#0



Band71 16QAM BW=10MHz Channel=133297 RB Size=1 Position=#0

Band71 16QAM BW=10MHz Channel=133422 RB Size=1 Position=#0



Band71 16QAM BW=15MHz Channel=133197 RB Size=1 Position=#0



Band71 16QAM BW=15MHz Channel=133297 RB Size=1 Position=#0

Band71 16QAM BW=15MHz Channel=133397 RB Size=1 Position=#0



Band71 16QAM BW=20MHz Channel=133222 RB Size=1 Position=#0



Band71 16QAM BW=20MHz Channel=133297 RB Size=1 Position=#0

Band71 16QAM BW=20MHz Channel=133372 RB Size=1 Position=#0



Band71 16QAM BW=5MHz Channel=133147 RB Size=1 Position=#0



Band71 16QAM BW=5MHz Channel=133297 RB Size=1 Position=#0



Band71 16QAM BW=5MHz Channel=133447 RB Size=1 Position=#0



Band71 QPSK BW=10MHz Channel=133172 RB Size=1 Position=#0



Band71 QPSK BW=10MHz Channel=133297 RB Size=1 Position=#0



Band71 QPSK BW=10MHz Channel=133422 RB Size=1 Position=#0



Band71 QPSK BW=15MHz Channel=133197 RB Size=1 Position=#0



Band71 QPSK BW=15MHz Channel=133297 RB Size=1 Position=#0



Band71 QPSK BW=15MHz Channel=133397 RB Size=1 Position=#0



Band71 QPSK BW=20MHz Channel=133222 RB Size=1 Position=#0



Band71 QPSK BW=20MHz Channel=133297 RB Size=1 Position=#0



Band71 QPSK BW=20MHz Channel=133372 RB Size=1 Position=#0



Band71 QPSK BW=5MHz Channel=133147 RB Size=1 Position=#0



Band71 QPSK BW=5MHz Channel=133297 RB Size=1 Position=#0