75.00 mm 75.00 mm 75.00 mm

75.00 mm

Mug Warmer & Qi Wireless Fast Charger
Qi急速ワイヤレス充電器(加熱/恒温機能搭載)
智能无线充电器(加热/恒温功能)

使用説明書
MANUAL
QTO402

扫码观看



一、产品介绍



二、LED灯使用指南

无线充模式

产品通电后，进入待机状态，显示红色灯;手机放置无线充电器上自动进入充电状态，(此时智能开关无作用)拿开手机自动退出充电模式，进入待机状态。

恒温保温模式



长按智能开关2秒进入恒温模式，显示紫色灯;15秒内放置杯子到产品上，进入保温工作状态，显示蓝色灯，(此时智能开关无作用)
如15秒内不放置杯子，会自动退出恒温模式，进入待机状态;在不拿起杯子使用情况下系统连续恒温1.5小时停止。
在进入恒温模式后如不放入杯子，触摸一次智能开关，退出恒温模式，红灯亮此时系统退回到待机状态

金属铁罐饮料加热模式

连续轻触智能开关2下进入金属铁罐饮料加热模式，显示白色灯;15秒内放置金属罐装饮料到产品上，进入金属罐装加热状态，显示浅绿色灯，(此时智能开关无作用)
如15秒内不放置金属铁罐饮料，会自动退出加热模式，进入待机状态;在不拿起饮料使用情况下系统连续恒温1.5小时停止。
在金属加热模式如不放金属铁罐饮料，触摸一次智能开关，也会进入待机状态

中文

7.2 CM

8.7CM



容量:360ML　　恒温:55°
材质:陶瓷　　颜色:白色
重量:335g
温馨提示:该产品可以用作消毒柜和洗碗机,但是请不要将其用于微波炉,电加热器等。
另外,请勿进行明火等尝试,以免引起火灾。

注意事項警告
• 我们所有的无线充电产品都符合Qi标准。
• 为确保安全和正常运行，请确保使用符合产品规格的电源适配器进行充电。
• 可能导致故障或触电。
• 为手机和 Qi 兼容设备充电时，必须处于充电模式。除充电模式外，无法充电。
• 可能导致故障和火灾等危险。
如果本产品在满载时运行一段时间，则会产生一定的热量，但工作正常。
(在杯恒温和金属罐加热时，本产品温度达到到55°C。)
• 在杯式恒温和金属罐加热时，本产品温度达到约 55°C，因此请勿用手或皮肤直接接顶板背面的散热器伸出，温度稳定，但皮肤异常，有受伤的风险。
• 只使用儿童，请不要把它放在儿童接触的地方。
温度稳定，皮肤异常，触电等受伤。
由于本产品由电力操作，因此存在在复杂事件中起火的风险。如果冒烟或异味，请勿关闭本产品和连接的计算机或设备。
• 当雷声响起时，请勿触摸本产品或电缆。
闪电可能会触电。
请勿拆卸、改装本产品。
• 不符合产品保修条件。此外，对于身体和连接设备的故障、人身伤害或社会故障，我们概不负责。
• 请勿用茉莉毡擦本产品或电缆。
• 本产品经过防水处理，但电缆连接器和顶板背面的散热器在连接到计算机时可能会触电。
• 请勿在水中或浅水。
可能导致故障或触电。
• 请勿在本产品的放置液体、金属等异物。
可能导致触电、火灾或故障。
请勿对本产品产生强烈的振动或冲击。
可能导致故障或损坏。

• 本产品在潮湿和潮湿的地方使用,阳光直射的地方,许多地方,如灰尘和热水烟雾,或用于高温的地方,如汽车或加热设备附近,安装,请勿存储。
• 可能导致故障或触电。
请勿安装本产品,也不要将重物放在本产品上。
可能导致火灾或故障。
• 请勿将本产品安装在不稳定位置或存放。
坠落可能导致故障或损坏。
重新按插本产品的电缆时,始终其有连接器部分,
不要施加过大的力量。
可能导致故障或损坏。
• 请勿用莫高踩在本产品的电缆上,也不要夹在门上。
此外,请勿拉或弯曲这些电缆。
可能导致火灾或故障。
• 不能保证在使用本产品时发生的连接设备的数据和程序的丢失。
• 请事先采取措施,如定期备份。
• 清洁本产品时,请勿使用含有挥发性有机溶剂(如苯或稀释剂)的溶剂。
• 油漆可能会损坏或可能导致故障。按下电源后,用干软布擦干。
本产品不用于医疗设备、核设施和设备、航空航天设备、与生命有关的设备和设备,如连输设备和设备,以及需要高度可靠性的设备、设备和系统。对于此类应用,对于因人身伤害或社会残疾而造成的任何损害,我们概不负责。
• 如果长时间不使用本产品,请断开与 USB 端口的一起使用。
• 关于本文件的内容,我们一致努力,但如果您有任何可疑点、错误或遗漏,请联系您购买的经销商。

FCC声明:

本设备符合FCC规则的第15部分,操作需符合以下两个条件:
(1) 本设备不会造成有害干扰,以及
(2) 本设备必须能够接受接收到的任何干扰,包括可能导致意外操作的干扰

警告:未经合规责任方明确批准的变更或修改可能会导致用户丧失对本设备的操作权限。

注意:根据FCC规则第15部分的规定,本设备已通过测试并符合B类数字设备的限制。这些限制设计用于对住宅装置的有害干扰提供合理的保护。本设备会对辐射射频能量产生影响,如不按照说明安装和使用,可能会对无线电通信造成有害干扰,且无法完全保证在特定安装中不会发生干扰。如果本设备确实对广播或电视接收造成了有害干扰,可以通过关闭和打开设备来确定,建议用户尝试通过以下一种或多种措施来纠正干扰:

重新调整或定位接收天线的方向。
增加设备和接收器之间的距离。
将设备连接到不同于接收器所连接电路的插座之上。
咨询经销商或经验丰富的无线电/电视技术人员以获取帮助。

FCC辐射暴露声明:

本设备符合FCC针对非受控环境规定的辐射暴露限值。在安装和操作本设备时,散热器与您身体之间的最小距离应保持在20厘米以内。

Smart Wireless Charger (with heating and constant temperature functions)

Manual

QTO402

viewing



I. Product introduction



Wireless charging LED indication

II. LED Light User Guide

Wireless charging mode

The product will enter the standby mode with red light after being electrified; when the mobile phone is placed on the wireless charger, the charging will automatically enter the charging mode (at this time, the intelligent switch will not work), and the charger will automatically exit the charging mode and then enter the standby mode after removing the mobile phone from the wireless charger.

Mode of heat-insulating und er constant temperature



The product will enter the constant temperature mode with purple light after pressing the intelligent switch for 2 seconds; and the product will enter the moment mode with blue light after placing the cup on the product within 15 seconds (at this time, the intelligent switch will not work)
If the cup is not placed within 15 seconds, the product will automatically exit the constant temperature mode and then enter the standby mode; the system will keep constant temperature for 1.5 hours and then stop working without removing the cup.
If the cup is not placed within 15 seconds after entering the constant temperature mode, the product will exit the constant temperature mode after touching the intelligent switch for one time, and the system will return to the standby mode with the red light

Heating mode of metal canned drinks

The product will enter the heating mode with white light after touching the intelligent switch for successive two times; and it will enter the heating condition with pale green light after placing the metal canned drinks on the product within 15 seconds (at this time, the intelligent switch will not work)
If the metal canned drink is not placed within 15 seconds, the product will automatically exit the heating mode and then enter the standby mode; the system will keep constant temperature for 1.5 hours and then stop working without removing the metal canned drinks.
If the metal canned drink is not placed on the product under the heating mode, the product will enter the standby mode with touching the intelligent switch for one time

英文

7.2 CM

8.7CM



Capacity: 360ML　　Constant temperature: 55°C
Material: Ceramics　　Color: white
Weigth: 335g
Warm tips: The product can be used for disinfection cabinet and dishwasher due to the specifications. please do not use it for a sub range, electric heater, etc.
in addition, please do not make a trial such as giving an Ipen fire, which may lead to afire.

Notes and warnings
• All of our wireless charging products comply with the Qi standard.
• To ensure safety and normal operation, be sure to use a power adapter that meets product specifications for charging.
• It may cause malfunction or electric shock.
• When charging a mobile phone or Qi compatible device, it is necessary to charge in charging mode. It cannot be charged in any mode other than charging mode.
• There is a risk of failure and fire.
• If this product operates at full load for a certain period of time, some heat will be generated, but it is within the normal operating range. (The temperature of this product reaches about 55°C when the temperature of the cup is constant and the metal can is heated.)
• When the temperature of the cup is constant or the metal can is heated, the temperature of this product reaches about 55°C.
• There is a risk of injury such as constant temperature burns and skin abnormalities.
• Use only by children, please keep out of reach of children.
• There is a risk of injury such as constant temperature burns, skin abnormalities and electric shock.
• Since this product is operated by electricity, there is a risk of fire in a complex event. If you should smoke or emit a strange odor, turn off the power of this product and the connected computer or device, and do not use it.
• Do not touch the product or cables while it is thundering.
• There is a risk of electric shock due to lightning strikes.
• Do not disassemble or modify this product.
• It is not covered by the product warranty. We are not responsible for any damage to the product or connected devices, personal injury or social damage.
• Do not touch this product or cables with wet hands.
• This product is waterproof, but the cable connector and heat sink on the back of the top board may cause an electric shock when connected to a PC.
• Do not soak or splash water.
• It may cause malfunction or electric shock.
• Make sure that no foreign matter such as liquid or metal gets inside the product.
• May cause electric shock, fire, or breakdown.
• Do not subject this product to strong vibration or shock.

• It may cause malfunction or damage.
Do not use, install, or store this product in places with high humidity or humidity, in direct sunlight, in places with a lot of dust or steam, in vehicles, or near high temperatures such as near heaters. please do not.
• It may cause a failure or electric shock.
• Do not stack the products on top of each other or place heavy objects on the products.
• May cause fire or malfunction.
• Do not install or store this product in an unstable place.
• Dropping may cause malfunction or damage.
• When connecting or disconnecting the cable of this product, be sure to hold the connector
Please do not apply excessive force.
• It may cause malfunction or damage.
• Do not step on the cable of this product with furniture or pinch it with a door.
Also, do not pull or bend these cables.
• May cause fire or malfunction.
• We cannot guarantee that data or programs on the connected device will be lost while using this product.
• Please take measures such as taking backup regularly.
• When cleaning this product, do not use one that contains volatile organic solvents such as benzine and thinner.
• It may damage the paint or cause a malfunction. Be sure to disconnect the power and wipe it with a dry soft cloth.
• This product should not be incorporated or used in medical equipment, nuclear equipment or equipment, aerospace equipment, equipment or equipment related to human life such as transportation equipment or equipment, or equipment, equipment or systems that require high reliability. Not Intended. Our company cannot take any responsibility even if this product is used for these purposes and causes personal injury or social injuries.
• If the product will not be used for a long time, disconnect it from the USB port.
• The contents of this paper have been created with the utmost care. However, if there are any suspicious points, errors, or omissions, please contact the store where you purchased the product.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Qi 急速ワイヤレス充電器(加熱/恒温機能搭載)

取扱説明書
MANUAL
QTO402

QR コードを読み取ると詳細を表示



一、製品概要



二、LED ランプについて

ワイヤレス充電モード

製品は電源オンになると、待機状態になり、赤色に点灯します,携帯電話をワイヤレス充電器 の上に置くと、自動的に充電状態になり、(このとき、スマートスイッチは機能しません)携帯電話を取り外すと充電モードが自動的に終了します。

恒温保温モード



スマートスイッチを 2 秒間押し続けると、恒温モードとなり、紫色に点灯します。
15 秒以内にカップを本製品の上に置くと、保温動作状態になり青色に点灯します。
15 秒以内にカップが置かれない場合、恒温モードが自動的に終了し、待機状態に戻ります。カップを加熱動作状態(青色)は、1.5時間一定温度に保持いたしますが、以降は自動的に停止いたします。
1.5時間経過および15秒以上本製品に金属缶を置かれない場合は、自動的に停止いたします。
再起動を行う場合は、スマートスイッチを 1回押すと恒温モードが使用します。このとき、赤色に点灯し、システムは待機状態に戻りますので再度一から設定をおこなってください。

金属缶飲料加熱モード



スマートスイッチを 2 回連続で押すと、金属缶加熱モードになり、白色に点灯します。15 秒以内に金属缶を製品の上に置くと自動的に検知し、加熱モード(緑色)に点灯をいたします。15 秒以内に金属缶が置かない場合、恒温モードが自動的に終了し、待機状態に戻ります。
金属缶を加熱動作状態(緑色)は、1.5 時間一定温度に保持いたしますが、それ以降は自動的に停止いたします。
1.5時間経過および15秒以上本製品に金属缶を置かれない場合は、自動的に停止いたします。再起動を行う場合は、スマートスイッチを 1回押すと、待機状態になります。

日文

7.2 CM

8.7CM



容量:360ML　　恒温:55°
材料:セラミックス　色:白色
重量:335g
ご注意:この製品は、消毒キャビネット、食洗器は仕様上問題はありませんが、電子レンジ、電熱器等には使用しないでください。
また、直火を与えるなど火災に繋がる試用はおこなわないでください。

注意事項および警告
•当社のワイヤレス充電製品はすべてQi規格に準拠しています。
• 安全と正常な動作を確保するために、充電には必ず製品仕様に適合する電源アダプターを使用してください。
•故障や感電の原因となります。
•携帯電話およびQi対応機器を充電する場合、充電モードで充電する必要があります。充電モードは以外で充電はできません。
•故障および発火等の危険が発生する恐れがあります。
•この製品が全角可で一定期間動作した場合、ある程度の熱が発生いたしますが正常動作範囲です。(カップ恒温時および金属缶加熱時には、本製品温度は55°C程度に達します。)
•カップ恒温時および金属缶加熱時には、本製品温度は55°C程度に達しますので、天板裏のヒートシンクを直接手や皮膚でさわらないでください。
•低温やけど、皮膚の異常などケガの恐れがあります。
•子供だけでご使用、お子様の手の届くところにおかないでください。
•低温やけど、皮膚の異常および煙などケガの恐れがあります。
•本製品は電気で動作しておりますので、複合的事象において発火する危険があります。 万一煙が出たり異臭がしたりした場合は、本製品及び接続しているコンピューターや機器の電源を切り使用をしないでください。
•雷が鳴っているときに、本製品やケーブルに触れないでください。
•落雷により感電する恐れがあります。
•本製品を分解、改造等をしないでください。
•製品保証対象外となります。また、本体ならびに接続機器の故障および人身事故・社会的障害などが生じても弊社はいかなる責任も負いかねます。
•濡れた手で本製品やケーブルに触らないでください。
•本製品は防水加工をされておりますが、ケーブルコネクタおよび天板裏のヒートシンクは、パソコンに接続されていると、感電する恐れがあります。
•水につけたり、水をかけたりしないでください。
•故障や感電の原因となる場合があります。
•本製品内部に液体、金属などの異物が入らないようにしてください。
•感電や火災、故障の原因となる場合があります。
•本製品に強い振動や衝撃を与えないでください。
•故障・破損などの原因となる場合があります。

•本製品を水分や湿気の多い場所、直射日光の当たる場所、ほこりや湿度などの多い場所、車中や暖房器具のそばなどの高温となる場所で使用したり、設置したり、保管したりしないでください。
•故障・感電などの原因となる場合があります。
•本製品を重ねて設置したり、本製品の上に重いものを置いたりしないでください。
•火災や故障の原因となる場合があります。
•本製品を不安定な場所に設置したり、保管したりしないでください。
•落下による故障・破損の原因となる場合があります。
•本製品のケーブルを強き兼しするときは、必ずコネクタ部分を持ち、
無理な力を加えないでください。
•故障・破損などの原因となる場合があります。
•本製品のケーブルは、家具で踏んだり、扉で挟んだりしないでください。
また これらのケーブルを引っ張ったり折り曲げたりしないでください。
•火災や故障の原因となる場合があります。
•本製品を使用中に発生した接続機器のデータやプログラムの消失についての保証はいたしかねます。
•定期的にバックアップを取るなどの対策をあらかじめ行ってください。
•本製品の内部に入れたりする場合には、ペンジンやシンナーなどの揮発性有機溶剤が含まれているものは使用しないでください。
•塗装を痛めたり、故障の原因となる場合があります。必ず電源を抜いた上で乾いた柔らかい布で取拭きしてください。
•本製品は医療機器、原子力設備や機器、航空宇宙機器、輸送設備や機器などの人命に関わる設備や機器、及び高度な信頼性を必要とする設備や機器やシステムなどへの組み込みや使用は意図されておりませんこれらの用途に本製品を使用され、人身事故・社会的障害などが生じても弊社はいかなる責任も負いかねます。
•本製品を長期間使用しない場合は、USBポートより外してください。
•本紙の内容に関しては万全を期して作成していますが、万一ご不審な点や誤り、記載漏れなどがありましたら、お買い求めになった販売店までご連絡ください

連邦通信委員会規約 (FCC):

本装置は、FCC規則のパート15に準拠しています。運転は以下の2つの条件を満たすことが条件となります。
(1)本装置は有害な干渉を起こさないこと。
(2)本装置は、望ましくない動作を引き起こす可能性のある干渉を含め、受信した干渉を受け入れなければなりません。
警告: コンプライアンスの責任者によって明示的に承認されていない変更や変更は、装置を操作するユーザーの権限を無効にする可能性があります。

注意:この機器はテスト済みであり、FCC規則のパート15に準拠したクラスBデジタルデバイスの制限に準拠していることが確認されています。これらの制限値は、住宅設備における有害な干渉からの合理的な保護を提供するように設計されています。この機器は、使用用途を発生させ、無線周波数エネルギーを放射する可能性があり、指示に従って設置・使用しない場合、無線通信に有害な干渉を引き起こす可能性があります。ただし、特定の設置で干渉が発生しないことを保証するものではありません。この機器がラジオやテレビの受信に有害な干渉を引き起こす場合、機器の電源をオフにしたり、オンにしたりして判断することができますが、ユーザーは、以下のいずれかの方法で干渉を修正することを試みることをお勧めします。
受信アンテナの向きを変えたり、位置を変えたりしてください。
装置と受信機の分離を高める。
受信機が接続されている回路とは異なる回路のコンセントに機器を接続してください。
販売店または経験豊富なラジオ/テレビ技術者にご相談ください。

FCC放射線暴露に関する声明。

この装置は、制限されていない環境のために定められたFCCの放射線被曝限度に適合しています。この機器は、ラジエーターと体の間に20cm以上の距離を置いて設置・操作してください。