LEYU SMART

F600 instructions
F600 说明书



+ LEYU SMART - F600

To connect the device, follow step 1.

若要连接设备，请按照步骤1操作。



1

Connecting devices

Install F600 in the head-set box, open the headset box, then go to Bluetooth settings and select F600.

连接设备

将F600装在耳机盒中，打开耳机盒，然后前往“蓝牙”设置并选取F600。



Click play pause.

按一下播放暂停。

Press the left ear twice to decrease the volume,
Press the right ear twice to increase the volume.

按左耳两下减少音量，
按右耳两下增加音量。

Press the left ear three times to jump to the next song,
Press the right ear three times to jump to the previous song.

按左耳三下跳到下一首，
按右耳三下跳到上一首。

Long press for 2 seconds to enter the voice assistant.

长按2秒进入语音助手。



Headset charging.

F600 needs to be charged in the headphone box, which uses the type-C connector to charge.

耳机充电。

F600需要在耳机盒中充电，耳机盒使用TYPE-C接头充电。

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.