正面

mini智能开关
说明书

mini智能开关

① 断电



⚠

设备安装、故障维修请由专业资质电工操作，以免发生触电危险！设备在正常使用的情况下不可触碰到。

② 接线



S1/S2接或不接机械开关两端(不支持自动回弹的机械开关)。设备都可以正常使用。为确保安全，不要接入零火线等强电。

③ 下载APP

涂鸦智能

Download on the App Store

GET IT ON Google Play

④ 上电和配网

上电，

如果为蜂鸣器款：听到蜂鸣器鸣叫，三分钟内可打开“智能生活”进行APP

如果为指示灯款：指示灯闪烁。

如果上电未听到蜂鸣器鸣叫，或者未见到指示灯闪烁。可通过以下方式进入配网状态：

1)：长按机身按键5秒，

2)：切换机械开关(如果连接)

3)：整机上下电六次，

直到听到蜂鸣器鸣叫或者指示灯闪烁。

⑤ 添加设备

点击“+”，根据app提示操作。

输入	交流 100-240V 50/60Hz
输出	交流 100-240V 50/60Hz
最大电流	10A/16A
LED 负载最大功率	150W
WiFi	IEEE 802.11 b/g/n
防火等级	V-0
APP	智能生活

MADE IN CHINA

反面

DIY MINI Smart Switch

Quick Installation Guide V 1.0

Wi-Fi DIY Smart Switch

① Power off



⚠

To avoid electric shocks, please consult the dealer or a qualified professional for help when installing and repairing! Please do not touch the switch during use.

② Wiring instruction

Make sure the neutral wire and live wire connection is correct



S1/S2 can connect with the rocker light switch (the self-return rocker light switch is not supported) or doesn't connect. To ensure safety, do not connect the neutral wire and live wire to it.

③ Download the APP

Smart life

Download on the App Store

GET IT ON Google Play

④ Power on and Pairing

Power on,

If Buzzer : the Buzzer will be make "DI~DI~DI~" sound,Then open "Smart life" to Pairing.

If LED:The LED will be light flashing.

IF don't have the "DI~DI~DI~" Sound,or the led don't light flashing,

you can:

A): Long press the manual bottonfor 5s,

B): Open and close rocker switch six times (if connect) ,

C): turn on and off the power six times until the Buzzer make "DI~DI~DI~" sound,or the led light flashing.

⑤ Add the device

Tap"+" to operate following the prompt on the APP.

Input	AC 100-240V 50/60Hz
Output	AC 100-240V 50/60Hz
Maximum current	10A/16A
For LED	Max 150W
WiFi	IEEE 802.11 b/g/n
Material	PC V-0
APP	Smart Life

MADE IN CHINA

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any inte rference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.