VIVITAR®

WIRELESS SPEAKER WATCH

ITEM ES64-BS-TA
USER'S MANUAL

Thank you for purchasing the Wireless Speaker Watch, item ES64-BS-TA. Carry with convenience on the go. Please read this manual before using your wireless speaker watch.

A Quick Look



Charging

Directions

Open the silicone tab to access the charging port.

Insert one end of the included charging cable into the charging port.

Insert the other end into a suitable USB charging adapter (not included).



Bluetooth Pairing

Directions

After your watch is charged, press and hold the power button to turn ON or OFF your watch.

Once powered ON your watch will enter Bluetooth pairing mode. Go to the Bluetooth settings menu on you phone. Make sure that Bluetooth is turned on. Connect to the device listed as 'Wireless Speaker'.



Controls

Taking Calls

Press the ⏻ button to answer an incoming call. Press again to hang up.

Press the ⏻ button twice to reject an incoming call

TWS Pairing

Use the TWS pairing function to connect with compatible devices and play music in sync.

To enter TWS mode press the ⏻ button three times.

You can then go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as 'Wireless Speaker'.

Listening to Music

Use your phone to control your speaker's volume or play or pause music.

ITEM ES64-BS-TA
USER'S MANUAL

WIRELESS SPEAKER WATCH

VIVITAR®

Contents

-Wireless Speaker Watch
-USB-C Power Cable
-User's Manual

Specifications

-Bluetooth Version: 5.3
-Power Output: 0.32dBm
-Battery: 300mah rechargeable battery
-Play Time: 2-5 hours
-Charge Time: 2 hours

Features

-Bluetooth Compatible
-Built-in Rechargeable Battery
-Lightweight and Portable

Safety Precautions

When using your Wireless Speaker Watch, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR WIRELESS SPEAKER WATCH.
2. Do not submerge your watch in water.
3. Only clean using a clean cloth.
4. Do not allow children or the lame to play with this product without adult supervision.
5. Do not expose this product to excessive heat or fire.
6. Do not expose this product to extreme temperatures. Keep out of direct sunlight.
7. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service.
8. Do not drop, crush, or expose this product to excessive physical force.
9. This product is not intended for commercial use.
10. When charging, keep all charging cables well ventilated. Do not keep your charging cable in contact with flammable materials such as bedding, linens or synthetic fabrics.
11. Please recycle or dispose of the product properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of the product for further information.

Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call 1-800-592-9541 or visit our website at www.vivitar.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

FCC Statement

VIVITAR®

© 2024 Sakar International
195 Carter Drive,
Edison, NJ 08817
Support: 800 592 9541
www.vivitar.com

⚠ **CAUTION**

BATTERY WARNING:
-The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
-Do not dispose of in fire or expose to excessive heat.
-Do not crush, puncture, incinerate, or short circuit external contacts.
-Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.