MLP-EC10
心情系列真无线入耳式耳机
使用说明书

包装清单

产品示意图

产品参数

蓝牙版本：V5.3
传输距离：>10米
喇叭直径：ø8mm
喇叭阻抗：32Ω±15%
喇叭灵敏度：100 ± 4dB
频响范围：20Hz - 20kHz
播放时间：≈ 4 小时
电池容量（耳机）：50mAh/3.7V
充电时间（耳机）：≈ 1.5 小时
额定输入(耳机)：5V ⎓ 30mA
电池容量(充电盒)：500mAh/3.7V
充电时间（充电盒）：≈ 2h
额定输入（充电盒）：5V ⎓ 220mA

充电指南

1. Type-C USB 充电线，连接充电盒与 5V/1A 输出的 USB电源接口连接。
2. 若耳机放在充电盒内，给充电盒充电的同时也能为耳机充电。

耳机充电：红灯长亮，满电灯灭
充电盒充电：红灯闪，满电灯灯长亮
充电盒给耳机充电：亮蓝灯，耳机满电灯灭
充电盒灯光：电压低于5.4V（间隔5分钟显示一次），红灯慢闪。
提示音：嘟嘟

额定输入：5V ⎓ 50mA（耳机）

额定输入：5V ⎓ 220mA（充电盒）

温馨提示

1、请说明书有特殊标示的操作方式以外，请自尝试拆卸或更换产品内的任何零件。
2、请勿将产品置入水或其他任何液体中，此产品非防水设计。
3、如果有任何液体不小心进入产品内时，请立即断开连接并移开此产品。
4、为避免触电，请在安装或卸载产品时，确保手上没有这些。
5、请勿将此产品放置于热源附近或直接暴露在火源附近。
6、请勿将本产品放置在有强大电磁力的环境中，否则会导致产品故障。

操作说明

①开机
长按4秒钟或从充电盒取出耳机
②关机
长按4秒钟或把耳机放入充电盒
(电压低于3.2V后耳机无法连接或手机断开蓝牙3分钟)
③蓝牙配对与连接
1.请将蓝牙耳机和手机（或其他功能正常接设备）的距离在1米的范围内。
2.开机后自动进入后半蓝牙耳机配对状态，左右耳自动连接，连接成功后，主耳进入配对状态（红蓝灯交替闪烁）；副耳进入联机状态：耳机互配不需要连接，单耳或双耳电仓配出，与蓝牙设备配对有提示音。
3.开启用户手机蓝牙功能（或其他蓝牙设备）并进行搜索或扫描，此时手机会搜索到附近所有的蓝牙设备，点选搜索到的"MLP-EC10"，即可连接。

连接设备成功：MLP-EC10

灯光与提示音

模式	灯光状态	提示音
开机	红蓝灯交替闪	开机
关机	红灯闪三下	关机
配对连接	主机红蓝灯交替闪副机蓝灯慢闪	配对中
配对成功	蓝灯闪	连接成功
中英文切换	主机红蓝灯交替闪副机蓝灯慢闪	English/中文
配对成功	蓝灯闪	连接成功
蓝牙断开	红蓝灯交替闪	连接断开
出距离断开自动回连	蓝灯闪	连接成功

功能键操作

■ 语音助手

语音助手: 长按左/右耳功能键2秒
听到提示音

■ 普通模式

上一曲: 双击左耳功能键
下一曲: 双击右耳功能键
播放/暂停: 单击左右任意耳机功能键

■ 通话模式

接听: 单击左右任意耳机功能键
挂断: 单击左右任意耳机功能键
拒接电话: 长按左右任意耳机功能键2秒

产品中有害物质名称及含量

部件名称	有害物质				
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(CrVI)	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T11364的规定编制
○:表示该有害物质在该部件所有均质材料中的含量在在GB/T26572规定的限量要求以下。
×:表示该有害物质至少在该部件的某一均质材料中的含量超出GB26572规定的限量要求。
通用单位"1"定义部件,其定义详见技术发展水平限制而无法实现有害物质的替代。

本表格依据SJ/T11364的规定编制
印刷电路组件"包括印刷电路及其零部件,电子元器件等。
根据产品型号不同,您所购买的产品可能不会含有以上所有部件

按不法令和补充毫有害物质法令有关十限量值，字母 "e" 代表表示电子电子(electronic)电子(electric)此即环境(environment)的首字母；环境的缩写长表示可回收利用。

保修声明

免责声明
本产品使用手册涉及有关可能的用途，公共表达或其他信息，本使用手册所提供的产品，其维护及使用的条件，内容在该情况下的适用，即不作担保。

保修声明
感谢您对我们的产品做出了保证，我们产品在在保证期之日起十二(12)个月(“保修期”)内，若正常使用情况下因质量缺陷发生损坏，被修理的，维修原理，相厂家确认无法修理的，免费更换，修理或更换后的产品，在剩余保修期（最短不少于30天）内继续享有保证，反正以剩余更换日期为准，如无法确定购买日，则保修期自产品生产日期起始十三（13）个月计算。
如申请保修，请先检查产品是否热插，并按照说明书的方式执行，申请保修时，您需要提供产品的购买证明或保修卡和原始包装盒，以上缺少不满足条件了的情况：
1.超过三包有效期。
2.由改装修长，产品编码与产品条码不符。
3.因误用，滥用或不适当的运输，使用，维护或管理作用引的损坏或损坏。
4.因不可抗力（如地震，战争，火灾等）或意外导致的损坏或损坏。
5.因油，腐蚀或受污染导致的。
6.因承载过重造成的损坏或变形。
7.因未经授权的维修或改造导致的。
8.有用或非有用造成的产品。
9.因酸性或碱性或腐蚀造成。
10.产品正常使用过程中发生的磨损，脱色，磨损，破裂和其他损耗。
11.如产品需要有标识被更改或更换，本保证将失效。
产品及随附物件的外观以和实际不属于保证范围，您应在确定产品符合您的要求后方对随附物件不予接受的保证。
以上保证是我们厂产品做出的全部保证，且仅在中国大陆地区适用与适用。本文件的任何内容均不表明或暗示保证不能按照实际制作消费者权利。
服务监督热线:400-865-8808

Packing list

Product diagram

Product specifications

Bt version : V5.3
Transmission distance : >10m
Speaker diameter : ø8mm
Speaker Impedance : 32Ω±15%
Speaker sensitivity : 100 ± 4dB
Frequency Response : 20hz - 20khz
playback time : ≈ 4 (hours)
Battery Capacity(Headset) : 50mAh/3.7V
Charging time(Headset) : ≈ 1.5 (hours)
Rated Input (Headset) : 5V ⎓ 30mA
Battery capacity (Charging Case) : 500mAh/3.7V
Charging time (Charging Case) : ≈ 2 hours
Rated input (Charging Case) : 5V ⎓ 200mA

Charging Guide

1. Type-C USB charging cable, connect the charging case to the USB power interface for 5V/1A output.
2.If the Headset are placed in the charging case, charging the charging case can also charge the Headset.

Headset charging: The red light stays on and the full charge light goes off
Charging case: The red light flashes, and the red light remains on when fully charged
Charging the Headset with a charging case: the blue light is on, and the Headset are fully charged and the light is off
Low battery state: The voltage is below 5.4V (prompted every 30 seconds), and the red light flashes slowly, Prompt sound: beep

Rated input (Charging Case) : 5V ⎓ 200mA

Rated Input (Headset) : 5V ⎓ 30mA

Tips

1. Do not attempt to disassemble or replace any parts of the product except for those operations specifically indicated in the instruction manual.
2. Do not put the product into water or any other liquid, this product is not designed to be waterproof.
3. If any liquid accidentally enters the product, disconnect and remove the product immediately.
4. To avoid electric shock, make sure there is no water on your hands when installing or uninstalling the product.
5. Do not place this product near a heat source or expose it directly to a source of ignition.
6. Do not place this product in an environment with strong electromagnetic forces, as this may cause the product to malfunction.

Product operation instructions

① Power on
Long press for 4 seconds or remove the Headset from the charging case to power on
Long press for 6 seconds or place the Headset in the charging case(if the voltage is below 5.2V, immediately shut down)no connection or disconnect Bt from the phone for 5 minutes)
② Bt pairing and connection
1. Please keep the distance between the Bt Headset and the phone (or other Bt connected devices) within a range of 1 meter.
2. After turning on, it automatically enters the pairing state on the left earbud, and the right earbud is in the pairing state and connecting. After successful connection, the main ear will enter the pairing state (red and blue lights flashing alternately), and the auxiliary ear will enter the online state; the earphones do not need to be paired with a prompt sound. When the single or double ear battery is removed, there will be a prompt sound when pairing with the blue ear device.
3. Turn on the user's mobile Bt function (or other Bt devices) and perform a search or scan.
At this time, your phone will search for all nearby Bt devices.
Click on the found "MLP-EC10" to connect.

Connection succeeded:MLP-EC10

Lights and warning sounds

Mode	Light status	Prompt sound
Power on	Red and blue lights flashing alternately	Power on
Power off	The red light flashes three times	Power off
Paired Connection	The red and blue lights of the main unit flash alternately, and the blue lights of the auxiliary unit flash slowly	Pairing
Paired successful	Blue light flashing	Connection successful
Switching between Chinese and English	The red and blue lights of the main unit flash alternately, and the blue lights of the auxiliary unit flash slowly	English/ Chinese
Paired successful	Blue light flashing	Connection successful
Bt disconnected	Red and blue lights flashing alternately	Connection disconnected
Remote disconnection and automatic reconnection	Blue light flashing	Connection successful

Function key operation

■ Voice Assistant

Voice Assistant: Long press the left/right ear function keys for 2 seconds
Release your hand upon hearing a beep

■ Normal mode

Last song:Double click the left ear function key
Next song:Double click the right ear function key
Play/Pause: Click on any earphone function key on the left and right sides

■ Call mode

Answer: Click on any earphone function key on the left and right sides
Hang up: Click on any earphone function key on the left and right sides
Reject call: Long press any earphone function key on the left and right for 2 seconds

Names And Contents Of Hazardous Substances In Products

Part Names	Harmful Substances					
	Pb	Hg	Cd	CrVI	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.
○:indicates that the content of the hazardous substance in all homogeneous materials of the part is in the limit required by GB/T 26572.
×:indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572.
The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components
including printed circuit boards and their parts;electronic components, etc.and Small structural parts such as the shell.refers to the exclude you purchased this product.Contain all the components

Refers to not containing 6 toxic and harmful substances or containing but less than the limit value, with the letter "e" representing the English letter "electronic", The first letters of electronic and environmental.
The curved arrows surrounding indicate recyclability.

Warranty Statement

Disclaimer
This user manual does not have any form of guarantee,position expression or other implication The mentioned products,specifications and information are for reference only,and the content will also be updated on the web at any time without additional separate notice

Warranty statement
The warranty attached to this document is guaranteed as follows:If the product is twelve (12) months from the date of purchase("Warranty Period")under normal conditions of use due to quality defects damaged,can be repaired.Free maintenance,repair or replacement of damaged products within the warranty period, repaired or replaced product,Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days).Purchased by sale date,if the sale date cannot be determined,the warranty period shall be 13 (13) months.
If you apply for a warranty,please call the product service hotline first and provide the product purchase certificate and warranty card.Customers also need to provide an accurate,complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1.Exceeding the validity period of the three packs
2.Altering the warranty card and product code does not match the product body.
3.Causes caused by misuse,abuse or improper transportation,use,maintenance or storage,obstacles or damage.
4.Due to force majeure or force majeure (such as earthquake,war,disaster,etc.) or accident loss.
5.The zipper and lower bundle are damaged due to excessive force;
6.Unauthorized repair or modification of the product.
7.Any damage caused by sharp objects.
8.Products with signs of burning of flooding.
9.Products subject to acid,alkali,corrosion or pollution.
10.Aging,discoloration,abrasion,rupture and other losses that occur during the normal use of the product.
11.If the product identification label of the product is changed or damaged,this guarantee will become invalid.

Warranty Statement

The completeness and appearance of the product and accompanying materials are subject to the actual product.Customers You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products,and are only applicable in mainland China.Nothing in this document affects consumer rights that cannot be excluded or restricted under the law.prohibit.

E-mail : service@kesion.com

MLP-EC10
Moods Wireless BT Headset
instruction manual

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.