TF-T28 Pro说明书 成品尺寸73X93mm 128克铜版纸 覆哑膜 双面印刷 钢琴折

虚线做
易撕线

正面

背面

TRANSFORMERS

TF-T28 Pro真无线蓝牙耳机

使用说明书

包装清单

耳机 x2	充电仓 x1
耳帽 x6 (S M L)	Type-C充电线 x1
说明书与保修卡 x1	

温馨提示

1. 除说明书有特殊标示的操作方式以外，请勿尝试拆卸或更换产品的任何零件。
2. 请勿将产品放入水或其他任何液体中，此产品非防水设计。
3. 如果有任何液体不小心进入产品内时，请立即拆开连接并晾开此产品。
4. 为避免触电，请在安装或拆解产品时，确保手上没有达水。
5. 请勿将此产品放置于热源附近或直接暴露在火源附近。
6. 请勿将此产品放置在有强大电磁力的环境中，否则会导致产品故障。

产品规格

耳机规格
蓝牙版本：V5.4
传输距离：≥10m
喇叭类型：Φ13mm 32Ω
频率响应：20Hz-20KHz
电池容量：3.7V / 35mAh
额定输入：5V⎓30mA
充电时间：≤1.5小时
播放音乐时间：≤6小时

充电仓规格
电池容量：3.7V / 300mAh
额定输入：5V⎓250mA
充电时间：≤2小时
（所有技术信息以实际性能为准）

产品示意图

① 出音孔
② 通话麦克风
③ 通话麦克风 / 耳机自拍灯
④ 触摸键
⑤ 充电触点
⑥ 数量
⑦ 复位键
⑧ Type-C充电接口

产品操作说明

1. 开机
方法一：充电仓上盖打开，耳机自动开机。
方法二：长按3秒左 / 右耳机触摸键，耳机开机。
2. 关机
方法一：耳机放回充电仓，合上上盖，耳机自动关机。
方法二：耳机无连接或断开连接超过3分钟，耳机自动关机。
低电压警告自动关机功能：当电池电压低于3.4V时，耳机会发出语音提示音，此时应该及时给耳机充电。当电池电压低于3.2V时，耳机将会自动关机。
3. TWS配对
方法一：耳机开机后，左右耳机自动互连（左右耳机出现不互连时，恢复出厂设置后放回充电仓，再打开时会自动互连）。
方法二：耳机在充电仓内且上盖打开，长按10秒复位键，数量闪烁5次。
4. 蓝牙配对
耳机开机后，开启智能设备的蓝牙列表，搜索"TF-T28 Pro"并点击连接，连接成功后提示音响起。
5. 音量
调低音量：单击左耳机触摸键，最小音量时有提示音。
调高音量：单击右耳机触摸键，最大音量时有提示音。
6. 音乐
播放 / 暂停音乐：双击左 / 右耳机触摸键。
上一曲：三击左耳机触摸键。
下一曲：三击右耳机触摸键。
7. 通话
接听 / 挂断电话：单击时，双击左 / 右耳机触摸键。
拒接电话：单击时，长按2秒左 / 右耳机触摸键。
8. 切换模式（开机默认普通模式）
普通 / 降噪 / 通透模式：长按2秒左耳机触摸键。
游戏 / 音乐模式：长按2秒右耳机触摸键。

恢复出厂设置

● 方法一：耳机开机但未连接蓝牙状态下，左击左 / 右耳机触摸键，灯灯长亮1秒后熄灭，耳机关机。
● 方法二：耳机开机但已连接蓝牙状态下，左击左 / 右耳机触摸键，然后马上长按10秒左 / 右耳机触摸键，灯灯长亮1秒后熄灭，耳机关机。
● 方法三：耳机在充电仓内且上盖打开，长按5秒复位键，数量闪烁3次。

LED指示灯状态

耳机	语音提示音	灯音
耳机	"Power on"	蓝灯长亮1秒后熄灭
关机 / 连接配对	"Power off"	红灯长亮1秒后熄灭
TWS配对	"Dong"	红蓝灯交替闪烁
蓝牙配对	"Paring"	主耳红蓝灯交替闪烁，副耳灯光熄灭
连接成功	"Connected"	灯光熄灭
断开连接	"Disconnected"	主耳红蓝灯交替闪烁，副耳灯光熄灭
低电提醒	"Battery low"	红灯快闪
充电状态	——	红灯长亮
充电完成	——	红灯熄灭

充电仓	数量
给耳机充电	数量显示以耳机，10秒后熄灭
给耳机充电完成	数量熄灭
低电报警	数量每0.5秒闪烁1次
充电状态	数量显示当前电量，个位数字闪烁速度
充电完成	数量显示100%电量

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 Pb	汞 Hg	镉 Cd	六价铬 CrVI6	多溴联苯 PBB	多溴二苯醚 PBDE
印刷电路板组件	○	○	○	○	○	○
外壳等小部构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。
注：
(1) 表中标记"－"的部件，因固定螺丝术足属水平原制而无法实现有害物质的替代。
(2) 印刷电路板组件 包括印刷电路板及其零部件，电子元器件等。
(3) 根据产品型号不同，您所购买的产品可能不会含有以上所有部件。

在中华人民共和国境内销售的电子电气产品必须标识此标志。
标志内的数字代表自正常使用状态下的产品的环保使用期限。

CE FC UK CA RoHS

保修声明

免责声明：
本使用手册没有任何形式的担保，立场表达或其他暗示。本使用手册所提到的产品，规格及信息仅供参考，内容会因时更新于调整，恕不另行通知。

保修声明：
凭本文件附随的产品能加下保证：如产品在您购买日起十二（12）个月（"保修期"）内，在正常使用情况下因重现概发生损坏，敝保证，免费修理，经厂家确认无法修理的，免费更换；修理或更换后的产品，在剩余保修期（最短不少于30天）内继续享有保修，购买日以销售发票日期为准。如无法确定购买日，则保修期自产品生产日期起推十三（13）个月计算。如申请保修，请在联络产品服务热线，并按指引提示的方式执行。申请保修时，您需要提供发票、完整和清晰填写的有效销售发票。

以上保证不适用于下列情况：
1. 超过三包有效期的；
2. 涂改保修卡，产品编码与产品本体不符；
3. 因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏；
4. 因不可抗力（如地震、战争、火灾等）造成的导致的故障或损坏；
5. 拉链、按扣因受力过大而损坏；
6. 因非敝公司原因或的故障或损害；
7. 任何因父母物体造成的损坏；
8. 有违规或未满足条件产品；
9. 因福自然改导致的损坏；
10. 产品正常使用过程中发生的老化、脱色、磨损、镀裂和其他损耗；
11. 如产品原有标识标签被更改或损毁，本保证将失效。

产品及随附物料的齐备和外观完好不属于保证范围。但应在接收产品时当场检验并对任何不符提出异议。

以上保证是我们就产品做出的全部保证，且仅在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利。

服务监督热线：400-885-8808

保修卡

尊敬的用户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用！

用户信息			
用户姓名		电子邮件	
联系电话		邮政编码	
通讯地址			
产品信息			
产品名称		产品型号	
产品条码 / 编号 / 批号			

销售商信息			
名　称			
地　址			
联系电话		邮政编码	
销售日期		发票号码	
备　注			

合格证
产品型号：
生产日期：
检 验 员：

Warranty card

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User information			
User name		Email	
Contact number		Postal code	
Mailing address			
Product information			
Product name		Product number	
Product barcode / serial number / batch number			

Vendor information			
Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

Certificate Of Approval
Product number: _____
Production time: _____
QC: _____

TRANSFORMERS

TF-T28 Pro true wireless BT earphones

Instruction manual

Packing list

Earphones x2	Charging case x1	
Ear cap x6 (S M L)	Type-C charging cable x1	
Instructions and warranty card x1		

Tips

1. Except for the operation methods specifically marked in the manual, do not try to disassemble or replace any parts in the product.
2. Do not put the product in the water or any others liquid, the product is not waterproof.
3. If any liquid accidentally enters the product, please disconnect and remove the product immediately.
4. To avoid electric shock, please make sure that there is no water on your hands when installing or uninstalling the product.
5. Do not put the product near a heat source or directly expose it to a fire source.
6. Do not put the product in an environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product specifications

Earphones specifications
BT version: V5.4
Transmission distance: ≥10m
Speaker type: Φ13mm 32Ω
Frequency response: 20Hz-20KHz
Battery capacity: 3.7V / 35mAh
Rated input: 5V⎓30mA
Charging time: ≤1.5 hours
Play music time: ≤6 hours

Charging case specifications
Battery capacity: 3.7V / 300mAh
Rated input: 5V⎓250mA
Charging time: ≤2 hours
(All technical information is subject to actual performance)

Product diagram

① Sound hole
② Call microphone
③ Call microphone / Earphone indicator light
④ Touch key
⑤ Charging contacts
⑥ Digital display
⑦ Recall key
⑧ Type-C charging interface

Product operation instructions

1. Power on
Method 1: Open the top cover of the charging case, and power on the earphones automatically.
Method 2: Long press the left / right earphone touch key for 3 seconds, and power on the earphones.
2. Power off
Method 1: Put the earphones back into the charging case, close the cover, and the earphones will automatically power off.
Method 2: If the earphones are not connected or disconnected for more than 3 minutes, the earphones will automatically power off.
Low power alarm and automatic shutdown function: When the battery voltage is lower than 3.4V, the earphones will emit a voice prompt, and the earphones should be charged in time. When the battery voltage is lower than 3.2V, the earphones will automatically power off.
3. TWS pairing
Method 1: After the earphones are power on, the left and right earphones will automatically interconnect (When the left and right earphones are not interconnected, they will be put back in the charging compartment after restoring the factory settings, and will be automatically interconnected when they are turned on)
Method 2: The earphones are in the charging case and the top cover is open, long press the Recall key for 10 seconds, and the digital display flashes 5 times.
4. BT pairing
After the earphones are power on, turn on the BT list of smart devices, search for "TF-T28 Pro" and click connect, the earphones will sound after the connection is successful.
5. Volume
Turn down the volume: Click the left earphone touch key, and there will be a prompt tone at the minimum volume.
Turn up the volume: Click the right earphone touch key, and there will be a prompt tone at the maximum volume.
6. Music
Play / pause music: Double-click the left / right earphone touch key.
Previous song: Triple-click the left earphone touch key.
Next song: Triple-click the right earphone touch key.
7. Phone call
Answer / end call: When calling, double-click the left / right earphone touch key.
Reject call: When calling, long press the left / right earphone touch key for 2 seconds.
8. Switch mode (Power-on default ordinary mode)
Ordinary / noise reduction / transparent mode: Long press the left earphone touch key for 2 seconds.
Game / music mode: Long press the right earphone touch key for 2 seconds.

Restore factory settings

● Method 1: When the earphones are power on but not connected to BT, five clicks the left / right earphone touch key. The red light is on for 1 second and then goes out, and the earphones are power off.
● Method 2: When the earphones are power on and connected to BT, five clicks the left / right earphone touch key, and then immediately long press the left / right earphone touch key for 10 seconds. The red light is on for 1 second and then goes out, and the earphones are power off.
● Method 3: The earphones are in the charging case and the top cover is open, long press the Recall key for 5 seconds, and the digital display flashes 3 times.

LED indicator light status

Earphone	Voice prompt	Lamp display
Power on	"Power on"	The blue light is on for 1 second and then goes out
Power off / Clear pairing	"Power off"	The red light is on for 1 second and then goes out
TWS pairing	"Dong"	The red and blue light flash alternately
BT pairing	"Paring"	The red and blue light of the main earphones flash alternately, and the light of the secondary earphones goes out
Connected	"Connected"	The light goes out
Disconnected	"Disconnected"	The red and blue light of the main earphones flash alternately, and the light of the secondary earphones goes out
Low power alarm	"Battery low"	The red light flashes
Charging status	——	The red light is steady on
Charging completed	——	The red light goes out

Charging case	Digital display
Charge the earphones	Digital display shows the effect of running horse lamp, which goes out after 10 seconds
Charging the earphones is complete	Digital display goes out
Low power alarm	Digital display flashes every 0.5 seconds
Charging status	Digital display shows the current power, and the number flashes increment
Charging completed	Digital display shows 100% power

The name and content of harmful substances in the product

Part name	Harmful substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit board components	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with the provisions of SJ/T 11364.
○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements specified in GB/T 26572.
×: Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirements specified in GB/T 26572.
Note:
(1) The parts marked with "－" on the table are unable to achieve the replacement of harmful substances due to limitations in global technological development;
(2) Printed circuit board components: including printed circuit boards and their parts, electronic components, etc;
(3) Depending on the product model, the product you purchased may not contain all of the above components.

Electronic and electrical products sold in the People's Republic of China must mark this logo, the number in the logo represent the environmental protection period of the product under normal use.

CE FC UK CA RoHS

Warranty statement

Disclaimer:
This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to damage occurred in the Warranty Period, the product can be repaired or replaced free of charge, confirm that it cannot be repaired, repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). The date of purchase is subject to the date of the sales invoice, if the date of purchase cannot be determined, the warranty period shall be thirteen (13) months from the date of production. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1. Exceeding the validity period of three guarantees;
2. Altering the warranty card, the product code does not match the product body;
3. Damage or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
5. Zipper and lower buckle are damaged due to excessive force;
6. Disconnection or tearing caused by excessive load;
7. Any damage caused by parents objects;
8. Violations with specifications or conditions of products;
9. Damage caused by self-improvement of Fukuda;
10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product;
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should inspect the product on the spot when you receive it and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in Chinese Mainland. Nothing in this document affects consumer rights that cannot be excluded or restricted by law.

Service supervision hotline: 400-885-8808

虚线做
易撕线

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.