TF-T39说明书 成品尺寸73X93mm 105克铜版纸 双面印刷 钢琴折

TRANSFORMERS

TF-T39 true wireless BT earphones

Instruction manual

Packing list

Earphones x2	Charging case x1
Ear cap x6 (S M L)	Type-C charging cable x1
Instructions and warranty card x1	

Tips

1. Except for the operation methods specifically marked in the manual, do not try to disassemble or replace any parts in the product.
2. Do not put the product in the water or any others liquid, the product is not waterproof.
3. If any liquid accidentally enters the product, please disconnect and remove the product immediately.
4. To avoid electric shock, please make sure that there is no water on your hands when installing or uninstalling the product.
5. Do not put the product near a heat source or directly expose it to a fire source.
6. Do not put the product in an environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product specifications

Earphones specifications

BT version: V5.4

Transmission distance: ≥10m

Speaker type: Φ13mm

Frequency response: 20Hz-20KHz

Battery capacity: 3.7V / 35mAh

Rated input: 5V⎓30mA

Charging time: ≈1.5 hours

Play music time: ≈5 hours

Charging case specifications

Battery capacity: 3.7V / 320mAh

Rated input: 5V⎓300mA

Charging time: ≈1.5 hours

(All technical information is subject to actual performance)

Product diagram

① Sound hole
② Call microphone
③ Earphone indicator light
④ Touch key
⑤ Charging contacts
⑥ Charging case indicator light
⑦ Type-C charging interface



Product operation instructions

1. Power on
   Method 1: When the earphones are power on but not connected to BT, five clicks the left / right earphone touch key. The white light is on for 1 second and then goes out, and the earphones are power off.

   ● Method 2: When the earphones are power on and connected to BT, five clicks the left / right earphone touch key, and then immediately long press the left / right earphone touch key for 10 seconds. The white light is on for 1 second and then goes out, and the earphones are power off.

LED indicator light status

Earphone	Voice prompt	Lamp display
Power on	"Power on".	The white light is on for 1 second and then goes out
Power off / Clear pairing	"Power off"	The white light is on for 1 second and then goes out
TWS pairing	"Dong"	The white light flashes
BT pairing	"Pairing"	The white light of the main earphones flashes, and the white light of the secondary earphones goes out
Connected	"Connected"	The white light goes out
Disconnected	"Disconnected"	The white light of the main earphones flashes, and the white light of the secondary earphones goes out
Low power alarm	"Battery low"	The white light flashes every 5 seconds
Charging status	——	The white light is steady on
Charging completed	——	The white light goes out

Charging case	Lamp display
Charge the earphones	The green light is steady on
Charging the earphones is complete	The green light goes out
Low power alarm	The green light flashes
Charging status	The orange light flashes
Charging completed	The orange light is steady on

Restore factory settings

● Method 1: When the earphones are power on but not connected to BT, five clicks the left / right earphone touch key. The white light is on for 1 second and then goes out, and the earphones are power off.

● Method 2: When the earphones are power on and connected to BT, five clicks the left / right earphone touch key, and then immediately long press the left / right earphone touch key for 10 seconds. The white light is on for 1 second and then goes out, and the earphones are power off.

LED indicator light status

Earphone	Voice prompt	Lamp display
Power on	"Power on".	The white light is on for 1 second and then goes out
Power off / Clear pairing	"Power off"	The white light is on for 1 second and then goes out
TWS pairing	"Dong"	The white light flashes
BT pairing	"Pairing"	The white light of the main earphones flashes, and the white light of the secondary earphones goes out
Connected	"Connected"	The white light goes out
Disconnected	"Disconnected"	The white light of the main earphones flashes, and the white light of the secondary earphones goes out
Low power alarm	"Battery low"	The white light flashes every 5 seconds
Charging status	——	The white light is steady on
Charging completed	——	The white light goes out

Charging case	Lamp display
Charge the earphones	The green light is steady on
Charging the earphones is complete	The green light goes out
Low power alarm	The green light flashes
Charging status	The orange light flashes
Charging completed	The orange light is steady on

The name and content of harmful substances in the product

Part name	Harmful substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit board components	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with the provisions of SJ/T 11364.
○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements specified in GB/T 26572.
×: Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirements specified in GB/T 26572.

Note:
(1) The parts marked with "－" on the table are unable to achieve the replacement of harmful substances due to limitations in global technological development;
(2) Printed circuit board components: including printed circuit boards and their parts, electronic components, etc;
(3) Depending on the product model, the product you purchased may not contain all of the above components.

Electronic and electrical products sold in the People's Republic of China must mark this logo, the number in the logo represent the environmental protection period of the product under normal use.

Warranty statement

Disclaimer:
This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired, free repair; free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). The date of purchase is based on the invoice issued by the seller. If the invoice issued by the seller is lost, the warranty period shall be thirteen (13) months from the date of production. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1. Exceeding the validity period of three guarantees;
2. Altering the warranty card, the product code does not match the product body;
3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
5. Failure or damage caused by abnormal or excessive force;
6. Disconnection or tearing caused by excessive load;
7. Any damage caused by sharp objects;
8. Products with signs of burning or flooding;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product.
If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should inspect the product on the spot when you receive it and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in Chinese Mainland. Nothing in this document affects consumer rights that cannot be excluded or restricted by law.

Service supervision hotline: 400-885-8808

Warranty card

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User information			
User name		Email	
Contact number		Postal code	
Mailing address			
Product information			
Product name		Product number	
Product barcode / serial number / batch number			

Vendor information			
Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

Certificate Of Approval

Product number: _____
Production time: _____
QC: _____

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.