TF-T55 说明书

尺寸：73x85mm 材质：128g铜版纸覆哑膜 风琴折正反印刷

中文

英文

TRANSFORMERS

TF-T55耳挂式蓝牙耳机
使用说明书

包装清单

产品示意图

温馨提示

1. 除说明书特殊标示的操作方式外，请在尝试拆卸或更换产品内的任何零件。
2. 请勿将产品放入水或其他任何液体中，此产品非防水设计。
3. 如果有任何液体不小心进入产品内部，请立即并且最快拆开产品。
4. 为避免触电，请在安装或拆解产品时，确保手上没有灰尘。
5. 请勿将此产品放置于热源附近或高温高湿的环境中，否则会导致产品变形。
6. 请勿将本产品放置在有强大电磁场的环境中，否则会导致产品故障。

产品规格

扬声器尺：V5.4
传输距离：≤10米
音频频率：8Hz-8KHz
单耳尺寸：Φ14.2mm
单耳重量：16G+10%
耳机时间：约1.5小时
电池容量：35mAh/3.7V
额定输入：5V⎓35mA

充电仓规格

电池容量：350mAh/3.7V
充电时间：约1.5小时
额定输入：5V⎓250mA
(所有技术指标以实测数据为准)

给充电仓充电
Type-C充电线接至电池仓的USB源适配器
温馨提示：当耳机充电电量接近低电量(声音提示：battery low，每1分钟响1次)时，请放回耳机充电

LED指示状态

开机	白灯长亮1秒
关机	蓝灯长亮1秒
等待连接	主从白蓝灯交替闪烁，蓝灯快灭
耳机成功连接状态	一段10%电量显示后为：白蓝灯每隔2秒闪
耳机充电	耳机盒灯长亮
耳机充满	耳机盒灯熄灭
低电量(10%左右电量时	蓝灯长亮1秒熄灭

充电仓指示（只做参考，以实物为准）

充电仓充电	充电个位数闪烁显示当前电量
充电仓充满电	充满显示电量百分比，在显示电量低于10%时闪烁提醒
充电仓电量显示	2.当仓内电量小于10%，耳机入仓不充电，只灭灯

产品操作说明

①开机
方法一：取出耳机并佩戴
方法二：长按左/右单只键直至听到，耳机开机提示音：“power on”
②关机
方法一：放回充电盒，耳机自动关机
方法二：耳机在3分钟内未佩戴状态自动关机(未佩戴状态：“power off”)
③配对
步骤一：开机后，左右耳机自动进入配对状态(进入配对状态提示音：“pairing”)
步骤二：打开蓝牙设备搜索界面，搜索“TF-T55”并连接
温馨提示：左右耳机出厂时已配对，请勿重出厂设置，否则可能造成耳机自动配对失败等问题

触摸操作

■ 单耳模式
- 单击一次：单击左耳机触摸键(最小提示音“叮咚”)
- 单击两次：单击右耳机触摸键(最大提示音“叮咚”)

■ 音乐播放模式
- 播放/暂停：双击触摸键
- 上一曲：三击左耳机触摸键
- 下一曲：三击右耳机触摸键

■ 通话模式
- 接听/挂断来电：双击左/右耳机触摸键
- 拒接来电：长按左/右耳机触摸键2秒

■ 游戏模式
- 长按左耳机触摸键2秒启动/关闭语音助手
- 长按右耳机触摸键2秒切换游戏/音乐模式(显示屏“game mode”/“music mode”)

恢复出厂设置

当出厂时未连接过任何设备，当前处于耳机关机状态(请确保耳机连接到充电仓)，
方法②开机连接状态：在耳机关机状态下，3秒内按住5秒，直到耳机开机提示音：“power off”，
耳机自动进入配对状态

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 Pb	汞 Hg	镉 Cd	六价铬 Cr(VI)	多溴联苯 PBB	多溴二苯醚 PBDE
印刷电路板组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在SG/T 26572规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出SG/T 26572规定的限量要求。
注：
1. 表中标记“×”的部件，因现全球技术发展水平限制而无法实现有害物质的替代；
2. 印刷电路板组件：包括印刷电路板及其零部件，电子元器件等；
3. 根据产品型号不同，印有相应部件或可能不存在相应上所有部件。

保修声明

尊敬的客户：
本商品承诺：
在商品正常使用情况下，若因产品质量问题出现故障，请凭保修卡进行保修服务。
本商品自出厂日期起享有两年保修期。
本商品不提供任何形式的担保，立场表达或其他暗示，本商品不提供任何的产品、商品及适合任何目的、内容的合适的更新于完美，型号不同，请确认。
保修条款：
因本文所提供的产品做出了保证，如产品在出厂后已超过一二（12）个月（“保修期”），在这段保修期间内因质量缺陷发生故障，经修理后，免费修理，修厂更换以及维护服务，免费退换，根据质量情况修理产品，在换新保修期（最短不少于30天）内重新享有保修，恢复以出厂日期为准日期内准，因无法确定原因且，新保修期内产品生产日期起算三（13）个月计算。
如申请保修，请先检查产品是否损坏，并按照以下指示进行方式进行。申请保修时，您需要提供发票，完整有效填写的有效保修凭证。

以上情况不属于质量问题：
1. 超出三年有效期限的产品；
2. 因使用不当，产品超出生产品质准不符；
3. 因误用，滥用或不适当的品质，使用，维护或保管等导致的故障或损坏；
4. 因不可抗力（如地震，自然，火灾等）或意外导致的故障或损坏；
5. 松脱，裂开因意外公证天的损坏；
6. 因非授权渠道或者的拆机或维修；
7. 任何因长期维修造成的损坏；
8. 有因因素未遵守使用产品；
9. 因擅自更改零件的损坏；
10. 产品正常使用以及非正常出现者长，潮湿，腐蚀，破裂和其他原因；
11. 因产品所有权证明及提供发票，本保证将无效。

产品质量控制程序的各每种环境因素对于属于保证范围，但因在使用产品时出现特别并对在任何环境因素。

以上保证条款不因产品质量的全部保证，且仅在中国大陆地区境内适用。本文件的任何内容均不表示明确表示或暗示不能因保证期限的消费者权利。

服务咨询热线：400-885-8806

保修卡

尊敬的客户，本保修卡是您将来申请保修的凭证，请您妥善保管并填写并妥善保管备用！

用户信息			
用户姓名		电子邮件	
联系电话		邮政编码	
通讯地址			
产品信息			
产品名称		产品型号	
产品序列/编号/型号			
销售信息			
姓 名			
地 址			
联系电话		邮政编码	
购买日期		发票号码	
备 注			

合格证
产品型号
生产日期
检 验 员

TRANSFORMERS

Warranty Service

Dear sir/Dear warranty card is the proof of your future warranty application, please cooperatewith the sales to fill in and keep it for future use!

User info			
User name		Email	
Contact number		Postal code	
Mailing address			
Product information			
Product name		Product number	
Product barcode / Serial Number / Batch number			

Vendor information			
Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

Certificate of conformity
Product No
Production Time
QC

TRANSFORMERS

TF-T55 Ear Hanging Wireless
Earphone Instructions for use

Packing list

Product diagram

Warm reminders

1. Do not attempt to remove or replace any parts in the product except for the operation method specifically indicated in the instruction manual.
2. Do not immerse the product in water or any other liquids.
This product is not waterproof.
3. If any liquid accidentally enters the product, immediately disconnect and dismantle the product.
4. To avoid electric shock, please make sure that your hands are not stained when installing or uninstalling the product.
5. Do not place the product in a place where the heat source or directly expose it to theFire source.
6. Do not place the product in a strong electromagnetic environment, otherwise it will cause the product to fail.

Product specifications

Version BT: V5.4
Transmission distance: ≤10 minutes
Music time: about 4 hours
Speaker size: Φ14.2mm
Input impedance: 16Ω+15%
Charging time: about 1.5 hours
Battery capacity: 35mAh/3.7V
Rated input: 5V⎓35mA

Specifications of charging compartment

Battery capacity: 350mAh/3.7V
Charging time: about 1.5 hours
Rated input: 5V⎓250mA
(All technical information is subject to actual performance)

For charging the charging compartment
Type-C charging cable connects the charging compartment to the 5V power adapter
Tips: When the headphone battery is low(power reminder
(sound prompt: battery low, once every minute)
Please charge the headphones in time.

LED indicates the status

Start	The white light is on for 1 second
Shut down	The blue light is on for 1 second
Waiting for connection	The white and blue lights in the main ear flash alternately, and the secondary ear goes out
Headphone Low Power Tips	Headphone blue light flash
Headphone charging	The blue light of the headphones is bright
The headphones are fully charged	The blue light of the headphones went out
Close TWS and mobile phone pairing	The blue light is on for 1 second

Charging case instructions

(For reference only, subject to the physical object)

Charging compartment charging	The number of single digits shows the current charge
The charging compartment is fully charged	Digital display shows that the current power is always 100%. The LED light is turned off after removing the earphone
The charging compartment charges the headphones	The digital display often shows the current power, and the headphones are turned off when they are fully charged
Charging compartment power display	Press and hold the power button, the current power of the warehouse is less than 10%, the digital tube will flash, the power of the warehouse is 0%, the headphones will not be charged when entering the warehouse, but only shut down

Product how-to instructions

① Start up
Method 1: Take out the headphones and turn them on
Method 2: Long press the Touch key of the active headset for 3 seconds,and the headphones turn on (Power-on tone: “power on”)
② Shut down
Method 1: Put it back in the charging case, and the headphones will turn off automatically
Method 2: The headphones will automatically shut down if the device is not connected within 3 minutes (power-off prompt: “power off”)
③ Pairing
Step 1: After turning on, the left and right headphones are automatically interconnected and enter the pairing state (pairing prompt: “pairing”)
Step 2: Open the APP of the smart device, search for “TF-T55” and connect
Step 3: Pairing is successful (prompt: “connected”). If the pairing fails, please restore the factory settings, put them back in the charging box and take them out for automatic pairing.

Touch operation

■ General mode
- Volumeintruction: Click the Touch key of theleft headset (minimal prompt tone: “dong-dong”)
- Volume plus: Click the right earphone, Touch key (maximum voice: “dong-dong”)

■ Music playback mode
- Play/Pause: Double-click the left and right Touch keys
- Previous song: Three-click the left headphone Touch key
- Next song: Three-click the right headphone Touch key

■ Call mode
- Answer/hang up the call: double-click the leftright headphone Touch key
- Reject incoming calls: Long press the Touch key of the leftright headphones for 2 seconds

■ Game/Music Mode
- Long press the Touch key of theleft headset for 2 seconds to startoff the voice assistant
- Long press the right headset Touch key for 2 seconds to switch gamemusic mode (game/game mode/music mode”)

Restore factory settings

Method 1: Turn on and not connect, turn off the leftright headset after 5 consecutive times, and the right headset (double) information about pairing and connection
Method 2: When the connection status is 5.2 Turn off the left and right headset when connected, press the pairing information between the headphones and BT device (prompt tone: “power off”)

The name and content of harmful substances in the product

Part name	Harmful substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit board components	○	○	○	○	○	○
Small structural components	○	○	○	○	○	○

This form is compiled in accordance with the provisions of SJ/T 11364.
○: Indicates that the content of the hazardous substance in all homogeneous materials of the parts of the product is below the limit requirements of SJ/T 26572.
×: Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirements specified in SJ/T 26572.
Note 1: The parts marked with “-” on the table are used to achieve the replacement of harmful substances due to limitations in global technological development.
2. Printed circuit board components including printed circuit boards and their parts and electronic components.
3. Depending on the product model,the product you purchased may not contain all of the above components.

Electronic and electrical products sold in the People's Republic of China must meet the labeling requirements of the environmental protection product under normal use environmental protection use period.

TRANSFORMERS

Warranty statement

Disclaimer:
This instruction manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use, the product is damaged due to quality problems, after repair, replacement and maintenance, if the manufacturer confirms that it cannot be repaired, repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). The date of purchase is based on the date of the product's ex-factory. This state of warranty period is not guaranteed. The warranty period is extended to thirteen (13) months from the date of purchase. If you apply for warranty, please call the product's customer hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1. Exceeding the validity period of three guarantees;
2. Product damage due to improper use, product does not match the product body;
3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accident;
5. Shell and lower buckle are damaged due to excessive force;
6. Disassembled or testing caused by excessive force;
7. Any damage caused by sharp objects;
8. Damage caused by the risk of burning or flooding;
9. Damage caused by unauthorized disassembly;
10. Aging, wear, abrasion, abrasion, rupture and other losses that occur during the normal use of the product;
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not guaranteed. The customer should carefully inspect the product on the spot when you receive it and raise objections to any discrepancies.
The above guarantees are all guarantees we make regarding the products, and are only applicable in Chinese Mainland. Nothing in this document affects consumer rights that cannot be excluded or restricted by law.

Service supervision hotline: 400-885-8806

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.