TF-Y02MAX 说明书 成品尺寸80X122mm 105克铜版纸

正面

TRANSFORMERS



TF-Y02 Max桌面蓝牙音箱
使用说明书

包装清单

音箱 *1	3.5mm线*1
Type-C充电线 *1	说明书与保修卡 *1

产品规格

蓝牙版本：V5.4	额定功率：24W
传输距离：≥10米	扬声器尺寸：Φ52mm
产品尺寸：197*110*99mm	频率响应：20HZ-20KHZ
产品重量（裸机）：≈1011g	电池容量：7.4V/2600mAh
灵敏度：85±3dB	播放时长：≈10 小时（60% 音量）
信噪比：≥85dB	充电时长：≈3 小时
待机时间：≈6个月	额定输入：DC5V⎓2A

温馨提示

1.让产品远离极热和极冷的环境，它会损坏电池和电路。
2.避免液体浸入产品中。
3.不要拆卸产品。
4.不要使用浓缩化学产品或洗涤剂来清洁产品。
5.仅使用5V⎓2A电源，连接电源电压过高可能会造成严重损坏。
6.不要随意丢弃或将产品放置在火灾或高温附近，以避免爆炸危险。

按键与功能



①开机键
②音量减/上一曲
③播放 / 暂停键
④音量加/下一曲
⑤M键
⑥灯光键



⑦Type-c充电口
⑧耳机接口
⑨AUX in
⑩TF卡槽
⑪U盘接口

1. 开机键
长按开机键开 / 关机，开机后，音箱没插外接设备状态下直接进入蓝牙搜索配对模式，没连接蓝牙状态下，10分钟内无任何操作，会自动关机

2. M键
●长按M键强制断开当前连接设备并进入搜索配对状态
●短按M键模式切换,所有设备都插上模式切换顺序为USB-TF-BT-AUX

3. 音乐模式
●长按"-"键切换到上一曲，短按"-"键音量减
●长按"+"键切换到下一曲，短按"+"键音量加
●U盘播放：插入U盘自动进入USB模式播放U盘音乐
●TF卡播放：插入TF卡自动进入TF卡模式播放TF卡音乐
●AUX播放：插入AUX线自动进入AUX模式

4.接听电话/回拨功能
短按播放/暂停键接听\挂断电话，长按拒接，双击回拨最后一个去电

5. TWS功能
支持两台音箱TWS配对功能，长按任一台音箱的播放/暂停键进入TWS配对模式，配对成功后长按播放/暂停键断开TWS配对，配对过的两台音箱重新开机会自动配对

6. RGB灯效
●6种灯效模式，单按灯光键
切换灯效模式:流水灯-律动灯-呼吸灯-冰蓝色-粉色-紫色
●长按关闭/开启灯光

故障排除

1. 自动关机：电池电量不足时会自动开启电池保护，请充电4小时后使用
2.无法播放音乐：音乐文件储存路径不能被播放器识别音乐文件用，请储存在可移动设备的根目录下
3.连接电脑无声电脑界面连接错误，请选择正确的音频输出端口
4.按键无反应或功能错乱关机后重试
5.复位：当机器出现异常情况时，长按10秒开机键

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 Pb	汞 Hg	镉 Cd	六价铬 Cr(VI)	多溴联苯 PBB	多溴二苯醚 PBDE
印刷电路板组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。
注：
(1) 表中标记"×"的部件，皆因全球技术发展水平限制而无法实现有害物质的替代；
(2) 印刷电路板组件：包括印刷电路板及其零部件、电子元器件等；
(3) 根据产品型号不同，您所购买的产品可能不会含有以上所有部件。

在中华人民共和国境内销售的电子电气产品必须标识此标志，标志内的数字代表在正常使用状态下的产品的环保使用期限。

保修声明

免责声明：
本使用手册没有任何形式的担保、立场表达或其他暗示。本使用手册所提到的产品、规格及信息仅供参考，内容亦会随时更新于网页，恕不另行通知。

保修声明：
就本文件附随的产品做如下保证：如产品在您购买日起十二（12）个月（"保修期"）内，在正常使用情况下因质量瑕疵发生损坏，能修理的，免费修理；经厂家确认无法修理的，免费更换；修理或更换后的产品，在剩余保修期（最短不少于30天）内继续享有保修。购买日以销售发票日期为准，如无法确定购买日，则保修期自产品生产日期起按十三（13）个月计算。如申请保修，请先致电产品服务热线，并按我们指示的方式执行。申请保修
时，您需要提供准确、完整和清晰填写的有效销售发票。

以上保证不适用于下列情况：
1. 超过三包有效期的；
2. 涂改保修卡，产品编码与产品本体不符；
3. 因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏；
4. 因不可抗力（如地震、战争、火灾等）或意外导致的故障或损坏；
5. 拉链、塔扣因受力过大而损坏；
6. 因承载过重造成的脱线或撕裂；
7. 任何因尖锐物体造成的损坏；
8. 有烧损或水浸迹象的产品；
9. 因擅自拆改导致的损坏；
10. 产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗；
11. 如产品原有标识标签被更改或损毁，本保证将失效。

产品及随附物料的齐备和外观完好不属于保证范围。您应在接收产品时当场检验并对任何不符提出异议。

以上保证是我们就产品做出的全部保证，且仅在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利。

服务监督热线：400-885-8808

TRANSFORMERS

保修卡

尊敬的用户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用！

用户信息			
用户姓名		电子邮件	
联系电话		邮政编码	
通讯地址			
产品信息			
产品名称		产品型号	
产品条码 / 编号 / 批号			

销售商信息			
名　称			
地　址			
联系电话		邮政编码	
销售日期		发票号码	
备　注			

合格证
产品型号：
生产日期：
检 验 员：

反面

Warranty Service

Dear user,this warranty card is the proof of your future warranty application, please cooperatewith the seller to fill it out and keep it for future use!

User info			
User name		Email	
Contact number		Postal code	
Mailing address			
Product information			
Product name		Product number	
Product barcode / Serial number / Batch number			

Vendor information			
Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

Certificate of Approval
Product No:
ProductionTime:
QC:

TRANSFORMERS



TF-Y02 Max Gaming BT Speaker
Instruction Manual

Packing List

Speaker *1	3.5mm cable*1
Type-C charging cable *1	Instruction manual and warranty card *1

Product Specification

Bluetooth version: V5.4	Rated power: 24W
Transmission distance: ≥10 metres	Speaker size: Φ52mm
Product size: 197*110*99mm	Frequency Response: 20HZ-20KHZ
Product weight (bare): ≈1011g	Battery capacity: 7.4V/2600mAh
Sensitivity: 85±3dB	Playback time: ≈10 hours (60% volume)
Signal-to-noise ratio: ≥85dB	Charging time: ≈3 hours
Standby time: ≈6 months	Rated input: DC5V⎓2A

Hint

1. Keep the product away from extreme heat and cold, which can damage the battery and circuitry.
2. Avoid immersion of liquids in the product.
3. Do not disassemble the product.
4. Do not use concentrated chemical products or detergents to clean the product.
5. Use only 5V⎓2A power supply, connecting the power supply with too high voltage may cause serious damage.
6. Do not discard or place the product near fire or high temperature to avoid the risk of explosion.

Keys & Functions



①On button
②Volume down/previous song
③Play/Pause button
④Volume up/next song
⑤M key
⑥Lighting key



⑦Type-c charging port
⑧ Headphone jack
⑨AUX in
⑩TF card slot
⑪U disk interface

1. Switch on button
Long press the power on button to switch on/off, after switching on, the speaker will enter the Bluetooth search and pairing mode directly without plugging in external devices.
mode, without connecting the Bluetooth state, within 10 minutes without any operation, it will be automatically shut down

2. M key
●Long press M key to force disconnect the current connected device and enter the search pairing mode.
●Short press the M key to switch modes, all devices are plugged in the mode switching order is USB-TF-BT-AUX

3. Music Mode
●Long press"-"key to switch to the previous song, short press"-"key to decrease the volume.
●Long press"+"key to switch to the next song, short press"+"key volume up
●U disk playback: Insert the U disk and automatically enter the USB mode to play the music on the U disk.
●TF card playback: insert TF card and automatically enter TF card mode to play TF card music.
●AUX playback: Insert AUX cable to enter AUX mode automatically.

4.Answer call/callback function
Short press play/pause to answer/hang up, long press to reject, double press to call back the last caller.

5. TWS function
Support two speakers TWS pairing function, long press the play/pause button of any one speaker to enter TWS pairing mode.
Long press the play/pause button to disconnect the TWS pairing after successful pairing, the two paired speakers will be paired automatically when they are turned on again.

6. RGB Light Effect
●6 kinds of light effect modes, single press the light button
Switch light effect modes: running light - rhythmic light - breathing light - ice blue - pink - purple
●Long press to turn off/on the light

fault resolution

1. Auto shutdown: battery protection will be automatically turned on when the battery is low, please charge for 4 hours after use.
2. Can not play music: music file storage path can not be recognised by the player music files, please store in the
Please store it in the root directory of the removable device.
3. Connect to the computer no sound computer interface connection error, please select the correct audio output port
4. key unresponsive or function error shut down the machine and try again
5. Reset: when the machine appears abnormal situation, long press the boot button for 10 seconds

The name and content of harmful substances in the product

Part name	Harmful substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit board components	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with the provisions of SJ/T 11364.
○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements specified in GB/T 26572.
×: Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirements specified in GB/T 26572.

Note:The parts marked with "×" on the table are unable to achieve the replacement of harmful
(1) substances due to limitations in global technological development;
Printed circuit board components: including printed circuit boards and their parts,
(2) electronic components, etc;
Depending on the product model, the product you purchased may not contain all of the
(3) above components.

Electronic and electrical products sold in the People's Republic of China must mark this logo, the number in the logo represent the environmental protection period of the product under normal use.

Warranty statement

Disclaimer:
This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired, free repair; free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). The date of purchase is subject to the date of the sales invoice, if the date of purchase cannot be determined, the warranty period shall be thirteen (13) months from the date of production. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1. Exceeding the validity period of three guarantees;
2. Altering the warranty card, the product code does not match the product body;
3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
5. Zipper and tower buckle are damaged due to excessive force;
6. Disconnection or tearing caused by excessive load;
7. Any damage caused by sharp objects;
8. Products with signs of burning or flooding;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product;
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should inspect the product on the spot when you receive it and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in Chinese Mainland. Nothing in this document affects consumer rights that cannot be excluded or restricted by law.

Service supervision hotline: 400-885-8808

TRANSFORMERS

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.