TF-Y07Pro说明书 成品尺寸73X93mm 128克铜版纸 覆哑膜 双面印刷 钢琴折

虚线做
易撕线

正面

背面

TRANSFORMERS

TF-Y07Pro穿戴式蓝牙音箱

使用说明书

包装清单

音箱 x1	Type-C充电线 x1
说明书与保修卡 x1	

产品规格

防护等级：IP67　　照明时间：≥4小时（100%亮度）

蓝牙版本：V5.4

传输距离：≥10m

喇叭类型：Φ33mm 4Ω

喇叭功率：3W

频率响应：80Hz-18KHz

电池容量：3.7V / 600mAh

额定输入：5V⎓450mA

充电时间：≤2小时

播放音乐时间：≥5小时

温馨提示

1. 除说明书有特殊标示的操作方式以外，请勿尝试拆卸或更换产品内的任何零件。
2. 如果有任何液体不小心进入产品内时，请立即断开连接并拆开此产品。
3. 为避免触电，请在安装或卸载产品时，确保手上没有达水。
4. 请勿将此产品放置于热源附近或直接暴露在火源附近。
5. 请勿将此产品放置在有强大电磁力的环境中，否则会导致产品故障。

产品示意图

① 多功能键
② 音量"+"键
③ 音量"-"键
④ 灯效键
⑤ 照明灯
⑥ 指示灯
⑦ 麦克风
⑧ Type-C充电接口
⑨ 磁吸夹

产品操作说明

1. 开 / 关机
   开机：长按2秒多功能键，白灯长亮1秒后熄灭。
   关机：长按4秒多功能键，白灯长亮1秒后熄灭。
   低电量警告自动关机功能：当电池电量低于3.4V时，音箱会发出提示音，此时应该及时给音箱充电。当电池电压低于3.2V时，音箱将会自动关机。
2. 蓝牙配对
   音箱开机后，打开智能设备蓝牙设置，搜索蓝牙名称"TF-Y07Pro"并点击连接，连接成功后提示音会响起，音箱无连接或断开连接超过3分钟，音箱将会自动关机。
3. TWS配对
   任意两台同款音箱开机状态下，三点其中一台音箱的多功能键即可进入TWS配对，15秒内建立TWS连接，连接成功后提示音会响起，三点其中一台音箱的多功能键即可断开TWS配对。
4. 清除配对
   开机状态下，同时长按2秒音量"-"键和音量"+"键，白灯慢闪。
5. 通话
   接听来电：来电时，单击多功能键。
   挂断来电：通话时，单击多功能键。
   拒接来电：来电时，双击多功能键。
   回拨电话：双击多功能键。
6. 音乐
   播放 / 暂停音乐：单击多功能键，音箱无播放超过30分钟，音箱将会自动关机。
   上一曲：长按1秒音量"-"键。
   下一曲：长按1秒音量"+"键。
7. 音量
   调低音量：单击音量"-"键。
   调高音量：单击音量"+"键，最大音量时有提示音。
8. 灯效
   开 / 关照明灯：长按2秒灯效键。
   切换灯效（100%亮度-50%亮度-快闪）：单击灯效键。
9. 指示灯状态
   配对状态：配对时白灯慢闪，连接时白灯长亮，播放音乐时白灯常亮。
   充电状态：充电时红灯长亮，充满电红灯熄灭。

常见问题及解决方案

问题	解决方案
无法开机	检查音箱内置电池是否有电
多次连接配对不成功	关闭音箱重新开机，或清除配对记录
音乐播放出现断音	连接距离是否超出范围，或音箱与手机之间是否有障碍物
播放无声	检查音箱是否处于最低音量
指示灯不亮	检查充电接口是否接好

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 Pb	汞 Hg	镉 Cd	六价铬 CrVI	多溴联苯 PBB	多溴二苯醚 PBDE
印刷电路板组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。

○：表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。

×：表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

注：

(1) 表中标记"–"的部件，意因全球技术发展水平限制而无法实现有害物质的替代；

(2) 印刷电路板组件：包括印刷电路板及其零部件，电子元器件等；

(3) 根据产品型号不同，您所购买的产品可能不会含有以上所有部件。

在中华人民共和国境内销售的电子电气产品必须标识此标志，标志内的数字代表在正常使用状态下的产品的环保使用期限。

保修声明

免责声明：
本使用手册没有任何形式的担保，立场表达或其他暗示。本使用手册所提到的产品，规格及信息仅供参考，内容会做修改恕不预页，恕不另行通知。

保修声明：
就本文件所指的产品做如下保证：如产品在您购买日起十二（12）个月（"保修期"）内，在正常使用情况下因质量瑕疵发生损坏，敬请提的，免费修理；经厂家确认无法修理的，免费更换；修理或更换后的产品，在剩余保修期（最短不少于30天）内继续享有保修。前买日以销售发票日期为准，如无法确定购买日，则保修期自产品生产日期起算十三（13）个月计算。如申请保修，请先查询产品服务热线，并按照引指示的方式执行。申请保修时，您需要提供发确、完整和准确填写的有效销售发票。

以上保证不适用于下列情况：
1. 超过三包有效期的；
2. 油改保修卡，产品编码与产品本体不符；
3. 因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏；
4. 因不可抗力（如地震、战争、火灾等）或意外导致的故障或损坏；
5. 拉链、搭扣或魔力过大而损坏；
6. 因非最日常意义或的规格或商标；
7. 任何因女装物体造成的损坏；
8. 有违规或未按说明书的产品；
9. 因擅自拆改导致的损坏；
10. 产品证明书、保修卡、发票、或编码和其他损耗；
11. 如产品原有标识标签被更改或损毁，本保证将失效。

产品及随附物料的开箱和外观完好不属于保证范围。您应在接收产品时当场检验并对任何不符提出异议。

以上保证是我们就产品做出的全部保证，且仅在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利。

服务监督热线：400-885-8808

保修卡

尊敬的用户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用！

用户信息			
用户姓名		电子邮件	
联系电话		邮政编码	
通讯地址			
产品信息			
产品名称		产品型号	
产品条码 / 编号 / 批号			

销售商信息			
名　称			
地　址			
联系电话		邮政编码	
销售日期		发票号码	
备　注			

合格证

产品型号：
生产日期：
检 验 员：

Warranty card

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User information			
User name		Email	
Contact number		Postal code	
Mailing address			
Product information			
Product name		Product number	
Product barcode / serial number / batch number			
Vendor information			
Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

Certificate Of Approval

Product number: _____
Production time: _____
QC: _____

TRANSFORMERS

TF-Y07Pro wearable BT speaker

Instruction manual

Packing list

Speaker x1	Type-C charging cable x1
Instructions and warranty card x1	

Product specifications

Ingress protection: IP67
BT version: V5.4
Transmission distance: ≥10m
Speaker type: Φ33mm 4Ω
Speaker power: 3W
Frequency response: 80Hz-18KHz
Battery capacity: 3.7V / 600mAh
Rated input: 5V⎓450mA
Charging time: <2 hours
Play music time: >5 hours
Lighting time: >4 hours (100% brightness)

Tips

1. Except for the operation methods specifically marked in the manual, do not try to disassemble or replace any parts in the product.
2. If any liquid accidentally enters the product, please disconnect and remove the product immediately.
3. To avoid electric shock, please make sure that there is no water on your hands when installing or uninstalling the product.
4. Do not put the product near a heat source or directly expose it to a fire source.
5. Do not put the product in an environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product diagram

① Multi-function key
② Volume "+" key
③ Volume "-" key
④ Light effect key
⑤ Light
⑥ Indicator light
⑦ Microphone
⑧ Type-C charging interface
⑨ Magnetic clip

Product operation instructions

1. Power on / off
   Power on: Long press the multi-function key for 2 seconds, the white light is on for 1 second and then goes out.
   Power off: Press the multi-function key for 4 seconds, the white light is on for 1 second and then goes out.
   Low power alarm and automatic shutdown function: When the battery voltage is lower than 3.4V, the speaker will make a prompt sound, and the speaker should be charged in time. When the battery voltage is lower than 3.2V, the speaker will automatically power off.
2. BT pairing
   After the speaker is power on, open the BT settings of the smart device, search for the BT name "TF-Y07Pro" and click connect, the prompt sound will sound after the connection is successful. If the speaker is not connected or disconnected for more than 3 minutes, the speaker will automatically power off.
3. TWS pairing
   When any two speakers of the same model are powered on, triple-click the multi-function key of one of the speakers to enter TWS pairing, and establish a TWS connection within 15 seconds, the prompt sound will sound after the connection is successful. Triple-click the multi-function key of one of the speakers to disconnect the TWS pairing.
4. Clear the pairing
   In the power-on state, long press the volume "-" key and the volume "+" key for 2 seconds at the same time, and the white light flashes slowly.
5. Call
   Answer call: When calling, click the multi-function key.
   End call: When talking, click the multi-function key.
   Reject call: When calling, double-click the multi-function key.
   Call back: Double-click the multi-function key.
6. Music
   Play / pause music: Click the multi-function key. If the speaker does not play for more than 30 minutes, the speaker will automatically power off.
   Previous song: Long press the volume "-" key for 1 second.
   Next song: Long press the volume "+" key for 1 second.
7. Volume
   Turn down the volume: Click the volume "-" key.
   Turn up the volume: Click the volume "+" key, and there will be a prompt sound at the maximum volume.
8. Light effect
   Turn on / off the light: Long press the light effect key for 2 seconds.
   Switch the light effect (100% brightness-50% brightness-flash): Click the light effect key.
9. Indicator light status
   Pairing status: The white light flashes slowly when pairing, the white light stays on when connected, and the white light goes out when playing music.
   Charging status: The red light stays on when charging, and the red light goes out when fully charged.

Common problems and solutions

Problems	Solutions
Unable to power on	Check whether the built-in battery of the speaker is charged
Connection pairing failed many times	Power off the speaker and restart it, or clear the pairing record
The music plays staccato	Whether the connection distance is out of range, or whether there is an obstacle between the speaker and the phone
Play without sound	Check whether the speaker is at its lowest volume
The indicator light is not on	Check whether the charging interface is plugged in

The name and content of harmful substances in the product

Part name	Harmful substances					
	Pb	Hg	Cd	CrVI	PBB	PBDE
Printed circuit board components	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with the provisions of SJ/T 11364.
○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is below the limit requirements specified in GB/T 26572.
×: Indicates that the content of the hazardous substance in at least one homogeneous material of the part exceeds the limit requirements specified in GB/T 26572.
Note:
(1) The parts marked with "–" on the table are unable to achieve the replacement of harmful substances due to limitations in global technological development;
(2) Printed circuit board components: including printed circuit boards and their parts, electronic components, etc;
(3) Depending on the product model, the product you purchased may not contain all of the above components.

Electronic and electrical products sold in the People's Republic of China must mark this logo, the number in the logo represent the environmental protection period of the product under normal use.

Warranty statement

Disclaimer:
This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects, free repair; if the manufacturer confirms that it cannot be repaired, if the manufacturer confirms that it cannot be repaired, repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). The date of purchase is subject to the date of the sales invoice, if the date of purchase cannot be determined, the warranty period shall be thirteen (13) months from the date of production. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1. Exceeding the validity period of three guarantees;
2. Altering the warranty card, the product code does not match the product body;
3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
5. Zipper and tower buckle are damaged due to excessive force;
6. Disconnection or tearing caused by excessive load;
7. Any damage caused by unauthorized repair;
8. Products with signs of burning or flooding;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product;
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should inspect the product on the spot when you receive it and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in Chinese Mainland. Nothing in this document affects consumer rights that cannot be excluded or restricted by law.

Service supervision hotline: 400-885-8808

TRANSFORMERS

虚线做
易撕线

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.