Bewwetting Alarm Introduction



BW 01

Urine moisture sensing transmitter

Power Indicator Light

CE FC Made in China

1.Start Button : Long press for 3 seconds to switch the machine on and off.

2.Mode Selection: Long press the mode button for 3 seconds, the mode icon on the screen flickers and jumps, press it once to switch mode selection, adjust to the required mode, and then stop blinking for 3 seconds to automatically determine the current mode.

3.Timing Setting: Hold press the button for 3 seconds to start the timing, and time icon on the screen flashes and pulsates. Press the button once to switch between different times. When the time is adjusted to the required time, it will blink for 3 seconds and stop blinking to automatically determine the selected time. None of the time is displayed, which means that the timed alarm function is turned off.

4.Power and Charging: When the power is low, the power icon flashes red light, indicating the need for charging. When connected to the charger, the red light stay on indicates charging, and when fully charged, the green light is steady on.

5.Three Mode (Vibration, Sound, Sound + Vibration): When the mode is set to any of the modes, the icon will be always on, and the corresponding light on the screen will automatically turn off after 1 minute of standby. Press any key to wake up.

6.Warning Light: When wet urine is triggered, the red light blinks, the beep and vibration are selected according to the mode. If you do not click the start button to cancel flashing after reminding, the alarm will remind again after 15 minutes.

Product Operation:

Long Press the Switch

Step 1: Long press mode icon flashes
Step 2 :Short press to switch mode
Step 3 :The icon flashing stops and the mode is selected

Step 1: Long press the time icon to flash
Step 2: Short press to switch time
Step 3: When the icon stops blinking, the time has been selected

Child Lock Icon

Step 1: Press and hold at the same time, the child lock icon lights up, and the child lock mode has been selected
Step 2: Press and hold at the same time to cancel the child lock function

Reminder: The product enters the energy-saving mode within 1 minute after any operation is completed. Short press any button to wake up, and the icon will light up.

Product Use:

Please wear the product correctly

Boy' s Briefs

Girl's Briefs

Baby's Diapers

Please clamp the sensor in a place where it is easy to get wet.

Tip:

1.Please fully charge both devices before use.

2.Do not rinse the transmitter with water, just wipe it with a paper towel.

3.The time alarm is only a reminder function that reminds children to go to the bathroom or the nanny to change diapers for the baby for a specified amount of time.

4.If the alarm is abnormal, please charge the transmitter or watch.

5.The range of the watch receiver is between 150 (wall obstruction) ----300 (no wall obstruction) feet.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarant ee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environm ent. This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.