Mibro Earbuds 3 Pro

User Manual

mibro

Thank you for choosing our product, hope the fashionable appearance and high quality stereo can enrich your life.

Note: After you receive this product, please tear off the insulation film of the earphone charging pin, charge the earphone for 10 minutes before taking it out and using.

Product Overview



❶ Microphone ❷ Eartips ❸ Charging Box Battery Indicator
❹ Charging Pin ❺ Touch Multi-function Button(MFB)
❻ LED Indicator ❼ Type-C Charge input

Charging

Please put the buds into the box before the first use, and connect the charging cable with the charging box to fully charge.

■ Put the buds into the corresponding slot to ensure that the charging contact of the buds contacts the metal sheet.
■ The white light is always on when the buds charging.
■ When the buds indicator is off, the battery is fully charged.

When the charging case shows a number less than 10, charge the charging case at this time.

■ Connect USB adapter to charge it
■ If it is not used for a long time, it shall be charged at least once every three months.
■ Please use the **A-C charging cable** to charge the charging case.

Charge your phone

The package contains a **C-C charging cable**, and the charging case can charge other type-C interface electronic devices such as mobile phones. （Apple phones need to bring their own charging cable）

Getting Starts

① Take out the headset to wear, the headset will automatically turn on, when you hear the tone, the headset enters Bluetooth pairing mode.
② Open your mobile phone system Bluetooth, search for the Bluetooth name "Mibro Earbuds 3 Pro" and click the device name to pair. The buds will prompt tone if the pairing is successful.
③ The buds will record the last connection status of the device. Take out two buds and wear them properly, you will hear prompt tone indicating that both buds are connected to the device and the device music can be played normally.

Functions

You can operate MFB to get certain functions as below:

1.Play / Pause
When playing music, double-click MFB(R or L) to pause , double-click again to resume.
2.Previous Track /Next Track
When playing music, Quick triple-click MFB(L) to previous track,
Quick triple-click MFB(R) to next track.
When playing with single earbud, triple-click MFB will always to the next track.
3.Volume Increase Or Decrease
When playing music, Click MFB(L) once to decrease the volume,
Click MFB(R) once to increase the volume.
When playing with single earbud click MFB will always to increase the volume.
4.Start voice assistant
In the Bluetooth connection state, press and hold MFB for 2 seconds to activate the voice assistant.
5.Answer/End a call
When there' s an incoming call,double-click MFB once to answer ,you can end it by double-click MFB again.
6.Reject An Incoming Call
When there's an incoming call ,press and hold the MFB for 2 seconds to reject.

Getting Off

The earbuds turn off automatically if:
① You put earbuds back to the charging case.
② When earbuds leave the charging case, but haven' t connect to any devices within 5 minutes.
③ When the earphone battery is low (please charge it in time).

Safety Instructions

- Avoid dripping and dropping.
- Please use a certified charging adapter with an output voltage not exceeding 5v.
- Never disassemble or modify your earbuds for any reasons to avoid any damages and dangers.
- Keep the earbuds dry and do not submerge it in water.
- Keep out of reach of children, small parts included may be a choking hazard,and avoid using the LED indicator close to the eyes of children or animals.
- Do not use this earbuds during a thunderstorm to avoid irregular function and increased risk of the electric shock.
- Clean with a dry, soft lint-free cloth, do not use harsh chemicals or strong detergents to clean.
- The product shall not be exposed to excessive hot or wet.

Hearing Safety

- To avoid hearing damage, do not listen for long time at high volume.
- Do not turn the volume so high that you're unable to hear your surroundings.
- Do not use earbuds while driving.
- You should use with caution or temporarily discontinue using in potentially hazardous situations.

Name and content of hazardous substances

Part name	Hazardous substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Earbuds	○	○	○	○	○	○
Battery	○	○	○	○	○	○
Charge Box	○	○	○	○	○	○
Charge Cable	○	○	○	○	○	○
Eartips	○	○	○	○	○	○

This table is prepared in accordance with SJ/T 11364-2014.

○ Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB/T 26572.

✕ It means that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit specified in GB/T 26572.

This product meets the ROHS environmental protection requirements: there is no mature technology in the world to replace or reduce the lead content of some electronic components of circuit components, steel and copper alloys.

Trouble shooting and after sales regulations

Name	Trouble shooting
Earbuds	1. The earbuds is silent during use. 2. During the call, the other party cannot hear the sound. 3. Unable to charge, the charging indicator is not on.

Non warranty regulations

1. Wear and dirt caused by users' use, such as scratches and color changes; As well as damage caused by contact with chemical reagents, sharp objects, falling, extrusion and deformation.
2. Unauthorized maintenance, collision, misuse, negligence, abuse, water ingress, accidents, and failures caused by the use of non-standard accessories of the product.
3. Tearing, altering labels, forging anti-counterfeiting marks, etc.
4. Damage caused by force majeure.
5. Non compliance with performance faults listed in the performance fault table.
6. The charging case is not waterproof!

If you need after-sales service, please contact Mibro customer service:
Website: www.mibrofit.com
customer service: 400-0908-508

Attention:
The illustrations of products and accessories in the manual are schematic diagrams for users' reference only. Due to the update and upgrading of this product, the actual product may be different from the schematic diagram. Please take the actual product as the standard.
● Mibro brand owns the final right to interpret the goods.

FAQ

Q: One of the earbud is silent while another is playing.
A: 1. It may be that the buds can't be connected normally, which may occur in extreme cases. Please put the buds back into the charging box, and then take it out for reconnection after 5 seconds;
2. The silent buds may be out of power. Please put your buds back into the charging box to fully charge them and then take them out for reuse.

Q: The earbuds didn' t turn on when I get them from the charging case, it can' t turn on automatically.
A: Please check the power of charging case, if there is no power the earbuds can' t turn on automatically,Please fully charge the product before use.

Q: The earbuds is placed in the charging compartment and still connected to the mobile phone.
A: Please check whether the earbuds is in good contact with the charging chamber, or the charging chamber is not powered.

Q: I have established connection with my smartphone, but I am not hearing any sounds?
A: Please make sure that you have turned up the volume of both devices Smartphone requires you to set up the Bluetooth earbuds as an audio output devices before transmition of sound. Please check the instruction of your smartphone for details. If you are using a music player or other Bluetooth devices, please make sure it supports A2DP protocol.

Q: Why the connection is not stable and cuts out intermittently?
A: Please make sure there are no obstacles between the ucBuds and your Bluetooth device; please make sure there is no radio or WiFi interference nearby.

Q: The sound is not very clear or the caller cannot hear my voice clearly.
A: Please adjust the volume on your phone and earbuds. Make sure there is no source of interference nearby. Stay close to your smartphone check if there's any improvement.

Package Contents

Charging Box X1, Earbuds X2, Charging cable X2(A—C/C—C), User Manual X1, 3 pairs of ear tips(M size has been pre-installed)

Basic Parameters

Earbuds Basic Parameters:

BT Model	XPEJ007
BT Version	V5.3
BT Range	≤10m(33ft
Battery Capacity	40mAh (Per Earbuds)
Charging Time	About 1.5 hours
Play Time	About 6.5hours
Stand By	About 40 hours
Input	5V ⎓ 40mA
Battery Type	Lithium ion polymer
Weight	About 3.5g (Per Earbuds)
Waterproof	IPX4

Charge Box Basic Parameters:

Battery Capacity	2000mAh
Input	5V ⎓ 1.2A
Output	5V ⎓ 1A (phone) 5V ⎓ 100mA (earbuds)
Charging Time	About 3 hours
Battery Type	Lithium ion polymer
Weight	About 52.7g

Manufacture:
ZhenShi Information Technology (Shenzhen) Co., Ltd
Address:
RM1505, Tower C, Galaxy World, Minzhi Street, Longhua District, Shenzhen, China

mibro

FCC Warnning:
This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:
Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.