aiwa

4 inches Light Up Wireless Speaker

Item: AI6035-BLK

Quick Start Guide

WHAT'S INCLUDED

--Wireless Speaker
--Carry Strap
--USB-C Charging Cable
--User's Manual with Warranty Information

A CLOSER LOOK





1. Volume Knob
2. Mode/LED Light Button
3. Previous Track Button
4. Play/Pause Button
5. Next Track/Next Station Button
6. EQ Button
7. LED Indicator
8. Microphone Port
9. Power ON/OFF Switch
10. Micro SD Card Input
11. Charge Port
12. USB Port

CHARGING

Insert one end of the included charging cable into the charging port.



Insert the other end into a suitable USB charging adapter (not included).



NOTE: Once fully charged, your speaker can provide up to 2 hours* of playtime.

*Applicable at 50% of maximum volume. Results will be lower when the volume is higher.

POWERING ON/OFF



To power ON your speaker, set the Power ON/OFF Switch to the ON position. To turn your speaker OFF, set the Power ON/OFF Switch to the OFF position.

SETTING MODE



Power ON your speaker. Press the mode button repeatedly to toggle through your speaker's various modes.

BLUETOOTH PAIRING

Once powered ON, press the mode button repeatedly to set your speaker to Bluetooth mode.

Go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as “AIWA AI6035.”

NOTE: Disconnect through your connected device or by changing modes.

LISTENING TO MUSIC

Previous Track Button:

- While using Bluetooth, press to go back to the last track in a playlist.

Play/Pause Button:

- Press to play or pause a track while using a USB, Micro SD card, or the speaker's Bluetooth functions.

- Press to auto-scan nearby FM channels while using FM Radio Mode.

Next Track Button:

- While using Bluetooth, press to go to the next track in a playlist.



Power/Master Volume Knob:

- Twist the Master Volume knob to increase or decrease volume.

- Twist the knob to the OFF position to turn OFF the speaker.

Mode Selector/LED Light:

- Press and hold for three seconds to turn the woofer LED on or off.

- Press to cycle between the different modes available on the speaker.



Microphone Port:

- You can connect a compatible microphone to the speaker through the microphone port.

ADDITIONAL FEATURES

USB Input Port

Plug a USB thumb drive into the USB Input Port on your speaker. To play from the USB, you must set the speaker to the corresponding mode. Your speaker can play .mp3 music files from your thumb drive. The maximum storage size of the USB flash drive cannot exceed 64 GB.

Note: Connecting to a computer will not work. Files will not be visible.

Micro SD Card Input

Slide a Micro SD Card into the Slot on your speaker. Your speaker can play .mp3 music files from the card inserted.

FM Radio

To use FM Radio mode to listen to music from local radio stations, set the speaker to the corresponding mode. Press the play/pause button to scan and save available FM stations.

TWS Pairing

TWS pairing allows the connection of two AI6035 speakers together on one device. Power on both speakers. Press the Play/Pause button twice on one speaker to pair together.

You can then go to the Bluetooth settings menu on your phone. Make sure that Bluetooth is turned on. Connect to the device listed as 'AIWA AI6035'.

SAFETY PRECAUTIONS

When using your speaker, basic safety precautions should always be followed including:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR SPEAKER.
2. Do not submerge your speaker in water.
3. Only clean using a clean cloth.
4. Do not allow children to play with this product. This product contains small pieces that can be a choking hazard. Parental supervision is advised.
5. Do not expose this product to excessive heat or fire.
6. Do not expose this product to temperatures above 100°F. Keep out of direct sunlight.
7. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service.
8. Do not drop, crush, or expose this product to excessive physical force.
9. This product is not intended for commercial use.
10. When charging, keep all charging cables well ventilated. Do not keep your charging cable in contact with flammable materials such as bedding, linens or synthetic fabrics.

Maintenance and Care

-Use a soft cloth or paper towel to clean your speaker. Never use any harsh chemicals or detergents for cleaning. Make sure your speaker is dry before charging.

-When your speaker is not in use, it should be stored in a cool, dry place.

-Never tug or yank on a cable while it is connected to your speaker. Connect and disconnect cables as carefully as possible.

-Never expose your speaker to high temperatures, extreme cold.

-Please recycle or dispose of your speaker properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your speaker for further information.

CAUTION

BATTERY WARNING:

-The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
-Do not dispose of in fire or expose to excessive heat.
-Do not crush, puncture, incinerate, or short circuit external contacts.
-Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

SPECIFICATIONS

Bluetooth Version: V5.3
Working Range: 10 m
Play Time: 2.5 hours*
Battery Type: 3.7V 1200mah Lithium Ion Battery

*** (At 50% volume)**

WARRANTY

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered By Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:
Call (800) 592-9541 or visit our website at www.aiwa.co.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address of the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

FCC Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

AIWA
Edison, NJ 08817
www.aiwa.us.com

© 2025 Aiwa Acquisitions LLC. All rights reserved. AIWA and associated marks are owned by Aiwa Acquisitions and used under license.

Keep all relevant information for future reference.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, INC. and any use of such marks by Sakar International is under license.