产品规格

· 产品型号：A6S
· 蓝牙版本：5.2
· 电池规格：耳机3.7V 35mAh；充电仓3.7V 250mAh
· 支持模式：HFP / HSP / A2DP / AVRCP
· 灵敏度：105d8±3dB S. P. L at 1KHz
· 信号距离：10米（无任何较大障碍物的理想环境中）
· 播放时间：约3小时
· 通话时间：约3.5小时
· 待机时间：约80小时
· 充电时间：给充电盒充电约1.5小时，充电盒给耳机充电约1小时
· 充电仓给耳机充电次数：约2.5次

功能操作说明

1、开机
将耳机从充电仓拿出自动开机或长按左右耳机多功能键3秒开机。

2、关机
将耳机放入充电仓自动关机 / 长按左右耳机多功能键5秒关机。

3、开机回连
当配对成功后，第二次开机时蓝牙耳机优先进入回连状态自动回连已连接过的手机。

4、播放 / 暂停
在待机状态下，单击左右耳机多功能键均可直接播放音乐，播放时单击左右耳机多功能键均可暂停播放。

5、切换歌曲

播放音乐时三击左右耳机多功能键切换上下曲。

6、音量加减

双击左右耳机多功能键加大减小音量。

7、来电接听

手机来电时，单击左右耳机多功能键均可接听电话。

8、来电挂断

手机通话时，单击左右耳机多功能键均可挂断电话。

9、来电拒接

手机来电时，长按左右耳机多功能键2秒均可拒接来电。

10、末号重拨

在待机或者播放音乐时，长按耳机多功能键3秒即可拨打您通话记录中最后一个拨打过的电话。

11、启动语音助手

长按耳机多功能键1.5秒即可启动Siri或谷歌语音助手进行语音控制手机操作。

配对方式

普通配对方式

1．从充电仓取出或者同时长按左、右耳机多功能键3秒开机，自动配对

2．启动手机或者其它设备的蓝牙功能，点击进入配对

3．两只耳机也可单独与手机进行配对使用，操作方法可按上步骤2操作手法进行操作。

充电操作

1．将Micro USB充电线一头插上充电盒的USB口一头插上充电器即可给充电盒充电，当充电盒电量在对应指示灯的指示范围时，该位置的白色指示灯间隔2秒闪一次，直至该指示灯的电量范围充满后则长亮进入下一电量范围的指示灯闪烁，全部充满电后所有指示灯长亮.

2．给耳机充电：将耳机放入充电仓即可自动充电，充电时耳机指示灯为红色，充满电后熄灭：充电仓蓝色指示灯长亮（充电仓满电时，4个电量指示灯全亮，当充电仓电量下降达到相应电量时，对应的指示灯则熄灭），当耳机充满电后充电仓蓝色指示灯全部熄灭。

。

Product specification·
Product model: A6S·
Version: 5.2
Battery specifications: Earphone 3.7V 35mAh; Charging bin 3.7V 250mAh·
Supported modes: HFP/HSP/A2DP/AVRCP·
Sensitivity: 105D8 ±3dB S.P.lat 1KHz·
Signal distance: 10m (ideal environment without any large obstacles)·
Running time: about 3 hours·
Talk time: about 3.5 hours·
Standby time: about 80 hours·
Charging time: charge the charging box for about 1.5 hours, and charge the headset for about 1 hour·
Charging times for earphones in charging bin: about 2.5 times

Function Operation Description
1, the bootTake the earphone out of the charging bin and start it automatically or press the left and right earphone multi-function button for 3 seconds to start it.
2, turn it offPut the earphone into the charging bin to automatically shut down/long press the left and right earphone multi-function button for 5 seconds to shut down.
3. Start and reconnectAfter the pairing is successful, the Bluetooth headset will enter the connection state preferentially and automatically return when it is turned on for the second time Connect to an already connected cell phone.
4. Play/pauseIn the standby state, you can click the left and right multi-function keys of the headset to play music directlyClick the left and right headset multi-function keys to pause the playback.
5. Switch songsWhen playing music, click the multi-function key of earphone three times to switch up and down.
6, volume increase and decreaseDouble click the left and right multi-function buttons to increase and decrease the volume.
7. Answer incoming callsWhen a mobile phone call comes in, you can click the left and right multi-function keys of the headset to answer the call.
8. Hang up the callDuring a phone conversation, you can hang up the phone by clicking the left and right multi-function keys of the headset.
9. Call rejectionWhen a phone call comes in, long press the left and right multi-function buttons of the earphone for 2 seconds to reject the call.
10. Redial the last numberWhen standby or playing music, long press the multi-function button of earphone for 3 seconds to dial your call recordThe last call made on the tape.
11. Activate the voice assistantHold down the headset multifunction button for 1.5 seconds to activate Siri or Google's Voice AssistantControl phone operation.

pairingCommon （pairing mode）
1. Take it out from the charging bin or press the left and right multi-function button for 3 seconds to start automatically pairing
2. Activate Bluetooth on your phone or other device and tap to enter pairing
3. The two earphones can also be paired with a mobile phone. For details, go to Step 2Operation method
Perform operations.
Charging operation
1. Connect one end of the Micro USB charging cable to the USB port of the charging box and the other end to the chargerCharge the charging box, when the charging box electric quantity is in the indicated range of the corresponding indicator light, this positionThe white indicator light flashes at an interval of 2 seconds until the electric range of the indicator light is fullOn The indicator that enters the next power range blinks. After the battery is fully charged, all indicators are on.
2. Charge the earphone: put the earphone into the charging bin to charge the earphone automaticallyThe light is red and goes off when it is fully charged: the blue indicator light of the charging bin keeps on (when the charging bin is fully charged,The four electric quantity indicators are all on. When the electric quantity of the charging bin decreases to the corres ponding electric quantity, the corresponding refers toWhen the headset is fully charged, the blue indicator lights in the charging bin are all off.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.