POLVCDG®

X8

FCC ID: 2BBK5-X8

USER PRODUCT GUIDE

Bone conduction sports headphones

Product parameters



Product model: X8.
Waterproof level: IP68.
Wireless version: V6.0.
Transmission distance: 10m.
Battery: 220mAh.
Charging: About 2 hours.
Playback: 8-10 hours at 50% volume.
Protocol: A2DP, AVRCP, HFP.

Multiple use button



Power on: Press and hold the power button for 3 seconds, and the red and blue lights will flash alternately.
Shutdown: Press and hold the power button for 3 seconds, and the red light will remain on for 2 seconds.
Answer and hang up: Click the power button.
Reject incoming call: Press and hold the power button for 2 seconds.
Pause/Play: Click the power button.
Volume up: Click the volume+button.
Volume reduction: Click the volume button.
Previous song: Double click the volume key.
Next song: Double click the volume+key.
Activate Siri: Long press the volume+key for 2 seconds.
Game/music mode switch: Long press the volume key for 2 seconds.
Switching between Chinese and English languages: Three clicks on the volume key.

TF Memory Version Extension Function

Switch between TF mode and Bluetooth mode: Double-click the multifunction button.
In TF card mode: Triple-tap the + button to switch between shuffle play and sequential play.
TF song mode supports: MP3/M4A/WAV/WMA/FLAC/AAC.

Pairing/Pilot lamp



Enter pairing mode: Once powered on, it enters the pairing mode. The blue light flashes once for 2.5 seconds.
Pair with the mobile phone: After entering the pairing mode, turn on the wireless (mobile phone/computer) search on the device and select the device name "X8". Click on "X8" to establish a pairing connection. Once the connection is successful, the blue light flashes rapidly twice.
The mobile phone initiates disconnection: The red and blue lights alternate flashing.
Charging: The red light remains on constantly.
Fully charged: The blue light remains on constantly.

Song download

(Expansion function of TF memory version)



1. Connect the headphones to your computer via the magnetic cable.
2. Open the disk on your computer.
3. Import audio files to the disk.

Adjustable elastic strip (fixed elastic strip)

Function 1: Adjust the elastic band to change the size.
Function 2: Use the fixed strap during exercise to prevent the headphones from falling off due to intense movement.

⚠ Charging

1. The headphones use a built-in rechargeable battery, which must be fully charged when using the headphones for the first time. If the voice prompts low battery, you need to charge the headphones on time.
2. Connect the charging cable to the magnetic charging port of the headphones, and it will be fully charged in about 2 hours. The indicator light stays red while charging and turns blue when fully charged.

⚠ Warning!!!

1. Magnetic charging has positive and negative poles corresponding to each other, mutual adsorption can be normal charging, mutual rejection can not be charged, or even cause a short circuit.
2. The rechargeable battery of this product must be properly disposed of for recycling. Please do not put the battery into the fire to avoid causing an explosion.

⚠ Matters needing attention

1. Do not soak the headphones in the seawater/salt water for a long time. Rinse the charging magnetic part with fresh water after use.
2. If you do not use it for a long time, please charge it at least once a month.
3. Please do not disassemble any part of the product without permission. If the product is found defective, stop using the product immediately.
Contact the seller for after-sales treatment.
4. After each exercise, please wipe the water on the surface of the headphones, especially the position of the charging magnetic suction port. It should be cleaned in time to prevent sweat and salt water from corroding the charging port and affecting the service life of the product.
5. Keep the product away from fire, heat source, freezing source, and chemicals, and prohibit violent impact, disassembly, and extrusion of the product.
6. Please use the charging head with output 5V 1A or less. If the charge is greater than 5V, it will cause the headphones to heat up, which may cause damage to the battery and motherboard.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.