65mmX85mm

XG42

使用说明书

请提前阅读使用说明书，方便后续使用

产品参数

产品名称	XG42
蓝牙版本	6.0
传输距离	10M
喇叭直径	Φ10mm
充电口	Type-C
灵敏度	114.5± 3dB
充电盒电池	3.7V 300mAh
耳机电池	3.7V 30mAh
充电时间（充电盒）	1.5-2H
充电时间（耳机）	0.8H
播放时间（耳机）	5H
待机时间（耳机）	30H(无连接)

包装清单

真无线蓝牙耳机	*2
耳机充电仓	*1
Type-c充电线	*1
说明书	*1

操作说明

1.基础说明



❶ 指示灯 ❷ 触摸区域 ❸ 透气孔
❹ 显示屏 ❺ 充电接触口 ❻ 出音孔
❼ 屏幕开关 ❽ Type-C充电口

2.模式选择

电话模式
拒接来电:长按2s
来电:单击接听，再单击挂断

对耳模式
左耳三触:音量降低
右耳三触:音量增加

音乐模式
左耳双触:播放上一曲
右耳双触:播放下一曲
单触:播放/暂停

对耳模式
开机:长按3S
关机:长按5S
唤醒SIRI:长按右耳2s

3.APP下载及使用

扫描二维码下载AI EarLink软件

Play 商店 App Store Android

❶ 打开设备，连接手机蓝牙

❷ 打开AI EarLink，[绑定设备]

❸ 点击我的设备，即可使用耳机所有功能

4.屏幕说明

拨打电话
在连接蓝牙情况下可以拨打电话

来电提醒
来电话可提醒并显示号码

音乐界面
点击图标即可播放/暂停
上下曲切换

语言设置
上下滑动选择合适的语言
点击即可完成切换

拍照
当耳机连接手机蓝牙时，
通过点击拍 照图标， 可控制手机拍照

手电筒
点击即可点亮屏幕

模式选择
音乐模式和游戏模式

壁纸
左右滑动可切换壁纸

亮度调节
左右滑动即可调整屏幕亮度

秒表
可设置时长或者重置

均衡器
提供7种风格选择

定位功能
点击即可搜寻耳机位置

小游戏
内置休闲小游戏

出厂设置
清除以往的缓存数据

关机界面
向右滑动即可关机

语音助手
点击图标，即可唤醒语音助手

重启界面
向右滑动即可重启

注意事项

提示

1. 使用产品前请仔细阅读本使用说明书并请妥善保管
2. 首次使用，请先将本产品充满电
3. 如果产品长期（超过 1 个月）不用，请对其充电；
4. 若手机无法搜索蓝牙耳机，请确认蓝牙耳机是否处于“配对状态” 若长时间未进行配对或连接，蓝牙耳机配对功能将关闭，请重新开启蓝牙耳机至“配对状态”若手机程序出错，请重启手机；若蓝牙耳机程序出错，请重启蓝牙耳机。

警告

1. 请勿以任何理由拆除或维修改装耳机，否则可能会导致起火、电子元件击穿甚至彻底损坏本产品
2. 请勿将设备置于温度过低或过高（0℃以下或 45℃以上）的环境下
3. 请避免靠近儿童或动物的眼睛使用设备指示灯
4. 请勿在雷暴天气下使用该设备，雷暴可导致设备工作不正常并增加触电的危险
5. 请勿用油及其他挥发液体擦拭本产品
6. 请勿将设备接触液体弄湿

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in an uncontrolled environment without restriction.

XG42

Instructions for use

Please read the instruction manual in advance to facilitate subsequent use

Product Parameters

Product Name	XG42
Bluetooth version	6.0
Transmission distance	10M
Horn diameter	Φ10mm
Charging port	Type-C
Sensitivity	114.5± 3dB
Charging case battery	3.7V 300mAh
Headphone battery	3.7V 30mAh
Charging time (charging box)	1.5-2H
Charging time (headphones)	0.8H
Play time (headphones)	5H
Standby time (headphones)	30H (No connection)

Packing List

True wireless Bluetooth headset	*2
Headphone charging case	*1
Type-c Charging cable	*1
manual	*1

Operation Instructions

1.Basic description



❶ Indicator light ❷ Touch area ❸ Breathable hole
❹ Display ❺ Charging contact port ❻ Sound output hole
❼ Screen switch ❽ Type-C charging port

2. Mode selection

Phone Mode
Reject incoming calls: Long press for 2s
Incoming call: Click answer, then click Hang off

Ear mode
Three touches on the left ear: volume down
Three touches of the right ear: volume increases

Music mode
Left ear double touch: Play the previous song
Touch the right ear: Play the next song
One Touch: Play/Pause

Ear mode
Start up: Long press 3S
Shut down: Long press 5S
Wake up SIRI: Press the right ear for 2 seconds

3. Download and use of APP

Scan the QR code to download **AI EarLink** software

Play Store App Store Android

❶ Turn on the device and connect to the Bluetooth phone

❷ Open AI EarLink, [Bind Device]

❸ Click on my device to use the headphones All functions

4. Screen description

Make a phone call
Scan the QR code to download AI EarLink Software, available for download in major app stores

Call reminder
Remind and display the number when incoming calls

Music interface
Click the icon to play/pause the up and down curves toggle

Language settings
Swipe up and down to select the appropriate language and click to complete the switch

Photograph
When the headset is connected to the phone's Bluetooth,By clicking on the photo icon, you can control it ,Take photos on your phone

Flashlight
Click to light up the screen

Mode selection
Music mode and game mode

Wallpaper
Slide left and right to switch wallpaper

Brightness adjustment
Slide left and right to adjust the screen brightness

Stopwatch
Can be set or reset

Equalizer
7 style options available

Positioning function
Click to search for the headset location

Small game
Built-in casual games



Factory settings
Clear past cached data



Shutdown interface
Swipe right to shut down

Voice Assistant
Click the icon to wake up the voice assistant



Restart the interface
Swipe right to restart

Things to note

Hint

1. Please read this instruction manual carefully before using the product and keep it properly
2. For the first time, please fully charge this product first
3. If the product is not used for a long time (more than 1 month), please charge it
4. If the phone cannot search for Bluetooth headsets, please confirm whether the Bluetooth headset is in the "pairing state". If the pairing or connection is not performed for a long time, the Bluetooth headset pairing function will be turned off. Please turn on the Bluetooth headset to "pairing state". If the mobile phone program is wrong, please restart the phone: If the Bluetooth headset program is wrong, please restart the Bluetooth headset.

Warn

1. Do not remove or modify the headphones for any reason, otherwise it may cause ignition electronic components to break down or even completely damage this product. 2. Do not place the equipment at a temperature that is too low or too high (below 0℃ or above 45℃). In the environment 3. Please avoid using the equipment indicator light near the eyes of children or animals 4. Please do not use the equipment in thunderstorms, as the equipment may not work properly. and increase the risk of electric shock
5. Do not wipe this product with oil or other volatile liquids.
6. Do not wet the device when it comes into contact with liquid