尺寸：70X100mm
材质：105G双铜+四色双面印刷+风琴折

70 mm

100 mm

Wireless Camera Clock

1. Thanks for your purchase and support, we appreciate all your valuable feedback.
2. If you have any questions about our products, please feel free to contact us.

Email: sztuweikeji@163.com

2.4G

Before operating this unit,please read these instructions carefully,and save them for future use.

AJCloud

Interface description

This manual is suitable for various types of cameras.
(The appearance may be different due to different batches. The details are subject to the receipt.This manual is only for the installation instructions of this series of equipment)



1. Magnetic adsorption area
2. Reset indicator green light
3. Power on/off button
4. Reset button
5. Camera
6. Alarm clock indicator light
7. Charge lamp
8. Set the +/ off screen button
9. Set the -/ Brightness Settings button
10. Time/year/month/day setting button
11. Alarm clock setting button
12. Alarm clock snooze button
13. USB-C (5V2A) charging input port
14. SD card slot

Software installation

APP Download and Installation

Users can search "**AJCloud**" on APP store or Google Play, or scan the QR code bellow to install the APP.

AJCloud APP　　APP download

Step 1

If you are prompted to open certain permissions (such as location, message notification, etc.) during APP installation, click Allow (agree).

Step 2

Account register: Open the APP,click" Sign up",enter your email or phone number to create an account.

Account login: On the login interface, enter the account(phone number/email), and the corresponding password and click the "OK" button to log in.

Thirdparty login: APP supports third-party login. Click the thirdparty social software icon, jump to the APP to complete theauthorization and log in.

Bluetooth adding process with network

Before pairing a camera, please make sure that the Bluetooth function of the mobile phone has been turned on, and do not turn off the Bluetooth during the pairing process. If a prompt box pops up during the pairing process to enable Bluetooth permissions, please click "Allow".
Pairing requires a phone to install. **(Keep the connection between the mobile phone and home WiFi.Only supports 2.4G WiFi network)**

Step 1

After the camera is powered on, open the "AJCloud "APP and click the "+" icon in the upper right corner to enter the interface of adding devices.

Step 2

The APP will automatically search for a new device and click the "Pair" button when it finds the device.

Step 3

Select the home Wi-Fi network you need the camera to connect to, enter the password, and then click "Next."

Step 4

After the network is configured successfully, the camera prompts you to enter the device name. Click Next.

Or you can add camera by WiFi configuration

Step 1

Open the APP, click the "+" icon Or click the "Add device" to enter the scan code interface;

Step 2

Select the device type , Select "IP Camera"

Step 3

Select WiFi connection by QR code

Step 4

Check whether the device is powered on and has a prompt tone

Step 5

Select the WiFi that the camera needs to connect to, enter the password, and click Next;

Step 6

Point the camera at the QR code that appears on the screen of the phone

Step 7

After the network configuration is successful, set a name for the camera.

If wireless camera configuration fails, please follow the APP guide to reconfigure.

Help FAQ

Q1: Why is the pairing network unsuccessful?

1. Please make sure that the distance among the camera, the router and the mobile phone should be close enough when configuring the network.
2. Please make sure that the WiFi signal connected to the mobile phone is 2.4G WiFi and 5G WiFi are both ok.
3. Please check whether the WiFi name and password are correct.
4. Please long press the reset button for 5 seconds and try again after restoring the camera to the factory settings

Q2: Why is there no playback?

1. Make sure that the TF card has been inserted into the camera and try to turn onoff the camera.
2. Enter the camera settings menu to check the storage status ("in good condition"/ " the status is abnormal") click to "Format the memory card".)

Q3: Why is the camera offline?

1. It may caused by router WiFi signal interference or network reasons. Power off and restart the optical modem, router or camera.
2. The camera maybe too far away from the WiFi router, try to get the camera next to the WiFi router.
3. Whether the WiFi password has been changed, try to reset the camera and try pairing again.

Q4: Why my phone does not have an alarm push function

1. Check your mobile phone permission settings, and make sure that enable the notification permission of "AJCloud" App.
2. Open your phone's Settings > Apps and Notifications, select Apps and Notification Management respectively, find the "AJCloud" app, and turn on all permissions.

Important Notice: To comply with local laws and regulations and protect user privacy, this device does not have a recording function.



Clock Function Introduction

- 4-digit LED display
- Time and date functions
- WIFI connection and automatic time synchronization
- Alarm function and snooze function
- 6-button operation: ×,MODE,AL,SNOOZE,ON/OFF,RST
- 4-level brightness adjustment
- Automatic dimming at night
- One-button screen-off function
- On/off function

Operating Instructions

In the power-off state, long press the ON/OFF key for 1 second to turn on the device and enter the time mode.
In the power-on state, long press the ON/OFF key for 1 second to turn off the device. When powered off, the clock function continues to keep time normally.
In the power-on state, long press the "R" key for 6 seconds to reset the WIFI configuration.

Time

In time mode, press the MODE key to display the date.
In time mode, press the AL key to display Alarm 1 and Alarm 2.
In time mode, press the "+" key to turn off the screen, and press any key to turn the screen back on.
In time mode, press the "-" key to adjust the brightness, which has 4 adjustable levels.
Auto-brightness function: The brightness will automatically dim from 18:00 to 6:00.

Alarm

WIFI Time Synchronization Function

After the alarm clock is turned on, it needs to be configured for Wi-Fi through a mobile phone. Once the configuration is successful, the alarm clock can automatically synchronize the time.

Time Setting

In time mode, press and hold the MODE key for 2 seconds to enter the time setting. First, set the hour: the hour will flash. Use the "+"/"-" keys to adjust the hour. After setting the hour, press the MODE key to switch to setting the minute, year, month, and date in sequence.

Alarm Mode Operation

In the time mode interface, press the AL key to switch to the alarm clock 1 mode, and AL 1 will be displayed. Then press the AL key in sequence: → Display the time of alarm clock 1; Alarm clock 1 in OFF/ON state; → Display AL 2; → Alarm clock 2 time; Alarm clock 2 is in OFF/ON state. Press the "AL" key again to return to the time display interface. If there is no operation and it stays for 10 seconds, it will automatically exit and display the time interface.

In the ON/OFF mode of Alarm Clock 1 (AL1) or Alarm Clock 2 (AL2), press the "+"/" -"keys to turn on (the alarm clock indicator light in the upper right corner lights up simultaneously)/ turn off the alarm clock (the alarm clock indicator light in the upper right corner goes off simultaneously).
On Alarm Clock 1 or 2, the alarm time mode is displayed. Press and hold the AL key for 2 seconds to enter the alarm time setting. First, set the hour. The hour will flash. Press the "+"/" -"keys to adjust the hour. After setting the hour, press the AL key again to switch to setting the minute.
The alarm rings for 60 seconds.
When the alarm rings, press the SNOOZE key to stop the alarm and enter a 5-minute snooze. Pressing any other key will cancel the snooze.
When the alarm rings, pressing any other key will cancel the alarm.
In off-screen mode, the screen will automatically turn on when the alarm rings.

Alarm 1

Alarm 1 Time

Alarm 1 OFF

Alarm 1 ON

Charging Indicator Instructions

Plug in the 5V2A USB-C charging cable to charge and the device can be turned on. During charging, the green charging icon in the upper right corner flashes at 0.5Hz and the green light of the full charge indicator light remains constantly on. When working without a charging cable, the indicator light remains constantly white.

The charging light is green

Standby with the white light on

Product Information

Product Name：Wireless Camera Clock
Product Model：T101
Product Features：Motion Detection, App Control,Night Vision,Remote viewing
Resolution：4K
Charging input：5V⎓2A (Charging time approximately 4 hours)
Battery energy：5000mAh(18.5Wh/3.7V) (Working hours 10~15 hours)
Storage medium：MicroSD / TransFlash Card (TF card system format: FAT32)
Wireless connection distance：10M(Undestructed)
Material：ABS
Size：152.16*68.6*25mm
Weight：210g

Product List

Wireless camera clock	Power adapter	Charging cable
User Manual	Magnetic fastening iron sheet	

After Service

1. Thanks for your purchase and support, we appreciate all your valuable feedback.
2. If you have any questions about our products, please feel free to contact us.

Email: sztuweikeji@163.com

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- **Reorient or relocate the receiving antenna.**
- **Increase the separation between the equipment and receiver.**
- **Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- **Consult the dealer or an experienced radio/TV technician for help.**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.