Professionally Test And Recommend Each Toy For You!

1 * WARRANTY & AUTHENTICATION
2 * BRAND STORY
3 * AFTER SALES SERVICE
4 * HOW TO USE

* User Manual
Thanks for using our products!
Please read and keep the user manual carefully.

WARRANTY & AUTHENTICATION

Vitally, Act Now!

The default warranty period for the product is 12 months.
Scan the QR code below to

Extend the warranty period to 2 years
Verify the authenticity of the product
Get exclusive Promos & Giveaways

www.utimi.com

* Or visit the "Warranty" menu on the official website to complete your product registration.

* Note: Warranty service is valid only under normal use of the product.

BRAND STORY

UTIMI

Professional testing and recommendation of each toy

All self-developed products are selected through online screening. Also, tested and recommended by professional players, and judged by the platform as excellent products before they hit the shelves.
Choose Utimi, no longer bad mood by buying inferior products.

Evolution
In 2014, UTIMI was founded.
In 2016, UTIMI became the largest seller in the Sexual Wellness category on Amazon.
In 2018, UTMI has 100+ patents for adult products.

Over the years, we found a large number of problems with adult products such as short life span, poor use, no privacy packaging, and use of materials that are harmful to the body. To solve these problems, we carried out a comprehensive strategic upgrade and determined to allow users to easily find the right and reassuring products.

Pleasure Products
Utimi provides "high-quality, safe, creative, effective, cost-effective" erotic products, as well as one-on-one expert customer service.

Each product is selected and developed from the real needs of users, careful analysis and research on the pain points of similar products. We focus on product rationality and how to use it longer and safer.
Each product is tested by professional players around the world, and receives their unanimous recommendation, and then is judged by the platform to be excellent before it goes on sale.
For each order, we invite users to participate in a satisfaction survey. The number of participants reaches more than 50. Products with a rating or a recommendation ratio separately lower than 4.3 or 80% will be permanently banned from sale. It's our priority to collect users' experience.

Interactions
Freedom, equality, respect, sharing, tolerance!
Sex is a fundamental human need, one that transcends gender, age, color, class, and culture, shameless and unyielding one with no obscurity and no relocation, a spiritual life that humans enjoy equally!
Utimi unites a group of certified professional sex educators, sexology experts, sex toy connoisseurs, and also brings together a group of men and women, LGBTQ, SM players who seek excitement and love to explore and share. You can easily communicate and share with us, and together we can create a very inclusive spiritual paradise.

OUR SLOGAN:

Professionally Test And Recommend Each Toy For You!

AFTER-SALES SERVICE

If you are not satisfied with the product please contact us first, we will try our best to solve your problem as soon as possible.

Other questions, such as: warranty and authentication, instructions for use, product advice, product representation, etc.

Please contact us through the following ways.

support@utimi.com
+1-6264184100
(GMT+8. 09:00 am - 06:00 pm Workday)
https://www.facebook.com/Utimitoys
+1-6264184100
https://www.utimi.com/

support@utimi.com
+1-6264184100
(GMT+8. 9:00 pm - 06:00 am Workday)
https://www.facebook.com/Utimitoys
+1-6264184100
https://www.utimi.com/

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2)This device must accept any interference received, including interference that may cause undesired operation.

EN EN

1. APP DOWNLOAD AND INSTALLATION

Ios System
*1. Search for "ijoy" in the APP Store to download, install, and update
*2. Scan the QR code below with your phone and follow the prompts to install the IJOY APP

Android System
1. Search for "ijoy" in the Google store to download, install, and update
2. Scan the QR code below with your phone and follow the prompts to install the IJOY APP

EN EN

2. REGISTRATION AND LOGIN

Choose the login registration method based on the current mobile language, with Chinese as the mobile verification code for registration, and overseas as the email for registration and login.



EN EN

3. CONNECTING DEVICES

*1. Open the app and follow the prompts to allow access to Bluetooth, storage, camera albums, microphones, positioning, and other related permissions.
*2. Turn on the device power, the device Bluetooth indicator light flashes, wait for a few seconds for the app to automatically connect to the device, and the device indicator light remains on.

EN EN

4. THE DEVICE HAS BEENSUCCESSFULLY CONNECTED



EN EN

SPECIFICATION

(Four Seasons) (CE and WEEE labels required) (Amazon boutique version) APP Women's vibrator Butterfly wearing vibrator Women's masturbation in body tapping vibrator clitoral stimulator G-point stimulator with magnetic suction built-in battery Rose red with remote control
Origin: China
Color: Rose Red
Material: silicone+ABS
Body size: 13 * 11.5 * 5.5cm
Remote control size: 6 * 3.6 * 1.3cm
Product weight: 182
Waterproof grade: IPX6
Function: 9-frequency dual vibration+tapping
Packaging List Product Body Remote Control Charging Line Instructions Storage Bag

EN EN

ILLUSTRATE



Key on
Press and hold for 2 seconds to turn on and 2 seconds to turn off.



Stroking key
Short press to activate the tapping function, long press for 2 seconds, standby mode, and the light flashes.

Vibration key
Short press to activate the dual vibration function, long press for 2 seconds, standby mode, and the light flashes.

EN EN

HOW TO USE

1. Before use, please disinfect the product and fully charge it.

2. Add some lubes into the product when using.

3. Magnetic suction, relying on a magnet to clamp underwear.

EN EN

ATTENTION

Insert the USB charging cable into the charging interface of the product.
Insert the USB charging cable into an available PC USB port or AC adapter.
After the connection is correct, the indicator light flashes every few seconds.
When the device is fully charged, the indicator light remains on.
Before connecting, please ensure that the USB port of the computer is connected to the product.
Please fully charge this product before first use or prolonged use.
To ensure the quality of the battery, please fully charge it at least every six months.
Do not use a USB charging cable that is not included. The accompanying USB charging cable is not waterproof.
Please be careful not to put it into water to avoid other accidents such as electric shock or burns

EN EN

CLEANING & STORAGE

>> Cleaning
Wash directly after use.
After dry cleaning, gently pat with a dry lint free linen cloth or towel until dry.
If there is lubricating oil or dirt on the product, please wipe it with a soft cloth and clean it with mild soap or neutral detergent.
The product body is waterproof and can be rinsed underwater.
Do not rinse with hot water or boil. Do not use solvents such as benzene or alcohol to clean the product to avoid deformation and discoloration.

>> Storage

Use talcum powder
Ventilated place
Avoid the sun
Away from children

⚠It is strictly prohibited to immerse this product in water during charging to avoid accidents such as electric shock, short circuit, fire, etc
⚠ Please do not store this product in areas exposed to sunlight, high temperatures, or high humidity. This may cause discoloration, cracking, heating, and even cause a fire.

EN EN

TROUBLESHOOTING

The product is not working properly/the expansion or rotation function is weak
Do you hold down the power button for 2-3 seconds after pressing it?
Is he fully charged?
Please release the power until the product cannot be turned on, and then fully charge it. If it still doesn't work after several attempts, the battery may be damaged

The product is not working properly/the expansion or rotation function is weak
Is the charging cable disconnected from the user or charging port?
When using the computer USB port at that time, if your computer entered standby mode, the product would not charge. Please check if your computer is in standby mode.
There may be dust and stains on the charging port. When recharging, please wipe it with a dry cloth or cotton swab
Is the product fully charged? When the product is fully charged, the indicator light will remain on.

Charging will not be completed. (Indicator light remains on)
Dust and stains may stick to the charging port. Please wipe with a dry cloth or cotton swab before charging
If the indicator light remains on after 180 minutes of charging, it may be due to poor contact of the charging contacts

EN EN

SAFETY & WARNINGS

If you are using a medical device/receiving treatment/pregnant, consult your doctor before use.
If you feel any discomfort while using the product, please stop using it and consult your doctor or pharmacist.
When you notice that the product is working abnormally, please stop using it and turn off the switch immediately to avoid injury or accident.
Keep it out of reach of children to prevent them from accidentally swallowing product parts or accessories.
Please use the provided USB charging cable to charge and connect it correctly otherwise it may overheat or burn out.
To avoid electric shock or burns, please keep your hands dry when unplugging the charging cable.
Please turn off the switch before charging or it may cause malfunction, heat or even fire.
Please turn off the switch before cleaning, otherwise it may cause malfunction, overheating or burning.
When unplugging the included USB charging cable, please hold the connection part and do not stretch the cable, otherwise it may accelerate the deterioration of the cable and lead to electric shock+short circuit or even fire.
Unplug the USB charging cable when there is no need for charging. Otherwise it may be short-circuited due to dust and moisture, and lead to electric leakage or fire accidents
Please clean the USB charging cable connector regularly to avoid dust causing a short circuit or fire.

EN EN

SAFETY & WARNINGS

Please do not make excessive profits or trample on it.
If you feel uncomfortable, please stop using it
Do not use when extremely tired or drunk to avoid causing other discomfort. Do not charge, use, or store at extreme temperatures, as this may cause burns or rupture
Do not forcefully pull or remove the surface silicone to avoid damaging or replacing the product
Do not excessively bend or pull the attached USB charging cable, nor wrap the charging cable around the product for storage, as this may damage the charging cable.
Do not use the attached USB charging cable when it is damaged, as it may cause electric shock, short circuit, or fire.
Please do not share this product with multiple people to avoid spreading sexually transmitted diseases.

DE DE

1. APP DOWNLOAD UND INSTALLATION

Ios System
*1. Suchen Sie im APP Store nach "ijoy", um herunterzuladen, zu installieren und zu aktualisieren
*2. Scannen Sie den QR-Code unten mit Ihrem Telefon und folgen Sie den Anweisungen, um die IJOY APP zu installieren

Android System
*1. Suchen Sie im Google Store nach "ijoy", um herunterzuladen, zu installieren und zu aktualisieren
*2. Scannen Sie den QR-Code unten mit Ihrem Telefon und folgen Sie den Anweisungen, um die IJOY APP zu installieren

DE DE

2. ANMELDUNG UND ANMELDUNG

Wählen Sie die Anmeldemethode basierend auf der aktuellen mobilen Sprache, mit Chinesisch als mobilen Verifizierungscode für die Registrierung und Übersee als E-Mail für die Registrierung und Anmeldung.

DE DE

3. ANSCHLUSSGERÄTE

*1. Öffnen Sie die App und folgen Sie den Anweisungen, um Zugriff auf Bluetooth, Speicher, Kameraalben, Mikrofone, Positionierung und andere zugehörige Berechtigungen zu gewähren.
*2. Schalten Sie das Gerät ein, und die Bluetooth-Kontrollleuchte des Geräts blinkt.

DE DE

4. DAS GERÄT WURDE ERFOLGREICH ANGESCHLOSSEN



DE DE

SPEZIFIKATION

(Vier Jahreszeiten) (CE- und WEEE-Etiketten erforderlich) (Amazon Boutique-Version) APP Frauenvibrator Butterfly tragender Vibrator Frauenmasturbation im Körper klopfenden Vibrator Klitorisstimulator G-Punkt Stimulator mit magnetischer Saug eingebauter Batterie Rose rot mit Fernbedienung
Ort: China
Farbe: Rose Red
Material: Silikon+ABS
Körpergröße: 13,11,5,5,5cm
Größe der Fernbedienung: 6.3.6.1.3cm
Produktgewicht: 182
Wasserdichte Qualität: IPX6
Funktion: 9-Frequenz Dual Vibration+Tapping
Verpackungsliste Produktkörper Fernbedienung Ladelinie Anleitung Aufbewahrungstasche

DE DE

VERANSCHAULICHEN



Key on
Halten Sie die Taste zwei Sekunden lang gedrückt, um sie einzuschalten und zwei Sekunden lang, um sie auszuschalten.

Schlagtaste
Kurz drücken, um die Klopffunktion zu aktivieren, lange drücken für zwei Sekunden, Standby-Modus, und das Licht blinkt.

Vibrationsschlüssel
Kurzes Drücken, um die Dual Vibration Funktion zu aktivieren, langes Drücken für zwei Sekunden, Standby Modus, und das Licht blinkt.

DE DE

WIE BENUTZT MAN

1. Desinfizieren und laden Sie das Produkt vor der Verwendung vollständig auf.

2. Fügen Sie dem Produkt bei der Verwendung etwas Gleitmittel zu.

3. Magnetische Absaugung, die sich auf einen Magneten verlässt, um Unterwäsche zu klemmen.

DE DE

ACHTUNG

Stecken Sie das USB-Ladekabel in die Ladeschnittstelle des Produkts.
Stecken Sie das USB-Ladekabel in einen verfügbaren PC-USB-Anschluss oder Netzadapter.
Nach korrekter Verbindung blinkt die Kontrollleuchte alle paar Sekunden.
Wenn das Gerät vollständig aufgeladen ist, bleibt die Kontrollleuchte eingeschaltet.
Stellen Sie vor dem Anschließen sicher, dass der USB-Anschluss des Computers an das Produkt angeschlossen ist.
Bitte laden Sie dieses Produkt vor dem ersten Gebrauch oder längerem Gebrauch vollständig auf.
Um die Qualität der Batterie zu gewährleisten, laden Sie sie bitte mindestens alle sechs Monate vollständig auf.
Verwenden Sie kein USB-Ladekabel, das nicht im Lieferumfang enthalten ist.
Das mitgelieferte USB Ladekabel ist nicht wasserdicht.
Bitte achten Sie darauf, es nicht in Wasser zu geben, um andere Unfälle wie Stromschlag oder Verbrennungen zu vermeiden

EN EN

REINIGUNG & LAGERUNG

>> Reinigung
Direkt nach Gebrauch waschen.
Nach der chemischen Reinigung vorsichtig mit einem trockenen fusselfreien Leinentuch oder Handtuch tupfen, bis es trocken ist.
Wenn sich Schmierölöder Schmutz auf dem Produkt befindet, wischen Sie es bitte mit einem weichen Tuch ab und reinigen Sie es mit milder Seife oder neutralem Reinigungsmittel.
Der Produktkörper ist wasserdicht und kann unter Wasser gespült werden.
Nicht mit heißem Wasser abspülen oder kochen.
Verwenden Sie keine Lösungsmittel wie Benzol oder Alkohol, um das Produkt zu reinigen, um Verformungen und Verfärbungen zu vermeiden.

>> Aufbewahrung

Talkumpuder verwenden
an einem belüfteten Ort aufbewahren
die Sonne meiden
von Kindern fernhalten

⚠Es ist strengstens verboten, dieses Produkt während des Ladens in Wasser einzutauchen, um Unfälle wie Stromschlag, Kurzschluss, Feuer usw. zu vermeiden
⚠ Bitte lagern Sie dieses Produkt nicht in Bereichen, die Sonnenlicht, hohen Temperaturen oder hoher Luftfeuchtigkeit ausgesetzt sind. Dies kann zu Verfärbungen, Rissen, Erwärmung und sogar zu einem Brand führen.

EN EN

TROUBLESHOOTING

Das Produkt funktioniert nicht richtig/die Expansions- oder Rotationsfunktion ist schwach
Halten Sie die Power-Taste für 2-3 Sekunden gedrückt, nachdem Sie sie gedrückt haben?
Ist er voll aufgeladen?
Bitte schalten Sie die Stromversorgung aus, bis das Produkt nicht eingeschaltet werden kann, und laden Sie es dann vollständig auf. Wenn es nach mehreren Versuchen immer noch nicht funktioniert, kann der Akku beschädigt werden.

Dieses Produkt kann nicht aufgeladen werden. (Kontrollleuchte blinkt nicht)
Ist das Ladekabel vom Benutzer oder Ladeanschluss getrennt?
Wenn Sie den USB-Anschluss des Computers zu diesem Zeitpunkt verwenden und Ihr Computer in den Standby-Modus wechselte, wurde das Produkt nicht aufgeladen. Bitte überprüfen Sie, ob sich Ihr Computer im Standby-Modus befindet.
Wenn Sie den Ladeanschluss aufladen, wischen Sie ihn bitte mit einem trockenen Tuch oder Wattestäbchen ab.
Ist das Produkt vollgeladen? Wenn das Produkt vollständig aufgeladen ist, bleibt die Kontrollleuchte eingeschaltet.

Die Aufladung wird nicht abgeschlossen. (Blinklicht bleibt an)
Staub und Flecken können am Ladeanschluss haften bleiben. Bitte vor dem Aufladen mit einem trockenen Tuch oder Wattestäbchen abwischen
Wenn die Kontrollleuchte nach 180-Minuten-Ladezeit leuchtet, kann es an einem schlechten Kontakt der Ladekontakte liegen.

EN EN

SAFETY & WARNINGS

Wenn Sie medizinische Geräte verwenden/behandelt werden/schwanger werden, konsultieren Sie bitte vor der Anwendung einen Arzt
Wenn Sie während der Anwendung Beschwerden verspüren, beenden Sie bitte die Anwendung und konsultieren Sie einen Arzt oder Apotheker
Wenn Sie feststellen, dass das Produkt abnormal funktioniert, beenden Sie bitte sofort die Verwendung und schalten Sie das Gerät aus, um Verletzungen oder Unfälle zu vermeiden.
Bitte bewahren Sie es außerhalb der Reichweite von Kindern auf, um zu verhindern, dass sie versehentlich Produktteile oder Zubehör verschlucken
Bitte verwenden Sie das mitgelieferte USB-Ladekabel, um es richtig aufzuladen und anzuschließen, da es sonst zu Überhitzung oder Burnout kommen kann.
Um Stromschläge oder Verbrennungen zu vermeiden, halten Sie bitte Ihre Hände trocken, wenn Sie das Ladekabel abziehen.
Bitte schalten Sie den Strom vor dem Aufladen aus, sonst kann es zu Fehlfunktionen, Wärmeentwicklung oder sogar Feuer kommen.
Bitte schalten Sie das Gerät vor der Reinigung aus, da es sonst zu Fehlfunktionen, Überhitzung oder Verbrennungen kommen kann.
Wenn Sie das angeschlossene USB-Ladekabel abziehen, halten Sie bitte das Verbindungsteil fest und dehnen Sie das Kabel nicht, sonst kann es die Kabelalterung beschleunigen, was zu Stromschlag, Kurzschluss oder sogar Feuer führen kann
Wenn das Aufladen nicht erforderlich ist, ziehen Sie bitte das USB-Ladekabel ab, da es sonst einen Kurzschluss durch Staub und

EN EN

SAFETY & WARNINGS

Feuchtigkeit verursachen kann und zu Stromleckagen oder Brandunfällen führen kann
Bitte reinigen Sie den USB-Ladekabelanschluss regelmäßig, um Staub zu vermeiden, der Kurzschlüsse oder Brände verursacht.

Bitte machen Sie keine übermäßigen Gewinne oder trampeln Sie darauf.
Wenn Sie sich unwohl fühlen, hören Sie bitte auf, es zu verwenden
Nicht verwenden, wenn extrem müde oder betrunken, um andere Beschwerden zu vermeiden. Nicht bei extremen Temperaturen laden, verwenden oder lagern, da dies Verbrennungen oder Risse verursachen kann
Ziehen oder entfernen Sie das Oberflächensilikon nicht gewaltsam, um Beschädigungen oder Austausch des Produkts zu vermeiden
Biegen Sie das angeschlossene USB-Ladekabel nicht übermäßig und wickeln Sie das Ladekabel nicht zur Aufbewahrung um das Produkt, da dies das Ladekabel beschädigen könnte.
Verwenden Sie das angeschlossene USB-Ladekabel nicht, wenn es beschädigt ist, da es Stromschlag, Kurzschluss oder Feuer verursachen kann.
Bitte teilen Sie dieses Produkt nicht mit mehreren Personen, um die Verbreitung sexuell übertragbarer Krankheiten zu vermeiden.