Professionally Test And Recommend Each Toy For You!

1 * WARRANTY & AUTHENTICATION
2 * BRAND STORY
3 * AFTER SALES SERVICE
4 * HOW TO USE

User Manual
Please for unique product
Please read and keep the user manual carefully

WARRANTY & AUTHENTICATION

Vitally, Act Now!

The default warranty period for the product is 12 months.
Scan the QR code below to

Extend the warranty period to 2 years

Verify the authenticity of the product

Get exclusive Promos & Giveaways

www.utimi.com

* Or visit the "Warranty" menu on the official website to complete your product registration.

* Note: Warranty service is valid only under normal use of the product.

BRAND STORY

UTIMI

Professional testing and recommendation of each toy

All self-developed products are selected through online screening. Also, tested and recommended by professional players, and judged by the platform as excellent products before they hit the shelves.
Choose Utimi, no longer bad mood by buying inferior products.

Evolution
In 2014, UTIMI was founded.
In 2016, UTIMI become the largest seller in the Sexual Wellness category on Amazon.
In 2018, UTIMI has 100+ patents for adult products.

Over the years, we found a large number of problems with adult products such as short life span, poor use, no privacy packaging, and use of materials that are harmful to the body. To solve these problems, we carried out a comprehensive strategic upgrade and determined to allow users to easily find the right and reassuring products.

Pleasure Products
Utimi provides high-quality, safe, creative, effective, cost-effective" erotic products, as well as one-on-one expert customer service.

Each product is selected and developed from the real needs of users, careful analysis and research on the pain points of similar products. We focus on product rationality and how to use it longer and safer.
Each product is tested by professional players around the world, and receives their unanimous recommendation, and then is judged by the platform to be excellent before it goes on sale.
For each order, we invite users to participate in a satisfaction survey. The number of participants reaches more than 50. Products with a rating or a recommendation ratio repeatedly lower than 4.3 or 80% will be permanently banned from sale. It's our priority to collect users' experience.

Interactions
Freedom, equality, respect, sharing, tolerance!
Sex is a fundamental human need, one that transcends gender, age, color, class, and culture, shameless and unyielding one with no obscurity and no relocation, a spiritual life that humans enjoy equally!
Utimi unites a group of certified professional sex educators, sexology experts, sex toy connoisseurs, and also brings together a group of men and women, LGBTQ, SM players who seek excitement and love to explore and share. You can easily communicate and share with us, and together we can create a very inclusive spiritual paradise.

OUR SLOGAN:

Professionally Test And Recommend Each Toy For You!

AFTER-SALES SERVICE

If you are not satisfied with the product please contact us first, we will try our best to solve your problem as soon as possible.

Other questions, such as: warranty and authentication, instructions for use, product advice, product representation, etc.

Please contact us through the following ways.

support@utimi.com
+1-4241134100
(GMT+8, 09:00 am –06:00 pm Workday)
https://www.facebook.com/Utimitoys
+1-4241134100
https://www.utimi.com/

support@utimi.com
+1-4241134100
(GMT+8, 9:00 am –06:00 pm Workday)
https://www.facebook.com/Utimitoys
+1-4241134100
https://www.utimi.com/

FCC Warning Statement
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.
FCC Radiation Exposure Statement
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2)This device must accept any interference received, including interference that may cause undesired operation.

EN EN

SPECIFICATION

Material: silicone + ABS
Main body size and plug: 70.5*70.5*155.5mm
Remote control: 16.3*34*67.5mm
Weight: 182g
Maximum noise: < 60db
Waterproof rating: IPx6
Function: remote control+ Inflatable+vibration
Accessories list:
1pcs*product
1pcs*manual
1pcs*charging cable
1pcs*remote control
1pcs*storage bag

EN EN

INSTRUCTIONS

Charging time: about 2H
Discharging time: 1.5H
Charging display: blinking
Fully charged display: long-on
Power on: light on
Insufficient power: light flashing
Waterproof rating: IPX6
Working voltage: 3.3-4.2V
Working Current: 450mA
Static current: 0.32μA
Charging Voltage: 5V
Charging Current: 450mA
Waterproof rating: IPX6
Noise Level: 56DB
Battery Capacity: 450mAhr

EN EN

OPERATION BUTTONS

Switch key:
long press 3 seconds standby light on. Short press to start vibration, then short press to change frequency, 10 frequency cycle. Each time the frequency changes light flashes a link. Long light. Long press 2 seconds to switch off the machine, at the same time separate the deflation action. Inflated, when the battery is almost dead, it will automatically deflate and switch off.

Inflate button:
long press to inflate, hand press to inflate, the light is on, do not press to not inflate, complete inflate 45 seconds full and prompt again, the light has been blinking, prompting can not inflate again. Max mom inflatable size is 78*55mm.

Deflate button:
short press to deflate for 11 seconds, can not be inflated within 11 seconds, the light is on for 11 seconds and then off, deflation is complete.

EN EN

OPERATION BUTTONS

Manual valve:
manually press to deflate. There is no relationship between deflation and battery, battery valve, and PCB here. If the battery valve is disconnected and not to be deflated, manually press it to deflate.

Remote control keys
Inflate key: long press to inflate, cumulative 45 seconds, hand press. Light on, hand release light off.
Deflate button: short press to deflate, deflate for 11 seconds, light flashes. Deflate complete.
Vibration: short press the motor to move and frequency conversion (10 frequency vibration cycle), each time the frequency conversion light flashes off. long press the motor of No deflation, Short press and can open.

Note that the deflation can not operate other functions need to complete the deflation before switching to operate!

EN EN

HOW TO USE

1. Before use: please fully charge the product with the USB charging cable and sterilize the product before you start using it.

2. When using: When using the product, it is recommended to use it together with condom lubricant in order to get the best user experience.

3. After use: After use, rinse with warm water and gently pat dry with a dry towel or wipe them with a towel until dry. If there is lubricant or dirt on the product, clean the product with mild soap or a neutral stain remover.

4. Preservation: If left unused, the product should be kept in a dry and ventilated place, out of direct sunlight and away from the reach of children.

EN EN

ATTENTION

Make sure the USB port of your PC is connected to the product before connecting. Fully charge the product before using it for the first time or before leaving it unused for an extended period of time. To ensure the quality of the battery, please fully charge it at least once every six months. Do not use a USB charging cable that is not included. The included USB charging cable is not waterproof. Please be careful not to put it into the water to avoid other accidents such as electric shock or burns!

The product body is waterproof and can be rinsed underwater.

Do not rinse with hot water or boil. Do not clean with solvents such as benzene, alcohol, etc. to avoid deformation and discoloration of the product.

⚠ It is strictly prohibited to immerse the product in water when charging to avoid electric shock, short circuit, fire, and other accidents.

⚠ Do not store the product in places exposed to sunlight, high temperature, or high humidity. This may cause discoloration, breakage, heating, or even fire.

EN EN

FAULT RESOLUTION

The product is not working properly / the telescoping or rotating function is weak.
Did you hold down the power for 2~3 seconds after pressing the power button?
Is the fully charged?
Please release the power until the product does not turn on, then fully charge it. If it does not work after several attempts, the battery may be damaged.

The product cannot be charged. (The indicator light is not lighting)
Is the charging cable disconnected from the adapter or charging port?
When using your computer's USB port, the product will not charge if your computer is in standby mode. Please check if your computer is in standby mode.
There may be dust and stains on the charging port when charging again, please wipe it with a dry cloth or cotton swabs
Is the product fully charged? When the product is fully charged, the indicator light will stay on.

EN EN

FAULT RESOLUTION

Charging will not be completed. (The indicator light does not go out)
Dust and stains may be adsorbed to the charging port. Please wipe them with a dry cloth or cotton swab first, and then charge them before
If the indicator light is still on after 180 minutes of charging, it may be due to poor contact with the charging contacts.

EN

SAFETY & WARNING

If you are using a medical device/receiving treatment/pregnant, consult your doctor before use.
If you feel any discomfort while using it, stop using it and consult your doctor or pharmacist
When you find that the product is working abnormally, please stop using it and switch off the power immediately to avoid injury or accident.
Keep it out of reach of children to prevent them from accidentally swallowing product parts or accessories
Please use the provided USB charging cable to charge and connect it correctly otherwise it may overheat or burn out.
To avoid electric shock or burns, please keep your hands dry when unplugging the charging cable.
When unplugging the supplied USB charging cable, please hold the connection part and do not stretch the cable, otherwise, it may accelerate the deterioration of the cable and lead to an electric shock short circuit or even fire.
Unplug the USB charging cable when it is not needed for charging, otherwise it may be short-circuited due to dust and moisture, and lead to electric leakage or fire accidents.
Please clean the USB charging cable connector regularly to avoid dust causing short circuits or fire.
Do not share this product with more than one person to avoid spreading sexually transmitted diseases.

DE DE

SPEZIFIKATION

Material: Silikon + ABS
Hauptkörpergröße: Anschluss 70.5*70.5*155.5mm
Fernbedienung: 16.3*34*67.5mm
Gewicht: 182g
Maximaler Lärm: < 60db
Wasserdichtigkeit: ipx6
Funktion: Fernbedienung+Aufblasbar+Vibration
Zubehör Liste:
1Stück*Produkt
1Stück*Handbuch
1Stück*Ladekabel
1Stück*Fernbedienung
1+1Stück*Aufbewahrungstasche

DE DE

ANWEISUNGEN

Aufladezeit: etwa 2 Stunden
Entladezeit: 1,5 Stunden
Ladeanzeige: blinkend
Anzeige bei voller Ladung: langanhaltend
Strom an: Licht an
Unzureichende Leistung: Licht blinkt
Wasserdichte Bewertung: IPX6
Betriebsspannung: 3.3-4.2V
Arbeitsstrom: 450mA
Statischer Strom: 0.32μA
Ladespannung: 5V
Ladestrom: 450mA
Wasserdichte Bewertung: IPX6
Geräuschpegel: 56DB
Batteriekapazität: 450mAh

DE DE

TASTEN ZUR BEDIENUNG

Jedes Mal, wenn die Frequenz ändert, Licht leicht ein-wenig. Lange leicht. 2 Sekunden lang drücken, um das Gerät auszuschalten, gleichzeitig wird die Trennung durchgeführt. Aufgeblasen, wenn die Batterie fast leer ist, wird es automatisch entleert und ausschalten.

Aufblasen+Taste:
Lange drücken, um zu aufblasen, Hand drücken um zu aufblasen, das Licht bleibt, nicht drücken, um nicht aufzublasen, kann daher aufblasbare 45 Sekunden, vollend drücken Sie erneut, das Licht wird blinken, Aufblasung kann nicht wieder aufblasen. Maximale aufblasbare Größe ist 78*55mm.

Entlüftungstaste:
Kurz drücken, um die Luft für 11 Sekunden abzulassen, kann nicht innerhalb von 11 Sekunden aufgeblasen werden, das Licht bleibt für 11 Sekunden und dann aus, die Entlüftung ist abgeschlossen.

DE DE

TASTEN ZUR BEDIENUNG

Manuelles Ventil:
manuelles Drücken zum Ablassen der Luft, Es besteht kein Zusammenhang zwischen dem Ablassen der Luft und der Batterie, dem Batterieventil und der Leiterplatte. Wenn das Batterieventil abgetrennt ist und nicht entfernt werden kann, drücken Sie es manuell, um die Luft abzulassen.

Taste zum Aufblasen:
lange drücken zum Aufblasen, kurz drücken 45 Sekunden, Handaufblasen, das Licht bleibt, wenn nicht aufgeblasen, erneut drücken Sie es, wenn es nicht aufgeblasen ist, Die Luft wird abgelassen.

Taste zum Aufblasen:
lange drücken zum Aufblasen, kurz drücken 45 Sekunden, Handaufblasen, das Licht bleibt, wenn nicht aufgeblasen, erneut drücken Sie es, wenn es nicht aufgeblasen ist, Die Luft wird abgelassen.

Vibration: Motor kurz drücken, um sich zu bewegen und Frequenzumwandlung (10 Vibrationszyklen), jedes Mal, wenn die Frequenzumwandlung abgeschaltet, Motor lang drücken. Keine Entlüftung. Kurz drücken und Tür öffnen.

Berühren Sie, dass die Entlüftung kann nicht betrieben werden, andere Funktionen müssen die Entlüftung vor dem Betrieb weiter zu verwalten beenden!

DE DE

WIE ZU VERWENDEN

1. Vor dem Gebrauch: Bitte laden Sie das Produkt mit dem USB-Ladekabel vollständig auf und sterilisieren Sie das Produkt, bevor Sie es verwenden.

2. Bei der Verwendung: Wenn Sie das Produkt verwenden, wird empfohlen, es zusammen mit Kondom-Gleitmittel zu verwenden, um die beste Benutzererfahrung zu erhalten.

3. Nach dem Gebrauch: Nach dem Gebrauch mit warmem Wasser abspülen und mit einem trockenen, fusselfreien Leinentuch oder Handtuch vorsichtig trocken tupfen. Wenn sich Gleitmittel oder Schmutz auf dem Produkt befindet, reinigen Sie es mit milder Seife oder einem neutralen Fleckenentferner.

4. Aufbewahrung: Wenn das Produkt nicht benutzt wird, sollte es an einem trockenen und belüfteten Ort aufbewahrt werden, ohne direkte Sonneneinstrahlung und außerhalb der Reichweite von Kindern.

DE DE

AUFMERKSAMKEIT

Vergewissern Sie sich vor dem Anschließen, dass der USB-Anschluss Ihres PCs mit dem Produkt verbunden ist. Laden Sie das Produkt vollständig auf, bevor Sie es zum ersten Mal benutzen oder bevor Sie es für längere Zeit unbenutzt lassen. Um die Qualität des Akkus zu gewährleisten, laden Sie ihn bei mindestens einmal alle sechs Monaten vollständig auf. Verwenden Sie kein USB-Ladekabel, das nicht im Lieferumfang enthalten ist. Das mitgelieferte USB-Ladekabel ist nicht wasserdicht. Bitte achten Sie darauf, es nicht ins Wasser zu ziehen, um andere Unfälle wie Stromschläge oder Verbrennungen zu vermeiden!

Das Produktgehäuse ist wasserdicht und kann unter Wasser abgespült werden.

Spülen Sie es nicht mit heißem Wasser ab und kochen Sie es nicht. Reinigen Sie es nicht mit Lösungsmitteln wie Benzol, Alkohol usw., um Verformungen und Verfärbungen des Produkts zu vermeiden.

⚠ Es ist strengstens untersagt, das Produkt beim Aufladen in Wasser zu tauchen, um Stromschläge, Kurzschlüsse, Feuer und andere Unfälle zu vermeiden.

⚠ Bewahren Sie das Produkt nicht an Orten auf, die dem Sonnenlicht, hohen Temperaturen oder hoher Luftfeuchtigkeit ausgesetzt sind. Dies kann zu Verfärbungen, Brüchen, Erhitzung oder sogar Bränden führen.

DE DE

STÖRUNGSBESEITIGUNG

Das Produkt funktioniert nicht richtig / die Teleskop- oder Drehfunktion ist schwach
Haben Sie die Taste 2~3 Sekunden nach dem Drücken der Einschalttaste für 2~3 Sekunden eingedrückt?
Ist es vollständig aufgeladen?
Bitte lassen Sie den Strom los, bis sich das Produkt nicht mehr einschaltet, und lassen Sie es dann vollständig auf. Wenn es nach mehreren Versuchen nicht funktioniert, ist der Akku möglicherweise beschädigt.

Das Gerät kann nicht aufgeladen werden. (Die Anzeigeleuchte ist ausgeschaltet)
Ist das Ladekabel locker mit dem Adapter oder dem Ladeanschluss verbunden?
Wenn Sie den USB-Anschluss Ihres Computers verwenden, wird das Produkt nicht aufgeladen, wenn sich Ihr Computer im Standby-Modus befindet. Bitte überprüfen Sie, ob sich Ihr Computer im Standby-Modus befindet.
Beim erneuten Aufladen können sich Staub und Flecken auf dem Ladeanschluss befinden, bitte wischen Sie sie mit einem trockenen Tuch oder Wattestäbchen ab.
Ist das Produkt vollständig aufgeladen? Wenn das Produkt vollständig aufgeladen ist, leuchtet die Kontrollleuchte weiter.

DE DE

STÖRUNGSBESEITIGUNG

Der Ladevorgang ist noch nicht abgeschlossen. (Die Kontrollleuchte geht nicht aus)
An der Ladebuchse können sich Staub und Flecken ansammeln. Bitte wischen Sie diese zunächst mit einem trockenen Tuch oder Wattestäbchen ab und laden Sie das Gerät dann auf.
Wenn die Kontrollleuchte nach 180 Minuten Ladezeit immer noch leuchtet, kann es an einem schlechten Kontakt mit den Ladekontaktenliegen.

DE

BEDIENUNGSANLEITUNG

Wenn Sie ein medizinisches Gerät verwenden, in Behandlung sind oder schwanger sind, fragen Sie vor der Anwendung Ihren Arzt.
Wenn Sie während der Anwendung Unbehagen empfinden, beenden Sie die Anwendung und wenden Sie sich an Ihren Arzt oder Apotheker.
Wenn Sie feststellen, dass das Gerät nicht ordnungsgemäß funktioniert, schalten Sie es bitte sofort aus, um Verletzungen oder Unfälle zu vermeiden.
Bewahren Sie das Gerät außerhalb der Reichweite von Kindern auf, um zu verhindern, dass diese versehentlich Produktteile oder Zubehör verschlucken.
Bitte verwenden Sie zum Aufladen das mitgelieferte USB-Ladekabel und ansonsten Sie es richtig an, ansonsten überhitzen oder durchbrennen kann.
Um einen elektrischen Schlag oder Verbrennungen zu vermeiden, halten Sie Ihre Hände bitte trocken, wenn Sie das Ladekabel abziehen.
Wenn Sie das mitgelieferte USB-Ladekabel trennen, halten Sie bitte den Anschluss fest und dehnen Sie das Kabel nicht. Andernfalls kann das den Verschleiß des Kabels beschleunigen und zu einem Stromschlag, Kurzschluss oder sogar zu einem Brand führen.
Ziehen Sie den Stecker des USB-Ladekabels ab, wenn es nicht zum Laden benötigt wird. Andernfalls kann es aufgrund von Staub und Feuchtigkeit zu einem Kurzschluss kommen, der zu einem elektrischen Lock oder einem Brand führen kann.
Bitte reinigen Sie den Stecker des USB-Ladekabels regelmäßig, um zu vermeiden, dass Staub Kurzschlüsse oder Feuer verursacht.
Teilen Sie dieses Produkt nicht mit mehr als einer Person, um die Verbreitung von sexuell übertragbaren Krankheiten zu vermeiden.