单页尺寸：105x74.25mm

DUPWAY
USER MANUAL



① Bone conduction speaker
② Microphone
③ Volume + button
④ Switch button
⑤ Volume - button
⑥ Charging and data transfer interface
⑦ Indicator light
⑧ Titanium ear hook

Charging
·When the headphones low battery, the indicator light red flashing, and voice prompts, please use the charging cable to charge the headphones, when the headphones power is too low, the headphones will automatically shut down.
·After completing charging with the included USB magnetic charging cable, the indicator light from red light is always on, to blue light is always on.

First time to use the headphones
·Headphones in the off state, long press the switch button for 2 seconds, and a tone "dengdeng dududu". Indicator red light blue light alternately flashing, the headphones default into the Bluetooth pairing mode. In the Bluetooth settings of cell phones or computers and other devices, search, find the headphones icon DUPWAY Bone, click, connect successfully, and there is a beep "dudu".
·The headphones has been paired successfully, the second time the headphones is turned on, it will automatically connect to the paired cell phone or computer and other devices Bluetooth.
If you find that the headphones can not search, please confirm whether the headphones has been connected to other devices, you need to disconnect the headphones from other devices.
·Power on state, long press the switch button, 4 seconds, the light goes off, the headphones shutdown, and a tone "dengdeng".
·When the headphones is connected to the cell phone and other devices, beyond the Bluetooth connection distance, the headphones will beep, the headphones and cell phone will be disconnected.
·180 seconds, back within the Bluetooth connection distance, the headphones and cell phone will automatically resume connection.
·If no connection with cell phones and other devices within 300 seconds, the headphones will automatically shut down.

MP3 player mode
·Power on, double-click the switch button, headphones switch to MP3 player mode, there is a beep "du". Double-click the switch button again, the headphones switch to Bluetooth mode, there is a tone "dududu".

Connect with computer
·Use the included USB magnetic charging cable, magnetic interface connected to the headphones, USB interface connected to the computer.
The computer will prompt out a USB flash drive, at this time you can copy MP3 songs to the headphones internal storage, or copy other files data when the USB flash drive use.

Button Operation
Switch button:
·When a call comes in, short press the switch button to answer the call; long press the switch button key for 2 seconds to reject the call.
·When talking, short press the switch button to hang up the phone.
·When playing music, short press the switch button to pause the music, short press the switch button again to resume the music.
Volume+ button:
·When talking or playing music, short press the Volume+ button to increase the volume.
·When playing music, press and hold the Volume+ button for 2 seconds to switch to the next song.
Volume- button:
·While talking or playing music, press the Volume - button briefly to reduce the volume.
·When playing music, press and hold the Volume - button for 2 seconds to switch to the previous song.

Device name: DUPWAY Bone
Bluetooth version: 5.3
Model: A211
Size: 135×105×48mm
Weight: 25g
Battery: Play Built-in music for about 12 hours
Battery: Play Bluetooth music about 6 hours
Charging: about 2 hours
Waterproof: IP67
Bluetooth distance: 10m
Input: 5V⎓150mA

Accessory list:
Earphone x1, USB magnetic charging cable x1,
Soundproof sponge earbuds x1,Swimming waterproof earbuds x1,
Manual x1
Trademark: DUPWAY
Website: www.dupway.com

Warning:
Charging with 5V DC charging adapter, too high a voltage on the headphones charging may cause damage!
This headphones can not swim to wear!

DUPWAY
ユーザーマニュアル



① 骨伝導スピーカー
② マイクロホン
③ 音量＋ボタン
④ スイッチボタン
⑤ 音量－ボタン
⑥ 充電・データ転送インターフェース
⑦ インジケーターライト
⑧ チタン製イヤーフック

充電
·ヘッドセットの電池残量が少なくなると、インジケータライトの赤色が点滅し、音声案内が表示されますが、充電ケーブルを使用してヘッドセットを充電してください。
·付属の USB 磁気充電ケーブルで充電を完了すると、インジケータ ライトが赤色光から青色光に常に点灯しています。

ヘッドセットを初めて使用する場合
·ヘッドセットがオフの状態で、スイッチボタンを 2 秒間長押しすると、「dengdeng dududu」という音がします。インジケータ赤色光青色光が交互に点滅し、ヘッドセットのデフォルトは、Bluetoothペアリングモードになります。携帯電話やコンピューク、その他のデバイスのBluetooth設定で、検索、ヘッドセットのアイコンDUPWAYボーンを見つけ、クリックし、正常に接続し、ビープ音がある "dudu"。
·ヘッドセットは正常にペアリングされ、2回目にヘッドセットをオンにすると、自動的にペアリングされた携帯電話またはコンピュータおよび他のデバイスのBluetoothに接続されます。
ヘッドセットが検索できない場合は、ヘッドセットが他のデバイスに接続されているかどうかを確認してください、あなたは他のデバイスからヘッドセットを切断する必要があります。
·電源オン状態、スイッチボタンを長押し、4秒、ライトが消灯し、ヘッドセットのシャットダウン、およびトーン "dengdeng」。
·ヘッドセットは、携帯電話や他のデバイスに接続されている場合、Bluetooth接続距離を越えて、ヘッドセットはビープ音、ヘッドセットと携帯電話が切断されます。
·180秒後、Bluetooth接続距離内に戻ると、ヘッドセットと携帯電話は自動的に接続を再開します。
·300秒以内に携帯電話や他のデバイスとの接続がない場合、ヘッドセットは自動的にシャットダウンします。

MP3 プレーヤーモード
·電源を入れ、スイッチボタンをダブルクリックし、ヘッドセットをMP3プレーヤーモードに切り替えると、「du」というビープ音が鳴ります。
スイッチボタンをもう一度ダブルクリックすると、ヘッドセットはBluetoothモードに切り替わり、"dududu"という音が鳴ります。

コンピュータと接続する
·付属のUSB磁気充電ケーブルを使用して、磁気インターフェイスをヘッドセットに接続し、USBインターフェイスをコンピュータに接続します。コンピュータは、USBフラッシュドライブ、この時点で、ヘッドセットの内部ストレージにMP3曲をコピーしたり、USBフラッシュドライブの使用時に他のファイルデータをコピーすることができますプロンプトが表示されます。

ボタン操作
スイッチボタン:
·電話がかかってきたら、スイッチボタンを短く押すと電話に出ることができ、スイッチボタンキーを2秒間長く押すと電話を拒否することができます。
·通話中、スイッチボタンを短く押すと電話を切ります。
·音楽を再生するときは、スイッチボタンを短く押すと音楽が一時停止し、スイッチボタンをもう一度短く押すと音楽が再開します。
ボリューム＋ボタン:
·通話中または音楽再生中に音量＋ボタンを短く押すと、音量が大きくなります。
·音楽再生中にボリューム+ボタンを2秒間長押しすると、次の曲に切り替わります。
ボリューム - ボタン:
·通話中または音楽再生中に音量-ボタンを短く押すと、音量が小さくなります。
·音楽再生中にボリューム-ボタンを2秒間長押しすると、前の曲に切り替わります。

デバイス名：DUPWAY Bone
Bluetoothバージョン：5.3
モデル：A211
サイズ：135×105×48mm
重量：25g
バッテリー 内蔵音楽を約12時間再生
バッテリー Bluetooth音楽再生 約6時間
充電：約2時間
防水性：IP67準拠
Bluetooth距離：10m
入力：5V⎓150mA

付属品リスト:
イヤホン×1、USB磁気充電ケーブル×1、防音スポンジイヤホン×1、水泳用防水イヤホン×1、マニュアル×1

商標について：DUPWAY
ウェブサイト：www.dupway.com

警告:
DC5Vの充電アダプターで充電する場合、ヘッドセットの充電電圧が高すぎると、破損の原因になることがあります！
このヘッドセットは、着用するために泳ぐことはできません！

DUPWAY
用户手册



① 骨传导喇叭
② 麦克风
③ 音量+按键
④ 开关按键
⑤ 音量-按键
⑥ 充电及数据传输接口
⑦ 指示灯
⑧ 钛合金耳挂

充电使用
·当耳机低电量时，指示灯红光闪烁，并有语音提示，请使用充电线对耳机进行充电，当耳机电量过低时，耳机会自动关机。

·用附带USB磁吸充电线完成充电后，指示灯从红光常亮，变成蓝光常亮。

首次开机使用耳机
·耳机在关机状态下，长按开关按键2秒，并有提示音"dengdeng dududu"。指示灯红光蓝光交替闪烁，耳机默认进入蓝牙配对模式。
在手机或电脑等设备蓝牙设置里，搜索，发现 耳机图标 DUPWAY Bone，点击，连接成功，并有提示音"dudu"。

·已配对成功的耳机，第二次耳机开机，会自动连接已配对手机或电脑等设备蓝牙。
若发现搜索不到耳机，请确认耳机是否已连接其他设备，需要断开耳机与其他设备的连接。

·开机状态下，长按开关按键,4秒，指示灯熄灭，耳机关机，并有提示音"dengdeng"。

·当耳机与手机等设备连接，超出蓝牙连接距离，耳机会有提示音，耳机与手机将断开连接。

·180秒内，回到蓝牙连接距离以内，耳机与手机会自动恢复连接。

·若300秒内没有与手机等设备连接，耳机会自动关机。

MP3播放器模式
·开机状态下，双击开关按键，耳机切换到MP3播放器模式，有提示音"du"。再次双击开关按键，耳机切换蓝牙模式，有提示音"dududu"。

与电脑连接
·利用附带USB磁吸充电线，磁吸接口连接耳机，USB接口连接电脑。
电脑会提示出一个U盘，此时可以将MP3歌曲拷贝到耳机内部存储里，或者拷贝其他文件数据当U盘使用。

按键操作
开关按键:
·来电时，短按开关按键，接听电话；长按开关按键键2秒，拒接电话。
·通话时，短按开关按键，挂断电话。
·播放音乐时，短按开关按键，音乐暂停播放，再次短按开关按键，音乐继续播放。
音量+按键:
·通话时或播放音乐时，短按音量+按键，加大音量。
·播放音乐时，长按音量+按键2秒，切换下一首歌曲。
音量-按键:
·通话时或播放音乐时，短按音量-按键，减小音量。
·播放音乐时，长按音量-按键2秒，切换上一首歌曲。

设备名称：DUPWAY Bone
蓝牙版本：5.3
型号：A211
尺寸：138 x106 x 42mm
重量：25g
电池：播放内置音乐约12小时
电池：播放蓝牙音乐约6小时
充电：约2小时
防水：IP67
蓝牙距离：10米
输入：5V⎓150mA

配件清单:
耳机x1，USB磁吸充电线x1，隔音海绵耳塞x1，
游泳防水耳塞x1，说明书x1

商标：DUPWAY
网站：www.dupway.com

警告:
用5V直流充电适配器进行充电，过高电压对耳机充电可能造成损坏！
这款耳机不能游泳佩戴！

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- **Reorient or relocate the receiving antenna.**
- **Increase the separation between the equipment and receiver.**
- **Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- **Consult the dealer or an experienced radio/TV technician for help.**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.