宽130mm，高185mm

EVRAIN

Mini PC

T8 PRO

User Guide

Please read this user guide carefully before use retain for future reference

Specification of T8 pro

Hardware	LCD Display	8 inch 800×1280 IPS
	Touch Screen	5 point capacitive G+G
	CPU	Intel Alder Lake N95 Quad Core 3.4 GHz
	RAM	SO-DIMM DDR4 8G/16G
	Storage	PCIE M.2 / 128G/256G/512G
		SATA / HDD
	WiFi	WiFi 5/6E Optional
	BlueTooth	BT V5.0/5.3 Optional
	Speaker	BOX Speaker Optional
	MIC	Optional
	G-sensor	support
I/O Interface	Jack	3.5＋2.1/5mm
	Internet	RJ45 × 2 1000M
	USB-A	USB3.0 × 4 + USB2.0 × 2
	HDMI	HDMI × 1
	DP	DP × 1
	TYPE-C	TYPE-C × 1
	TF-Card	TF-Card × 1
OS	Operating System	Window 11
Power	Input	AC 100-240V
	Output	TYPEC PD 65W/DC 19V3A
Housing	Unit Size	211×129×89mm
	Material	Plastic
	Color	Black/Gray
	Net weight	680g

Product Illustration

① Power button (on/off)
② TF card port
③ USB 2.0 port
④ USB 3.0 port
⑤ Type-C full function
⑥ Earphone Jack 3.5mm
⑦ DC port(19V/3A)
⑧ HDMI port
⑨ DP port
⑩ USB 3.0 port
⑪ Gigabit LAN port
⑫ Gigabit LAN port

Additional description of internal interfaces



HDD Hard Disk Expansion Interface

Network connection

Connection with multiple devices

Touch Screen Operation

Special Function

Double Gigabit LAN port Design

Perform the following steps before using.

① Check that the package is intact, Disassemble and inspect accessories.
② Check the completeness of packing accessories
③ Understanding product Interface
④ Connect the power and start using

Procedurefor use

① Connecting the adaptor to the DC port
② The power indicator will show red
③ Press the power button
④ The power indicator will show green
⑤ The mini pc is starting up

Mini PC Pre-installed Windows 11 pro OS, Just follow the system prompts

EVRAIN

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.