55mm

80mm

TWS新版本说明书

一.TWS操作说明

开机

出仓自动开机
关机状态:长按3秒触摸区域手动开机

关机

入仓自动关机并充电
开机状态:长按5秒触摸区域手动关机,手动关机任意边耳机,另一边会同步关机.

耳机配对

开机自动配对

连接设备

手机打开蓝牙搜索设备名连接即可使用.
(超过3分钟无连接耳机会自动关机)

操作控制 (左右耳均可)

播放/暂停/接听电话/挂断电话----单击触摸区域
切换下一曲----双击触摸区域
切换上一曲----三击触摸区域
拒绝来电----长按2秒触摸区域

安全事项

为正确而安全地使用本耳机,请在使用前详细阅读本说明书,并保存好。

使用耳机时应注意下列事项

1.请合理控制使用耳机时的音量和时间。
2.请勿在潜在危险环境中使用耳机，以确保安全。
3.尽量避免在驾驶途中使用耳机聆听音乐，拨打或接听电话，分散注意力 造成危险。
4.请将耳机置于儿童无法接触到的地方,避免儿童使用不当造成危险。
5.在梳洗时应避免耳机进水,以免损害耳机音质或耳机。
6.应尽量避免持续调高音量,导致你听不到四周的声音，如出现耳鸣或将音量调得过高,请调到合适音量
7.如使用耳机时感到明显不适，有刺激感或其他不良反应,请立刻停止使用。
8.避免将耳机储存或使用于温度低于-15°C (5 F)或高于55°C (131 F)的环境，否则或会缩短耳机或电池寿命。

警告

1.必须使用配套的充电线给耳机充电，使用不配套的充电线缆可能会损坏耳机，并且DC电压必须5V，电流大于100mA (5V/100mA)。
2.本耳机使用内置式不可拆卸充电电池。勿尝试从耳机中取出电池，以免损坏耳机。

保修卡

用户信息	用户姓名		联系电话	
	邮　　箱		邮　　编	
	通讯地址			
销售信息	商家名称			
	联系地址			
	联系电话		邮　　编	
	生产日期		销售日期	
	销售商盖章			

(维修机构填写)

维修次数	维修单位名称	维修原因	维修时间
第一次			
第二次			
第三次			
第四次			

WIRELESS EARBUDS MANUAL

A. TWS operating instructions

Boot up FCC ID:2BCQN-SMS-T23

Automatically turn on when exiting the warehouse;
Power off state: press and hold the touch area for 3 seconds to manually power on

Shut down

Automatically shut down and charge after entering the warehouse;
Power-on state: Press and hold the touch area for 5 seconds to manually power off, manually power off either side of the headset, and the other side will turn off synchronously.

Earbuds pairing

Automatic pairing at boot

Connect digital equipment

You can use the mobile phone to turn on the Bluetooth to search for the device name to connect. (The headset will automatically shut down if it is not connected for more than 3 minutes)

Operation control (both left and right ears)

Play/pause/answer/end call----click on the touch area
Switch to the next song----double-click the touch area
Switch to the previous song----three-click the touch area
Voice assistant----long press the touch area for 2 seconds
Reject the call----long press the touch area for 2 seconds

Safety Precautions

To use this headset correctly and safely, please read this manual carefully before use and save it.

Precautions

1. Please control the volume and time when using the headphones.
2. Do not use the headset in a potentially hazardous environment to ensure safety.
3. Try to avoid using headphones to listen to music while driving, making or receiving calls, distracting and posing a danger.
4. Keep the headphones out of reach of children to avoid danger from improper use.
5. Avoid cleaning the headphones when washing, so as not to damage the sound quality of the headphones or headphones.
6. Try to avoid continuously increasing the volume, so that you can't hear the surrounding sound. If you have tinnitus or turn the volume too high, please adjust to the appropriate volume.
7. If you feel obvious discomfort when using headphones, have a irritating feeling or other adverse reactions, please stop the month immediately.
8. Avoid storing or using the headset in an environment where the temperature is below -15 ° C (5 F) or above 55 ° C (131 F), otherwise the headset or battery life may be shortened.

Warning

1. The headset must be charged with the matching charging cable. Using an unsuitable charging cable may damage the headset, and the DC voltage must be 5V and the current is greater than 100mA (5V/100mA).
2. This headset uses a built-in non-removable rechargeable battery. Do not attempt to remove the battery from the headphones to avoid damaging the headphones.

WARRANTY CARD

User Info	Name		Contact number	
	Mail		Zip code	
	Address			
Sales information	The shop's name			
	Address			
	Contact number		Zip code	
	Production Date		Sales date	
	Seller stamp			

(Repair agency)

Number of repairs	Maintenance unit name	Maintenance reason	Repair time
first			
Second			
Third			
Fourth			

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement， the device can be used in portable exposure condition without restriction