OUTDOOR TECH.

CHIPS XV

WIRELESS HELMET AUDIO

Good call on picking up the Outdoor Tech® CHIPS® XV , universal wireless helmet audio. Your experience of the universe will soon be enhanced wirelessly. This manual exists to help make sure that you use them correctly, so you're definitely going to want to relax for a hot second and look through this manual.

Kisses,

OUTDOOR TECH.

WARNING: For safety reasons, some state and local laws prohibit the use of headsets when operating a bicycle. Use Chips® only for off-highway activities. Do not use Chips® at excessive volumes because it may cause permanent hearing damage.

ANATOMY

A. Left ear button
B. Right ear button
C. Charge port USB-C
D. LED light
E. Microphone

FUNCTIONS

RIGHT

FUNCTION	ACTION	VOICE PROMPT
POWER ON	LONG PRESS 4 SECONDS	"POWER ON"
PLAY	PRESS ONCE	
PAUSE	PRESS ONCE	
SKIP FORWARD	PRESS TWICE	
SKIP BACKWARD	PRESS THREE TIMES	
ANSWER CALL	PRESS ONCE	"ANSWER"
END CALL	PRESS ONCE	"CALL TERMINATED"
REJECT CALL	LONG PRESS 2 SECONDS	"REJECT"
SIRI SINGLE ASSISTANT	PRESS RIGHT + LEFT	"BEEP"
CLEAR MEMORY	LONG PRESS 8 SECONDS	

FUNCTIONS

LEFT

FUNCTION	ACTION	VOICE PROMPT
POWER OFF	LONG PRESS 4 SECONDS	"POWER OFF"
VOLUME UP	PRESS TWICE	"MAX VOLUME"
VOLUME DOWN	PRESS ONCE	
MIC MUTE	PRESS TWICE TIMES	
SIRI SINGLE ASSISTANT	PRESS RIGHT + LEFT	"BEEP"

POWER UP

Charge Time 45 minutes

For best results, fully charge your CHIPS® XV using the supplied USB C to USB C charging cable and power source.

The indicator light located on the right ear piece will flash red to indicate a low battery.

Once the Chips XV® are plugged into a power source, the indicator light will turn red. It will turn off once the CHIPS are completely charged.

NOTE: It only takes 45 minutes to give your CHIPS® XV a full charge.

PAIRING

RIGHT

1.From the OFF position press and hold until LED flashes red and blue alternately.
VOICE PROMPT: "power on+pairing"

Choose: "ODT Chips® XV " in your phone's Bluetooth settings.
VOICE PROMPT: "connected"
(If prompted by your device to connect, select "Yes". If prompted by your device enter password or use pairing code: 0000.)

TALK

The following are tips on how to use your CHIPS® to speak on the telephone:

Answer a call..... Press right ear button

End a call..... Press right ear button

Reject a call..... Press and hold the right ear button for two seconds

Make a call..... Use your phone to dial as usual. Listen & talk through the CHIPS®

Volume up..... Double press the left ear button

Volume down..... Press left ear button

Voice Activation..... Press and hold both left and right ear buttons simultaneously. Release and speak when you hear the voice prompt: "Beep".

Trutone APP

-Level up your sound game! Just head to the App Store if you're on iOS or the Android Store for Android devices and download the Trutone APP.

-Getting connected is a breeze! Turn on Bluetooth, pair with your device, fire up the APP, and follow the easy steps.

Sound Modes

-Default: Jam to your heart's content.
-Popular: Perfect for jamming to today's hits.
-Bass: Crank up those deep, thumping beats.
-Rock: Rock out to music that has energetic rock vibes.
-Gentle: Smooth, laid - back tones.
-Classical: Brings out the elegance of classical music.
-Custom: Tweak treble, mid, and bass, give it a cool name, and save it for later!

-Keep an eye on your battery level. And if your device ever goes MIA, use the map to track 'em down.

-Keep your APP and phone system updated. If you run into any snags, hit us up! Have a blast!

PUT THE CHIPS IN YOUR HELMET

1. Drop the CHIPS® XV into the slots inside your helmet liner.

2. Rock out, make calls, and, you know, ski and snowboard and whatnot.

SPECS

Battery life..... 15hours of play time

*Battery life varies subject to different playing circumstances, such as music type and volume.

Bluetooth version..... V5.3
Bluetooth profiles..... HFP1.8, HSP1.2, A2DP1.3, AVRCP1.6
Operating distance..... 33 feet, 10 meters
Charging input..... DC 5.0V, 1A
Dimensions..... 2" diameter, 0.5" thick
Weight..... 0.13 lbs (61.6g)
Battery capacity..... 250mAh

FAQ

Why is the red LED flashing twice every 20 seconds? The battery is low. Recharge it.

Why is the red LED off when charging?
A. Make sure the connection between the charging port and the charger is tight.
B. If the CHIPS®XV haven't been used in awhile, the light may not come on immediately. Charge the battery for at least 30 minutes.

Why can't I pair my CHIPS®XV ?
A. Your Bluetooth device and the CHIPS®XV must both be in pairing mode.
B. Your CHIPS®XV must not be paired to any other devices.

Why do I have Bluetooth signal loss/dropout/unclear conversations?
A. Make sure the phone closer to your CHIPS®XV .
B. Make sure your CHIPS®XV are charged up.
C. Turn off your CHIPS® XV and device, then power up and reconnect.

Why can't the CHIPS®XV hear my voice during a call?
A. Make sure the CHIPS®XV are on.
B. Make sure the volume is not too low or muted.
C. Make sure the CHIPS®XV are properly connected with your device.
D. Make sure the CHIPS®XV are within range of your device.

CARE & MAINTENANCE

-Keep the CHIPS®XV dry.
-Keep the CHIPS®XV away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
-Do not try to disassemble the CHIPS®XV .
-Do not drop the CHIPS®XV fall onto the floor or other hard surfaces. The internal circuit board may get damaged.
-Do not use intensive chemical products or detergent to clean the product.
-Do not scratch the surface with sharp things.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Manual de usuario en Español.
Manuel d'utilisation en Français.
Benutzerhandbuch auf Deutsch.
Manuale d'uso in Italiano.

By Outdoor Tech

K, Later gator.

DON'T BE SO ANTISOCIAL

Facebook.com/outdoortechnology
Twitter & Instagram: @outdoortech

Questions, comments, complaints, secret desires, or just to say what's up email info@outdoortech.com

K Bye.

www.outdoortech.com