Wireless keyboard user manual



Package included: Instruction manual*1 Wireless keyboard*1 USB charging cable*1

Specification

1. Frequency: 2.4GHz
2. Working voltage: 3.0v-4.2v
3. Working current: ≤5.5mA-11.5mA
4. Standby current: ≤0.25mA
5. Sleep current: < 6uA
6. Working distance: ≤ 8m
7. Lithium battery capacity: 400mAh

Indicator

1. Power indicator: Turn on the light for 3S blue light, then turn off
2. Pairing indicator light: The blue light flashes for 1 second for the pairing code, and the 180S is not paired and enters deep sleep
3. Charging indicator light: red light for charging, goes out when the battery is fully charged
4. Low voltage indicator: when the voltage is lower than 3.3v, the blue light flashes for 2 seconds, and the low 3.0v shuts down

Keyboard shortcut function description

	Back to Home page		Brightness –		Brightness +
	search		Screen keyboard		Lock screen
	Previous track		Pause/Play		Next track
	Select All		Shear		Volume–
	Copy		Paste		Volume+
Fn	Combination Key	Control + Space bar	Language switching	Fn+ Connect	Bluetooth pairing
	Backlight mode		RGB-Key		

Bluetooth keyboard connection

1.After turning the Bluetooth switch to the ON position, the power indicator light will stay on for 3 seconds, press FN + Connect at the same time, the Bluetooth indicator light will start to flash, and the Bluetooth keyboard will enter the pairing state.

2.Open and unlock your tablet and click on the "Settings" icon.



3.In the settings menu, click on the "Bluetooth" menu.

4.Turn on the Bluetooth switch and the tablet will automatically search for Bluetooth keyboard decices.

5.Discover the Bluetooth keyboard device: Bluetooth Keyboard, and clicky on it, the Bluetooth keyboard will automatically connect.

6.After the Bluetooth connection is successful, the pairing indicator is off, and "Connected" will appear in the list of Bluetooth devices.

Attention

1.When not use for long time, suggest to close keyboard, in order to prolong battery lift.
2.In order to obtain longer battery life, the charging time must be more than 2 hours before charging when the low voltage indicator of the keyboard flashes.

Energy saving sleep mode

When the keyboard is not in use, it will enter the sleep state after 10 minutes, and the keyboard indicator will be off. When it is used again, press any key to wake up, and the keyboard indicator will be on.

Troubleshooting

1.Make sure the power is turned on
2.Ensure keyboard operable distance
3.Make sure the battery has power
4.Ensure the device' s Bluetooth was turned on
5.Ensure the wireless keyboard was connected with the Bluetooth
6.Ensure the wireless keyboard paired successfully

Cleaning

Washing, alcohol or a similar cheaning agent decontamination keyboard.

Charging

When the blue light of the power indicator flashes slowly, it means that the power of the keyboard is low and needs to be charged
1. Use the Type-c data cable to connect the charging port to charge the keyboard.
2. When charging, the charging indicator light turns red, and the red light turns off when fully charged.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement， the device can be used in portable exposure condition without restriction