Portable HD Projector

User Manual

Models: HI 6

This device complies with Part 15 of the Fcc Rules.
Operation is subject to the following two conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, Including interference that may cause undesired operation.

MADE IN CHINA

Contents

Important Notice 1
Package Contents 2
Feature Description 3
Input Connections 5
Using Features 6
Projector Connection 10
Projection Distance and Size 10
Specifications 11
Caution 12
Troubleshooting Guide 13

Important Notice

Installation
- For optimal performance,use this device in a dimly lit room or with The curtains drawn.
- Handle the device with care;dropping or bumping it may damage parts Or cause blurry images or display malfunctions.

Power Supply
- Turn off the device after four continuous hour of operation,and dis- Connect the power for 30 minutes before restarting.
- Use the specified power source or adapter only;contact your supplier For replacements if,needed.
  After use,when unplug the power cord from the electrical outlet.

Water Resistance
  This product is not waterproof.To prevent the risk of electric s- hock and short circuits,avoid exposure to water splashes or spill- Is,and do not place objects containing liquids,such as vases or c- Ups,near the device.

Cleaning
- Unplug the power cord first;
- Regularly clean the casing with a damp cloth and mild detergent; do not use harsh cleaning agents or solvents(such as alcohol or- thinners)
- Clean the lens with an lens cloth or lens paper,being careful not To scratch or smudge the lens.
- Periodically use a soft brush to clean the device' s vents and s- Peaker areas;otherwise,dust accumulation may block the vents,cau- Sing overheating and potentially leading to device failure.

High Altitude and Non-Tropical Climate Consideration
This product is only safe for use at altitudes below 2000 meters.
This product is only safe for use in non-tropical climate conditions.

Friendly Reminders
- **Do not disassemble the projector arbitrarily as it poses a risk of elec- Tric shock and may affect the warranty.**
- Please do not place any liquids or heavy objects on top of the device.
- Avoid placing items around the product that could block the ventil- ports.
- To prevent potential harm to children,place the product out of reach of children.
- If you find that the product is damaged,do not attempt to repair it yourself;contact the supplier.
- To protect your eyes while the product is in use,maintain a proper distance when viewing and avoid looking directly into the lens to preventeye injury.

Package Contents

Feature Description



QuickStart

①Insert the power cord into the wall Socket,then into the device.

②Press the power button to turn on The projector.

③Select the correct type of program to play.

④Use digital keystone correction and focus adjustment for optimal Performance.

⑤Press the button to turn off the projector.

Input Connections



Using Features

1. Wi-Fi Connection

Tap the "Settings" icon→select "Network"→enter the password complete.

2 Bluetooth Connection

Tap the "Settings" icon→select "Bluetooth"→choose the Bluetooth de- vice→enter the pairing code→complete.

3 Keystone Correction

Tap the "Settings" icon→select "Keystone"→use the OK button to s- witch points and the directional keys to adjust the angle.

Using Features

4 Projection Mode

From the home screen,tap the "Settings" icon→selector"→ Projection Mode"→choose the desired orientation.

5 Zoom

From the home screen,tap the "Settings" icon→select "Zoom"→ adjust the page zoom ratio using the up and down keys.

Using Features

6 Android Mobile Phone Screen Mirroring with Android Phones

Using Features

7 Iphone Screen Mirroring with iPhone

7.1 From the home screen,tap "AirPlay Pro".
7.2 Connect both the smartphone and the projectorto to the same Wi-Fi network.

7.2 Turn on WiFi on the projector,select "Screen Mirroring" On your phone,and then connectto the projector by selecting the corresponding "Device Name" displayed on the projector.

7.3 Turn on the "Screen Mirroring" function on your phone and connect to the projector.

投影机与电视



投影距离和尺寸

注意

Troubleshooting and Guide

1. Blurry Image

*Adjust the focus ring.
*Ensure the projector and the screen/wall are at an effective distance.

2. Remote Control Not Responding

*Ensure the remote is pointed directly at the IR receiver.
*Do not obstruct the IR receiver.
*Check the batteries.

3. Inverted Image

Access the "Menu" on the projector or remote control to flip the projected image.

4. Restore Factory Settings

Go to "Settings" → "Restore Factory Settings" to reset if Projectorior to default setting.

注意

Samsung Tech: Magicinfo Player	Samsung Tech: Magicinfo Player
MAC Kiosk: Kiosp Browse	MAC Kiosk: Kiosp Browse
Solar-dimm sjn digiprint player: Mediaos Manager	Solar-dimm sjn digiprint player: Mediaos Manager

Certification
Model: HI6
Product Code: 0000-0000-0000-0000

便携高清投影仪

用 户 手 册

型号：HI 6
本设备符合FCC规则第15部分的规定。

操作符合以下两个条件：
1. 此设备可能不会造成有害干扰。
2. 此设备必须不接受任何的干扰，包括可能导致意外操作的干扰。

MADE IN CHINA

目录

重要注意事项 1
包装清单 2
功 能 描 述 3
快速使用 4
输入连接 5
功能使用 6
投影机连接 10
投影距离和尺寸 10
规格 11
注意 12
故障排除指南 13

重要注意事项

安装
- 为获得最佳效果，请在较暗的房间内或关上窗帘使用本机。
- 请小心使用本机，粗落或撞击可能会损坏部件或发生图像模糊、显示不正常。

电源
- 请在本产品连续工作4小时后关机，冷断开电源30分钟后再开机使用。
- 请使用指定规格的原电源或适配器。如需更换电源线或其它附件时更换，•小心使用电源线，避免过度折弯，电源线损坏或可能会导致触电和失火。 •使用结束后，应从电源插座拔下电源线。

注意防水
本产品不具有防水功能，为防止触电发短路危险，应避免水渗或水溅，且产品

•

周围不应放置如花瓶、水杯等盛有液体的物品。

清洁
- 先拔下电源线；
- 经常用布定期清洁机壳，可使用中性洗涤剂。请勿使用烈性洗净剂或溶剂(如酒精或稀释剂)；
- 镜头要用镜头布或镜头纸清洁，注意不要刮伤或弄伤镜头。
- 请定期使用软毛刷清洁本机的通风口和扬声器部分，否则通风口会被积尘堵塞引起本机过热，从而导致机器出现故障。

高海拔和非热带气候注意
本产品仅适用于海拔2000m以下的地区安全使用。
本产品仅用于非热带气候条件下安全使用。

温馨提示
- **不要随意拆开投影仪，有电击风险，影响正常保修。**
- 本机上面请勿放置任何液体或重物。
- 请勿将可能导致产品通风口堵塞的物品放置在产品周围。
- 为避免产品对儿童可能造成的伤害，产品请放置在儿童无法触及的区域。
- 如发现本产品已损坏，请不要尝试自行修复，请联系供应商。
- 产品工作时，为保护您的眼睛，请保持适当的距离观看，请勿直视镜头，以免**灼伤您的眼睛。**

包装清单

功 能 描 述



快速使用

①将电源线插入插座，连接入机箱。

②按电源键进行开机操作。

③选择要播放的正确节目内容进行播放。

④使用数字调焦和聚焦功能进行最佳效果。

⑤按键关闭投影机。

输入连接



功能使用

1 Wi-Fi连接

主页点击“设置”图标→选择“网络”→输入密码→完成。

2 蓝牙连接

主页点击“设置”图标→选择“蓝牙”→选择蓝牙设备→输入配对码→完成。

3 梯形校正

主页点击“设置”图标→选择“Keystone”→确认键 切换点位，方向键调整角度。

功能使用

4 投影方式

主页点击“设置”图标→选择“Projection Mode”→根据需要选择不同的方向。

5 缩放

主页点击“设置”图标→选择“缩放”，通过上下键调整页面缩放比例。

功能使用

6 Android手机无线投屏

6.1 主页点击“Miracast”



6.2 投影仪开启后，手机选择“投屏”，手机中选择投影仪中显示的相应的“设备名”进行连接即可。

功能使用

7 苹果手机无线投屏

7.1 主页点击“AirPlay Pro”。
7.2 手机与投影仪连接到同一个无线网络。

7.3 手机打开“手机镜像”功能，连接到投影仪即可。

投影机连接

投影距离和尺寸



规格

显示技术	光源	原始分辨率	分辨率支持
LCD	LED	1280x720	1080P, 4K
投影距离	投影比例	焦距	变焦比
0.85-4.7M	32" -150"	电子调焦	4:3/16:9
投影尺寸	梯形校正	最大尺寸	投影模式
2K/4Ｋ x2	电子模形	196x142x158mm	正投/背投/侧投
输入电压	声音多媒体	支持的视频格式	支持的图片格式
AC100-240V	8.W/ 4ω	MPEG1/2/4 H.264 MPEG-TS/MPEG-2/ DivX/H.264	BMP/JPG/JPEG PNG
耳机	支持的音频格式		
DBC41/ TIDA-2C20W / Audio Ro/4C	MP3/ WPD/ WAV FLAC/ WAV/AAC		

购买日期:	客户签名:
MAC码:	店铺签章:
购买商店:	商店签章:

合格证
MODEL: HI6
Product Code: 0000-0000-0000-0000

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.