MEGAKEY

MEGAKEY MK983 User's Manual

Typewriter Keyboard





NO. 1 Function description



①Volume

The volume switch is made of metal. Push the metal ring can adjust volume.

②Power switch

Switch to the ON side means to turn on the keyboard power, and to the OFF to turn off the keyboard power.

③System switch

Press ③ to switch between Windows/Android System and Mac/IOS System. When the second indicator is blue light, means It can be used under Windows/Android system; when the third indicator is blue light, means it can be used under Mac/IOS system.

④Type-c Charging Port

When the fourth indicator light turns red, it need to be charged with the Type-C charging cable. It normally takes around 6 hours to fully charge.

⑤Lightness

Push the metal ring to adjust the keyboard brightness of the light.



⑥Pull rod

The pull rod of the electroplating process can switch the backlight mode by pulling the switch.

NO. 2 Indicator description



①Bluetooth/wired mode indicator

Wired mode：The indicator is red

Connect to the device (computer, mac, laptop) and typewriter with a type-c cable, press FN and R to switch the first indicator to turn to red. This is wired mode.

Tips: In wired mode,the first indicator light ① will not light up if you connect the keyboard with computer without the charging cable in our packing.

Bluetooth mode：The indicator is blue

First press FN and R to switch the first indicator to turn to flashing blue.
Second press FN and Z/X/C and hold on 5 seconds.
Third open the bluetooth switch and find the name of MK983 in the device click and connect it .
The first indicator will turn to fixed blue when bluetooth connect success.

②Window System

When the indicator light is on, it means that the keyboard is suitable for Window/Android System



③Mac/IOS System

When the indicator light is blue light,it means that the keyboard is suitable for Mac/ios System.

④Charging indicator

When the voltage is lower than 3.7V and the indicator light is red, it will be flashing red when the power less than 20%, it means the typewriter need to be charged;
the blue light fixed when charging. The light off when it is full.
When using individual mobile phone chargers to charge the typewriter, the indicator light will not light up.
Pressing CapsLK to switch between A/a, the key light is off.

Capitals lock indicator(A/a)

Win/Android:Pressing the 'CapsLk'key is the caps lock switch. The'CapsLk'key light up when the caps lock unction is turnedon,and the light is off when the 'CapsLk'caps lock function is turned off.
MAC/IOS :Pressing CapsLK to switch between A/a, the key light is off.

Win lock indicator (option key)

Press FN+WIN keys is the windows lock key switch. The WIN key light up when Win Lock Function is open, and Win key have no function at the same time. The light is off when lock key is closed and the Win key recovery function.

NO.3 FN combination keys manual

Window/Android

FN+F1	My Computer
FN+F2	Search
FN+F3	Calculator
FN+F4	Multimedia
FN+F5	Last Song
FN+F6	Next Song
FN+F7	Pause
FN+F8	Stop
FN+F9	Mute
FN+F10	Volume+
FN+F11	Volume-
FN+F12	Keyboard Lock
FN+WIN	WIN Lock

Mac/ios

F1	Screen Brightness-
F2	Screen Brightness+
F3	Call out all programs (Mac work IOS None)
F4	Launchpad (Mac work IOS None)
F5	Keyboard Brightness-
F6	Keyboard Brightness+
F7	Last Song
F8	Play / Pause
F9	Next Song
F10	Mute
F11	volume −
F12	volume +
PrtSc	screenshot
Pause (Only in Mac)	Start-up Siri

How to use Pause key to start up Siri:
Mac Apple—System Preferences—Siri—Keyboard shortcuts—Enter Pause—Finish

NO.4 Backlight combination keys manual

FN+↑ FN+↓	Adjust the lightness
FN+← FN+→	Adjust the speed of flashing
FN+HOME	Switch the backlight mode
FN+ESC	Press 3 seconds to restore the original design

NO.5 Sleep patterns

In the Bluetooth mode.it will enters sleep patterns after 5 minutes without press any key. It needs a few seconds pause to rework.

NO.6 Multi device Bluetooth mode combination keys

①Press "FN+R" to switch the indicator NO.1① to blue
②press FN and Z/X/C keys and hold for 5 seconds, the first indicate keep blue flashing at this time, then open the bluetooth switch in the device to finish pairing .
③The Bluetooth of the three devices is paired and connected to the corresponding FN+Z/FN+X/FN+C.
④How to switching among 3 devices: Press FN+Z/X/C=Device 1 or Device 2 or Device3

WHAT'S IN THE BOX:

MEGAKEY Typewriter BT MK983 *1
Metal Switch Puller*1
Keyboard Blue Switch*2
Type-C USB Cable*1
User Manual*1

NO.7 Specifications data

Number of keys: 83
Number of Multimedia Keys: 12
Materials: ABS &Metal
Battery: 2,000mAh
Charging Time: Around 6 hrs
Interface: Type-C
Mode: Bluetooth&Wired
Switch lifespan: >50milions
Keyboard function:All keys anti-ghosting
BT Name: MK983
Dimensions: 32.5*16.9*4.3CM
Weight: Approx. 1.642lb

Press and hold for 5 seconds to bluetooth pairing during bluetooth pairing, the first indicator light flashes slowly.
Turn on the bluetooth switch of the mobile phone/tablet device to connect operation. After the connection is successful, the first indicator light will keep blue.

Dear Custormer:

Thank you for purchasing at MEGAKEY, we hope that our products will bring you a pleasant experience.
If you have any problems with our products, please feel free to comtact us, we will try our best to solve all problems for you.
If you satisfied with our products, please leave a positive comment as an encouragement to us, we are very grateful if you would share your shopping experience with our customers.
In any case, don't forget. If you encounter any problem, big or small, we're at your disposal, any time.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction