User manual

Read these safety instructions before using the device and store them for future reference.

YKY-01 is a wireless couples earphone that including two pairs of YKY-J02 earclip(OWS) and YKY-B01 earbuds. Afterconnecting the earphones to the device, you canstill listen to music and answer calls even when youare doing other activities (such as fitness). Beforeusing their mobile devices,make sure they arecompatible with this device.

Be careful not to wet the equipment when using it. If the equipment is damaged by water, it may malfunction.
Avoid storing or using the device at temperatures lower than -15°C or higher than 55°C, which could shorten the headset or battery life.

Specifications

Modelo : YKY-01
Bluetooth Version: V 5.3
Bluetooth Range: 10meters
Playback time: 4–5 hours
Charging time: 1–1.5 hour
Standby time: 100 hours

Accessories:

1*user manual
1*type–c charging cable

Key function diagram

Charging box



Earphone



Use headphones

1. Insert the headset into the acupoint of the headset charging box correctly. If the indicator light does not blink, connect the charging box to the charger and charge it for more than 10 minutes.
2. Close the charging box.
3. Open the charging box and take out the headset, the headset will automatically enter the pairing mode
4. On the mobile devIce, enable Bluetooth function to search for " YKY-B01and YKY-J02 " and connect it to the mobile device

Touch control

Touch pannel	Left earbuds	Right earbuds
Long Touch	Power on/off	Power on/off
Single Touch	Play/ Suspend	Play/ Suspend
Long press (2 seconds)	Next track	Previous track
Tap twice	Volume +	Volume -

Function	Touch pannel
Answer calls	Single Touch
Reject incoming call	Long press (2 seconds)
Redial last number	Single Touch
Voice Assistant	Third times Touch

When the left and right ears cannot pair. Please click four times when not connected to your phone Earphones (both sides need to be pushed). After four clicks take effect, it will automatically shut down. The reset is now complete.Put the earphones into the charging compartment and take them out to pair them again.

Charging

You need to charge your device for 10 minutes before using it for the first time or after a long period of absence.
When the battery of the earplug is low, it will issue "Please charge", which can put the earphone into the charging box. When the earphone is charging, the red light will be displayed, and the light will be off if the charge is slow.Please close the charging case when storing or charging the headphones.
The charging case has a built-in battery, please use a type-c cable to charge itbox, then connect it to a computing or other charger for charging, charging Whencharging, the indicator light flashes, and the fully charged indicator light is always on.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there isno guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

· Reorient or relocate the receiving antenna.
· Increase the separation between the equipment and receiver.
· Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
· Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

使用说明书

在使用设备之前，请阅读这些安全说明，并将它们存储起来，以备将来参考

YKY-01是一款无线蓝牙机，内含运动夹耳式YKY-J02和柄式YKY-B01两对耳机，将耳机连接到设备后，即使是进行其他活动的时候(例如健身)，仍然可以听音乐和接听来电。使用其移动设备前，请确保它们与本设备兼容。

使用时注意不要弄湿设备，如果设备因水受损，可能会发生故障。
避免将设备储存或使用于温度低于–15℃或者高于55℃的环境否则会缩短耳机或电池寿命。

参数

型号: YKY–01
蓝牙版本:v5.3
蓝牙范围:10米
播放时间:4–5小时
充电时间:1–1.5小时
待机时间:100小时

配件:

1*使用说明书
1*Type–c充电线

按键功能示意图

充电盒



耳 机

使用耳机

1.将耳机正确的插入耳机充电盒穴位中，如果指示灯没有闪烁，将充电盒连接到充电器为其充电10分钟以上。
2.关闭充电盒。
3.打开充电盒，取出耳机后，耳机将自动进入配对模式。
4.在移动设备上，启动蓝牙功能搜索“YKY-B01和YKY-J02将其连接至移动设备。

功能使用

按键	左耳塞	右耳塞
长按	开机/关机	开机/关机
单次触摸	播放/暂停	播放/暂停
双击2次	上一曲（音乐状态）	下一曲（音乐状态）

功能	按键
接听电话	单击
拒接来电	长按 1 秒
挂断电话	单击
语音助手	长按耳机功能键 2 秒

当出现左右耳无法配对时。请在未与手机连接状态下四击耳机(左右都需操作）。四击生效后会自动关机。即完成重置。再将耳机放入充电仓后拿出即可重新配对。

充电

初次使用耳机前或长时间未用耳机后，需要充电10分钟才能使用设备。
当耳塞电量不足时，会发出“Please charge”可以将耳机放进充好的充电盒，耳机充电时将显示红灯，充满灯灭。存放耳机或耳机充电时，请合上充电盒。
充电盒配有内置电池，请使用type-c电缆，与其充电盒连接，然后将其连接到计算或其他充电器进行充电，充电时，指示灯闪烁，充满电指示灯常亮。