尺寸:75x75mm
折叠方式:风琴式
材质:100g书纸
颜色：434243

iGene

iGene G2

INSTRUCTION MANUAL FOR TRUE WIRELESS HEADSET

Please read the instruction manual carefully when using this product

TIPS

1. Please fully charge before first use
2. During daily use, please regularly clean the charging port and the charging pins of the charging case with an alcohol swab to prevent sweat and dirt affecting charging.
3. After connecting the earphones to some Android/HarmonyOS phones, you need to open the option to synchronize the volume of the Wireless device with the phone in the Wireless settings.
4.Please do not use the product outdoors during thunderstorms.

PRODUCT LIST



① Charging case ② Earphones ③ Charging cable ④ Ear tips ⑤ Manual

START

NAME: IGENE-G2

ACTIVATE EARPHONES

Use a 5V-1A charging head to charge the case and activate the earphones

PAIR EARPHONES

Remove both earphones from the charging case and they will automatically pair

CONNECT EARPHONES

Turn on your phone's Wireless, search for the name "iGene-G2" and click to connect
Note: Some phones will prompt you to confirm pairing with the earphones. Click "Pair" to complete the connection

FUNCTION

POWER ON

Remove the earphone from the charging bay or press and hold it for about 4 seconds to turn it on

POWER OFF

Long press the touch point on the left or right earphone for about 6 seconds while the device is on
Put the earphones into the charging case and close the lid to charge and automatically power off

PHONE

Cancel dialing by double-clicking the touch key on either earphone during dialing
Answer incoming calls by double-clicking either earphone touch key
Reject incoming calls by long-pressing either earphone touch key for 2 seconds
Hang up by double-clicking either earphone touch key during a call

VOICE ASSISTANT

Wake up voice assistant by triple-clicking the left earphone touch key
Turn off voice assistant by single-clicking the left earphone touch key
Note: Siri of Apple will be waken up and the voice assistant that comes with your Android phone will be turned on - Earphone touch key

MUSIC PLAY

Play music: Play/pause by single-clicking either earphone touch key while playing music
Skip to the previous track by double-clicking the left earphone touch key while music is playing
Skip to the next track by double-clicking the right earphone touch key while music is playing

SWITCH BETWEEN GAME AND MUSIC

Music mode is the default mode when the device is turned on
Switch to game (low latency) by triple-clicking the right earphone MFB touch key while in music mode
Return to music mode by triple-clicking the right earphone touch key while in game mode

CHARGING INSTRUCTIONS

Charging: Charge the earphones by put them back in the charging case and closing the lid
The battery case can be charged with a 5V ⎓ 1A charging head

NOTES

HEALTH AND SAFETY

1. Stop using the product if it shows obvious damage.
2. Do not listen to music at high volume for a long time.
3. Do not use it while driving or engaging in other activities that require concentration.
4. Do not use the product outdoors during thunderstorms.
5. Keep the product away from children under 12 and pets to prevent accidental ingestion.

Product protection

PRODUCT PROTECTION

1. Store the product at room temperature, keep it dry, and avoid prolonged exposure to high or low temperatures or humid environments.
2. Use the original or certified charging cable.
3. Do not submerge the product in water.
4. The product has a built-in lithium battery, and its composition may change due to surrounding temperatures. Do not use it in environments with extremely high or low temperatures, as this may cause permanent damage to the battery.

FAQS

WHY CAN'T THE LEFT AND RIGHT EARPHONES CONNECT SUCCESSFULLY?

Re: The earphones need to be close to each other when pairing and connecting. Please keep the earphones close together during pairing and connection. Once paired successfully, they can be used normally.

CAN I USE A FAST CHARGER TO CHARGE THE CHARGING CASE?

Re: Please use a 5V ⎓ 1A charging head to charge the case. High power charging devices may cause damage to the product.

WARRANTY

IGENE ACOUSTICS TECHNOLOGY'S AFTER-SALES SERVICE COMMITMENT: WE STRICTLY FOLLOW THE "CONSUMER RIGHTS PROTECTION LAW OF P.R.C." AND THE "LAW OF THE PEOPLE'S REPUBLIC OF CHINA ON PRODUCT QUALITY" TO PROVIDE AFTER-SALES SERVICE, WHICH IS AS FOLLOWS:

1. Within 7 days of purchase, if the product experiences performance failure, consumers can choose to return, exchange or repair the product.
2. Within 15 days of purchase, if the product experiences performance failure, consumers can choose to exchange or repair the product.
3. Within 1 year of purchase, if the product experiences performance failure and our technical staff determines it is not caused by human factors, we will provide repair services for free.
4. In the following situations, we will provide repair services but may charge for parts and labor based on the actual situation:
① Product damage caused by incorrect operation, negligence or force majeure.
② The product has been repaired by a third party organization before being repaired by our company.
③ The warranty period has expired or the product has been damaged by human factors.
Please keep the warranty card safe. We will not be able to provide repair services in the following circumstances:
① The information on the warranty card and related sales voucher does not match the product.
② The content of the warranty card has been altered or is unclear or unrecognizable.
5. The free service provided by this warranty card does not include accessories or other decorative items.
7. Warranty service does not include transportation or on-site service fees.

iGene reserves the right of final interpretation

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

RF WARNING STATEMENT

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

WORRY-FREE AND CONSIDERATE WARRANTY

BRAND NAME	iGene-G2
PRODUCT MODEL:	TWS002
DATE OF PURCHASE	
USER NAME	
CONTACT NUMBER	
USER ADDRESS	
WARRANTY	

Bluetooth headphones
FCC ID: 2ABJ7-I-GENE-G2
Model:iGene-G2

Shenzhen Yiqiang Technology Co., Ltd.
Address: Room 1101, Building 1, Yiqiang Technology Building, Shiyan Street, Bao'an District, Shenzhen, Guangdong Province, China

Product name: iGene-G2
Manufacturer: Qianqian Acoustics Technology Co.,Ltd.
Address: iGene Acoustics Technology Co.,Ltd., Shijai town, Dongguan City, Guangdong Province
Executive standard: GB8898-2011