尺寸：50*100mm,5折页正反印刷，材料：70g双胶

KIMISO

KMS-671

SPEAKER User Manual



Product specifications:

- Version : 5.3
- Working distance: 10M
- SNR: ⩾95db
- Battery:3.7V 1200mAh
- Normal volume playing time: 2H
- Speaker driver : Ø 52 mm *2
- Power : 4Ω/5W *2
- Frequency response: 120 Hz-18KHz
- Unit size:84mm*84mm*186mm
- Unit weight:460g
- Charging:5V/500mA

Product Feature:

1.International advanced chip and circuit design techniques, support all device ;

2.Built-in Low-freq radiators, Super dynamic low-frequency sound pressure gain, listening transparent and flexible.

3.Can play music after pairing with device .for example mobile/ MID/ TV, the working distance is more than 10M.

4.Support AUX IN audio input

5.Built-in MP3 decoding, can directly play TF card, U disk

6.Build-in the FM radio module, convenient to auto scan and save radio channels.

7.With Mic for hands-free phone call function.

8.Support TWS

9.FM is in RX mode

key & slot function:



1.DC 5V charging slot:use the standard TYPE-C USB charging cable for power charging

2.TF slot: it can decode and play MP3/WAV format audio when put TF card into the slot

3.USB slot: it can decode and play MP3/WAV format audio when put USB card into the slot

4.AUX : it can play audio via 3.5mm AUX cable to audio device

5.When play music , press short for last song/last FM station, press long to turn down the volume.

6.When play music, press short for next song/next FM station, press long to turn up the volume

7.When play music,press short for option of the LED flashing light, press long to open/close.

8.Power switch: Press long for power on /power off;press short to swith model(USB card/TF card/ /FM)switch to “line in” if via AUX cable to audio device.

9.When play music,(USB card/ TF card/LINE IN/), short press for “play/pause”. Under mode with mobile paired,when call coming,press short to answer a call hands-free,press again to hand up,press twice to ring up a call.

In FM mode, press short to search station automatically, press again to stop searching.Keep the TWS speaker under mode without pairing,press the“play/pause”key for 4 seconds either of the speaker until hear a hint and meantime the button light stop flashing,now is in TWS mode,then can paire the mobile.

Note: Under FM mode, put in the AUX cable to get better FM radio station

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including interference that may cause undesired operation.