Vibrating Anal Plug

User Manual

Daigan



Before first use, please read the instructions below carefully.

RoHS IPX6 RED

About this Device:

Daigan vibrating anal plug not only has a thick feeling but also allows you to experience 10 different vibration frequencies. The compact size is convenient for wearing and going out, and the wireless remote control is easier to control.

Product information：

Model NO:	YC-52
Material:	Liquid silicone and ABS
Waterproof:	IPX6
Features:	10 vibration patterns
Charging Method:	Rechargeable Li-ion Battery，USB Charging
Charging Time:	120 minutes
Usage Time:	50 minutes



Product description:

- Press for 3 seconds to turn on / off.
- Press shortly to shift vibration

LED light indication:
Device ON: Solid light ON
Low Battery Warning: Light flashing
On Charging: Light blinking
Fully Charged: Solid light ON



- Press shortly to shift 10 Vibration patterns.
- Press for 3 seconds to turn on / off.
- Press shortly to shift 10 Vibration patterns.



Charging Tips:

Make sure this product is fully charged before first use. It will NOT work while charging!

Disclaimer:

This product is to be used as a novelty for people over the age of 18 only. Users of this item do so at their own risk. It should not be use on prolonged or frequent basis.
Neither nor its retailers assume any responsibility or liability for the use of this product.
This product doesn’t claim to cure any disease or STI.

Warranty Terms & Conditions:

This product warrants this device for a period of one year, after the date of original purchase against defects due to faulty workmanship or materials. If you experience any factory/assembly defects, please contact us and we will do our best to solve your issues as soon as possible.
Caution: please do not take your vibrator apart by yourself or by an unauthorized repair shop, as your warranty will automatically expire.

Safety Tips:

Avoid sharing this device with others due to hygiene concerns.Only water based lubricant is recommended to use with this product.Do not use massage oils or hand cream as lubricants for this device, as you will damage its silicone soft touch surface.Stop using this device if its tip is chipped or broken or has sharp edges.

Cleaning and Storage:

Please note that the remote controller is not waterproof.
Always clean your device thoroughly before and after each use.
Clean your device with an antibacterial toy cleaner.
Alternatively, you can wash the device with warm water and soap, rinse with clean hot water and pat dry with a clean towel.
Hard detergents, disinfectants, acetone or alcohol are not recommended to use to clean your device.
Store your device in a clean and dry space and keep it out of children’s reach.

Applicable for ALL products, the model may be changed for improvements without notice.

FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.