WIRELESS HEADSET

INSTRUCTION MANUA

Model: MH04

These instructions are for your safety. Please read through them thoroughly before use and retain for future reference.

WARNING

- The device is not water-proof, please against any liquid so that well protect the device.
- Please keep it out of small children reach, and stock against humidity and hot temperature.
- Please remove the electronic parts from the helmet when the device would be detached.
- Please keep the device against acidic, alkaline and cuspidal things.
- Please do not disassemble, amend or alter device alone, and do not throw and drop it.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.

FEATURES

- Wirelessly listen to music with integrated BT technology.
- Fashion design, let music surrounding your life any time.
- Hands free function, truly free your hand.
- Set-in rechargeable Li-ion battery, long stand-by and working time.
- 5.0 type of CSR BT chip, Hi-Fi earphone.
- Support power displaying on iPhone, easy to know when will to be charged.
- DIY design, available to be detachable when you want.
- Sound reminder function, easy to set the device according to sound remind.

PARTS INCLUDED

Wireless Headset
Micro-USB to USB charge cable
User manual

SPECIFICATIONS

- BT version: 5.0
- Frequency: 2.402GHz-2.480GHz
- Range: 20-30 meters (depending on device)

- Transmission distance of Microphone: ≤1 meter
- Li-ion battery: 3.7V/180mA
- Playback time: ≤8 hrs
- Charging Voltage: 5V
- Charging time: ≤1 hrs
- Standby time: ≤160 hrs
- BT name: MH04

CHARGING THE HEADSET

Note: The Device will need to be fully charged prior to initial use(approx. 2 hours).

1. Connect the micro-USB end of the charge cable to the micro-USB port on the Cap (Fig. 1).
2. Connect the USB end of the charge cable to the USB port of the computer or adapter (not included).
3. The LED indicator (Fig. 1) will turn solid RED while charging and will turn off when fully charged.



Fig.1

Note: the Device can not be music playing or call answering while it is charging.

USING THE HEADSET

Power on : Press the power button 3 seconds, the device will be sound reminder as"Power on".

Power off : Press the power button 3 seconds, the device will be sound reminder as"Power off".

Pairing :

1. Press the BUTTON 3 seconds with the sound reminder of "power on" and the sound reminder of "pairing", then seek the BT name of "MH04" to pair, the sound remind of " connected" seems paired successfully(set-in the password of "0000" if your BT device is BT 2.0 version.)

2. Automatically repair: If your device is the latest recent paired device, the headset will be automatically re-paired with your device when the device open it again.
3. Automatically search: The device will be automatically into pairing mode again once the paired device is off.
4. Broadcasting/Pause: Press button to pause the song, press it again to continue the song. Upper song/decrease the sound press"-" one time for upper song, continue press the button to decrease the sound.
5. Next song/increase the sound: Press "+" one time for next song, continue press the button to increase the sound.

CALL ANSWER

1) Android smart phone: the cap will be alarming with "DONG, DONG..." while somebody calling. iPhone: the Headset will be alarming with phone calling music which is the same as the phone calling music in iPhone.
2) Answering: Automatic speak phone number when call is coming and automatic answer the incoming call after ten seconds. Short press to answer the incoming call if you want to answer the phone early.
3) Hang-up: Press the button again to hang-up.
4) Re-dial phone function: Press the button two times to redial the most recently phone number directly.
5) Phone number broadcasting: somebody call you, the device will sound broadcast the calling phone number, and the user will easy to know who calling.

Power save mode: The device will be off automatically after 5 minutes if no working device paired.

Low power warning: The device will be with the sound remind of "power low" while is working, it seems the power not enough, need to be charged.

Power Off: Press the button 3 seconds again, the device closed with the sound reminder of "power off", and the LED indicator off.

English and Chinese switch: Double pressing the power button when the BT is open but not connected, while you head the sound"di...di...di...di...di...", the BT language switches successfully.

Hand up call: Keeping pressing the power button for 1 second while called.

INSTALLING STEP

Step 1: Take out the BT part from the color box, and find out the two earphone, put the earphone into the both sides of the ear position via magic tape
(reference. Fig. 2)



Fig. 2



Fig. 3

Step 2: And then, put the suitable position, try to put the helmet on the head so that the device is on suitable position, you can modify the position by hand in order to well use it. (reference. Fig. 3)

COMPATIBILITY DEVICES



Warranty Card

Please keep your purchase receipt together with your warranty card & "invalid if removed" label.

Name: _____

Address: _____

_____

☎ _____

Please affix a copy of invoice on the back of warranty card as a proof of purchase date.

If you find any problems during use of our product, please contact our after sale service.

Please make sure that you describe the problems clearly on warranty card so that we can handle them timely.

1 Year Warranty

Failure Description:

MADE IN CHINA

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device

must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarant ee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environm ent. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.