SWITCH用無線コントローラー

WIRELESS CONTROLLER FOR SWITCH/SWITCH OLED

*コントローラーの色は参考用だけ。多色の一つです

01 製品ボタンのレイアウト 1P
02 接続方法 2P
03 連射機能 3P
04 LEDランプ 4P
05 LED調節 5P
06 強弱振動調整 | 自動スリープ 6P

製品ボタンのレイアウト

接続方法

無線接続（初回接続）：

❶SWITCH本体の電源を入れて、起動してください

❷SWITCHのHOMEボタンを押す→コントローラー→持ち方/順番を変えるを押してコントローラー接続画面に入ります。

❸コントローラーのBluetooth接続ボタンを2秒を押して、四つのLEDが点滅したら手を放してください。。SWITCH本体とコントローラー接続が開始します。

❹接続完了すると、LEDランプが点灯します

次回接続場合：

❶コントローラーのHOMEボタンを2秒以上を押して、LEDが点滅したら手を放してください。接続が開始します

❷接続完了すると、LEDランプが点灯します

※HOMEボタンでSWITCHのスリープを解除することができます

有線接続方法

❶ 設定→コントローラーとセンサー→pro コントローラー有線通信を ON にしてください

❷ 付属しているケーブルでコントローラーとドック接続してください

Android：

❶シャットダウン状態で「X+HOME」ボタンを2秒押して、AndroidGamepadモードで、LED4はランプが点灯することを示します。

❷ペアリングに成功したら、今度はホーム(ボタン)を押して自動的に接続できます。

macOS：

❶ケーブルmfiモードでは、「B+HOME」ボタンを2秒押し続けると、LED3のランプが常に点灯します。

連射機能

1.連射設定：A/B/X/Y/L/ZL/R/ZRの中で一つボタンを選んで押しながら連射ボタンを押すと連射機能がプラスされます

2.自動連射：連射設定したボタンを押しながら、連射ボタンTを押すと自動連射になります

3.連射解除：連射設定したボタンを押しながら、連射ボタンTを押すと設定したボタンの連射機能が解除します（1,2,3が繰り返す）

※ 連射ボタンTを5秒が長押しと全ての連射機能が解除します

LEDランプ

コントローラー	LEDランプ
使用中	LEDが点灯します
充電中	LEDが点滅します
充電完了	四つLEDが点灯します

LED調節

1.色調節：Tボタンを押しながら、L3が押すと消灯色が変えます。順番：赤、オレンジ、緑、青、ブルー、紫、多色

2.呼吸ランプと消灯：Tボタンを押しながら、L3が2回押すと呼吸ランプになります。順番：呼吸ランプ、多色呼吸ランプ/消灯

3.明るさ調節：Tボタンを押しながら、L3が2秒以上長押すと明るさが調節できます。順番：25%、50%、75%、100%

強弱振動調整

強くなる：Tボタンを押しながら、方向ボタン上を押してください

弱くなる：Tボタンを押しながら、方向ボタン下を押してください

自動スリープ

1 switch本体画面が閉じると、コントローラーがスリープモードになります

2コントローラーら分以上が使わないとスリープモードになります

3無線の場合、homeボタンを5秒以上を押しと接続が切れます

リセット方法：接続ボタンを3秒以上長押すとコントローラーがリセットします

BUTTONS

CONNECTION

The First Connection: Long press pairing key for 2 seconds, led1-led4 running lights flash

Second connection mode:

❶ Please sure the "Pro controller wired Communication" is turn on
（System settings > Controllers and Sensors >Pro Controller wired communication > On）

❷ Wired connect ways like the picture

Android：

1.Longpressthe"x+home"keyfor2secondsintheoff state,whichisthetheAndroid gamepadmode,andtheLED4indicatorwillseon.

2.After successfull pairing,press the[home] key next time to connect automatically.

macOS：

Apple MFI mode,long press"B+home"key for 2 seconds,LED3 indicator will be on.

CONTINUOUS FUNCTION

1.Manual continuous firing: Press (the first time) A/ B / X / Y / L1 / L2 / R1 / r2 / cross key +turbo key to set continuous firing function.



2. Clear the continuous sending: press turbo again (the second time) to realize the auto turbo function; Press and hold turbo key for 5 seconds to clear all consecutive functions.

3. Press and hold turbo key + "A" key first to clear turbo function of current "A" key.

BATTERY

STATE OF CHARGE	INDICATOR STATUS
Low power	Channel lights flash in the game
Charging	Led 4 Indicator Flashing
Charging complete	Led 4 Indicator is always on

LIGHTING CONTROL

1.T plus L3 (stick click down) order: red, orange, green, cyan, blue, purple, magic) light loop.

2.T plus L3 (rocker double click down) Order: color breathing light cycle / phantom breathing light cycle / turn off light.

3.T plus L3 (stick long press for 2 seconds) adjustable light brightness, light scheduling a total of levels, 25%, 50%, 75%, 100%

VIBRATION

1.Enhance the vibration effect (T+Up arrow key)



2.Reduce vibration effect (T+ Down arrow key)

AUTOMATIC SHUTDOWN

The host screen is closed and the handle automatically sleeps If no key is pressed within 5 minutes, it will sleep automatically.In Bluetooth mode, press the home key for 3 seconds to disconnect the host, and the handle will sleep.

按键分配

连接方式

连接方式一：长按配对键2秒，LED1-LED4 跑马灯快闪

连接方式二：

❶ 确保 SWITCH 已在设置中**开启手柄有线连接**
（设置 > 手柄与感应器 > Pro 手柄的有线连接 > 开启）

❷ 将 Switch 放至底座，使用附带的 Type-C 数据线连接底座 USB 接口，或直接连接 Switch。



Android：

1.关机状态下长按“X+HOME”键2秒，为安卓Gamepad模式,LED4指示灯会亮。

2.成功配对后，下次使用按[home]键可自动连接。

macOS：

苹果mfi模式，长按“B+HOME”键2秒，LED3指示灯会常亮。

连发功能

1.手动连发：按下（第一次）A/B/X/Y/L1/L2/R1/R2/+TURBO键可设置连发功能。

2.清除连发：再次（第二次）按下 TURBO 即实现 AUTO TURBO 功能;长按Turbo键5s，清除所有连发功能。

3.另外先按住 Turbo 键+A 键,清除当前 A 按键的 Turbo 功能。

电量显示

电量状态	指示灯状态
低电量	游戏中通道灯闪烁
充电中	LED1-4 指示灯闪烁
充电完成	LED4 指示灯常亮

灯光控制

1.T加L3(摇杆单击下压)顺序:红、橙、绿、青、蓝、紫、幻彩)灯光循环。

2.T加L3(摇杆双击下压)顺序:彩色呼吸灯循环/幻彩呼吸灯循环/关闭灯光。

3.T加L3(摇杆长按2秒）可调节灯光亮度，灯调度共个级别，25%，50%，75%，100%

马达震动调节

增强震动效果：T加方向键上

减轻震动效果：T加方向键下

自动关机

自动关机：

主机屏幕关闭,手柄自动休眠。

5分钟之内没有任何按键按下则自动休眠。

蓝牙模式，按下HOME键3秒，断开主机连接，手柄休眠。

IINE 良值

基本信息		工艺	
名称	L617SWITCH唤醒手柄黑色	颜色	4C
尺寸	63x102(mm)	材质	128g哑粉纸
日期	2022.06.04	表面处理	无
		折法	骑马钉

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.