正面

TWS无线耳机

使用说明书

E7S

产品参数为实验室测试数据，具体数据以使用数据为准

产品示意图

耳机参数配置

产品型号：E7S　　版本：5.3
播放时间：约5小时　　通话时间：约5小时
耳机容量：50mAh/3.7V　　充电时间：约1小时
有效距离：≥ 10米　　喇叭：铜环 8mm

包装清单

1. 充电盒*1　2. 左右耳机*1　3. 大号耳帽*2
4. 产品手册*1　5. 充电线*1

充电仓配置参数

电池容量：200mAh/3.7V
充电时间：约1小时
输入电压：5V/200mAh

佩戴方式

打开充电仓盖,取出右耳耳机,将耳机喇叭端轻轻放入右耳耳道，再轻轻摆动耳机不晃动为宜。用同样方法佩戴左耳耳机。

操作方式

1. 开机
(1)打开充电仓盖子，取出耳机自动开机,耳机红蓝灯闪烁
(2)耳机在关机状态,长按耳机按键板3秒开机
2. 关机
(1)将耳机放回充电仓，耳机自动关机充电
(2)耳机在开机状态下,长按耳机按键板5秒关机

双耳配对连接

1. 打开充电仓盖子，取出耳机自动开机，红蓝灯闪烁，进入自动组队状态，其中一个耳机灯灭，表示组队成功。

2. 打开设备蓝牙列表，搜索找到“E7S”

3. 点击连接“E7S”即可连接。如未连接失败，将耳机放回充电仓盖上盖子，然后重复上面操作步骤即可。

4. 双耳同时离开与设备正常连接距离后，耳机进入回连蓝牙耳机状态，5分钟内未完成回连成功，双耳将自动关机。

5、耳机开机之后，未连接手机之前，双击双耳任意一边自动切换中英文语言
(单中文或单英文的产品无此功能)

首次连接设备后，下一次耳机重启开机，会自动连接上一次配对设备

双耳触控操

耳机充电:耳机放入充电盒自动充电
充电指示灯亮红灯,充满后红灯熄灭
充电盒低电:数码管个位数闪烁
充电盒充电:数码管个位数闪烁,充满100停止

F&Q

1、问:怎么只有一个耳机有声音?
答:将两个耳机同时放回充电仓,关盖充电,然后在取出看是否恢复双耳模式,如未恢复,恢复出厂设置即可解决
2、问:手机无法连接耳机?
答:将手机上配对的TG01删除,再进行配对连接即可.
3、问:怎么听歌/通话没有声音?
答:手机在手机连接记录的右边有一个设置图标,点击进入,将两个音频选项取消勾选再重新选择,在设置通用辅助功能进入音频通话方式,选择自动,如果本来就是自动,就更为其他选项,然后在更改为自动,如未恢复,删除配对记录重新连接尝试.
4、问:怎么有卡顿/断续?
答:如果使用耳机时,周边有大量的Wi-Fi设备、4G信号,大功率电器等等产生干扰,可能会出现卡顿,断续情况,更换环境或者重新配对连接可以恢复正常.

注意事项

1、请使用正规来源有安全认证的充电器进行充电
2、使用耳机时适量的调节音量大小以免损伤听觉
3、正确使用产品避免高空摔落或重度挤压
4、儿童请在成人陪同下使用避免误食
5、远离高温或潮湿等极端环境
6、请勿拆卸本产品

反面

TWS WIRELESS HEADPHONES

Operating instruction

E7S

Product parameters are laboratory test data, the specific data is subject to the use of data

Product diagram

Headset Configuration

Product Model: E7S　　Version 5. 3
Running time: about 5 hours　　Talk time: about 5 hours
Headphone capacity: 50mAh/ 3.7V　　Charging time: about 1 hour
Effective distance :≥10 m　　Horn: copper ring 8mm.

Packing list

1. Charging box *1　2. Left and right earphones *1
3. Large ear cap *2　4. Product Manual *1
5. Charging cable *1

Charging bin configuration parameters

Battery capacity: 200mAh/ 3.7V
Charging time: about 1 hour
Input voltage: 5V/200mAh

Wearing a way

Open the cover of the charging bin, take out the earphone of the right ear, and put the earphone horn end Gently put into the ear canal of the right ear, and then gently swing the earphone not to shake.Wear the left earpiece in the same way.

Mode of operation

1.The boot

(1) Open the cover of the charging bin, take out the earphone and start up automatically, and the earphone turns red Blue lights flashing

(2) When the earphone is off, press the button for 3 seconds to start the headset

2.To turn it off

(1) Put the earphone back to the charging bin, and the earphone will automatically shut down and charge

(2) When the headset is on, press the button for 5 seconds to power off the headset.

Pairs of ears connected

1. Open the cover of the charging bin, take out the earphone and start it automatically. The red and blue lights are flashing, and we're in automatic formation mode, one of them If the headphone indicator is off, the team is successfully formed.

2. Open the bluetooth list of the device and search for "E7S"

3. Tap E7S to connect. If the stay connection fails,Put the earphones back in the charging bin and close the lid, then repeat the top The operation procedure is ok.

4. When both ears leave the normal connection distance with the device,Headset The headset is connected back to the Bluetooth headset, and the connection is not completed within 5 minutes If the connection is successful, both ears will shut down automatically.

5. After the headset is turned on and before the phone is disconnected, double-click Automatically switch between Chinese and English on either side of ears.
(Only Chinese or only English products do not have this function)

After the device is first connected,
The next time the headset is restarted,
It will automatically connect the last pair device

Two-ear touch operation

Earphone charging: The earphone is automatically charged in the charging case The charging indicator light is red and the red light goes out when it is full
Charging case low power: digital tube single digit flashing
Charging case charging: digital tube single digit flashing, full 100 stop

F&Q

1. Q: Howx:-49.66m one earphone has sound?
Y: 118.26 mm
A: Put the
unpuones back into the charging bin at the same time,
close the cover to charge, and then take them out to see whether the dual-ear mode is restored
If the fault is not rectified, restore the fault to factory Settings
2. Q: The phone can' t connect to the headset?
A: Delete the paired TG01 on the mobile phone, and then make the paired connection.
3. Q: How can I listen to music/talk without sound?
A: phones have a setting icon on the right side of the phone onnection record. Click enter to select two audi oDeselect and then re- select. Enter audio Call mode in Setting General Accessibility, and select Automatic, if it is automatic, then other options, and then change to automatic, if not restored, Delete the pairing record retry attempt.
4. Q: Why is there a stutter/ stutter?
A: If you use headphones, there are a lot of Wi-Fi devices, 4G signals, high power appliances and so onInterference, stuttering and di scont inuous condi tions may occur, and the connection can be restored by changing the environment or re pairing

Matters needing attention

1. Please use a charger with safety certification from a formal source for charging
2. Adjust the volume of headphones to avoid damage to hearing
3, the correct use of the product to avoid falling from high or heavy extrusion
4. Children should be accompanied by adults to avoid accidental ingestion
5. Stay away from extreme environments such as high temperature or humidity
6. Do not di sassemble the product

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.