slcep -one Ai

Shenzhen Shushi Intelligent Home Furnishing Co., Ltd.
Tel: 400-181-6996
官网：www.sleeponeai.com
Address: No.8 Tangfu Road, Pingshan District, Shenzhen, Guangdong

Sleepone Ai Dexin WeChat official account

Model: SlGeP One AiMatratze

wisdom intelligent deep sleep sleep



Sleepone Ai Intelligent Mattress Remote Control Instruction Manual

Schematic diagram of Sleepone Ai smart mattress operation



1、Adjustment method

Press left/whole/right to confirm the position of the mattress before adjusting the hardness or yoga to help you sleep.
Take yoga to help sleep on the left as an example: press left first, then press yoga.

Take the right hard adjustment as an example: press right first, then press hard.

2、Intelligent adaptive switch

If you need a completely silent sleep environment, you can press Sleep before going to sleep, thus turning off intelligent adaptation. Smart adaptation will not be turned on automatically after it is turned off. If you want to turn it on again, please press Smart.
The sleep key and smart key are aimed at the whole mattress, and there is no distinction between left and right. There is no need to choose the position of the mattress before use.

Frequently asked questions

FREQUENTLY ASKED QUESTIONS	Possibility analysis	Solution countermeasures
The remote control cannot be adjusted.	The mattress is not plugged in. Or the plug is loose	Please check whether the adapter is connected to the power cord, whether the power cord is connected to the mattress and whether the power plug is plugged into the triangular socket.
	Remote control pairing abnormal	Please re-pair your remote control with the smart mattress and try again.
	The remote control is dead.	Please replace the remote battery.
How to control the mattress after the remote control is lost?	In the case of stable home network environment, you can still use Mijia APP to control the mattress (if the mattress has not been equipped with a network, you need to complete the network configuration first, please refer to the product manual of smart mattress for details). If you need a new remote control, please contact customer service.	
What should I do if I want to redistribute the network after losing the remote control?	Please contact customer service to get a new remote control, then pair the new remote control with the bed cushion, and then you can re-allocate the network.	
If the problem still exists after troubleshooting by the above methods, Please contact customer service: 400-181-6996.		

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.