User Manual Tuya smart IP Camera

Smart camera/infrared remote control/temperature and humidity sensor

Thank you for your purchase.

Please read this user manual carefully and use it correctly. Please keep it carefully.

Important reminder: Before using this product, please make sure that your phone is connected to a Wi-Fi signal in the 2.4GHz frequency band.

Names of each section



When using SD card, please pay attention to the front and back.

Installation location and method

●Do not install in areas with chaos, unstable signals, weak intensity, danger of falling or reflective obstacles, such as the front glass.

●Please avoid direct sunlight and install it in a well ventilated and dry environment.

●Please confirm if the installation location is within the range of Wi-Fi signals.

●A power socket is required within 1M of the installation location.

●Please use this product within the legal scope.

Install fixed camera

①Fix the buckle with screws in the installation position of the camera

②Insert the camera into the clip and rotate it to tighten it.

③Please ensure that the camera and clip are securely locked and will not fall off.

Download software

一. Scan QR code to download

二. Search for "TUYA Smart" or "Smart Life" in the app store to download

Register an account

Register with your mobile number/E-mail then login



The supported applications are free, but when using paid services such cloud storage within the application, an additional usage fee will be charged.

JS-P195 Connection Configuration Method

Open the app, click on "Add Device" or the icon "+" in the upper right corner (Figure 1), select "Smart Camera" in the device type (Figure 2), and ensure that the indicator light is flashing.

Figure 1 Figure 2 Figure 3

Select 2.4GHz Wi-Fi signal, enter your Wi-Fi password, and click "Next" (Figure 3). A QR code will appear on the phone screen (Figure 4). Use the QR code on your phone to aim at the camera lens (15-20 centimeters away) and scan. When the device has a voice prompt, click "hear the prompt sound".



Figure 4 Figure 5 Figure 6

After waiting successfully, there will be a smart camera on the homepage of the APP (Figure 5), and clicking to enter will display the live broadcast screen (Figure 6).

How to use the application (camera)



① Click to enter settings
② Resolution switching
③ Temperature/humidity
④ Turn on and turn off the camera speaker
⑤ Screen zoom display switching
⑥ Wide screen display
⑦ Save photos
⑧ Voice call button
⑨ Save video
⑩ Function menu

The configuration method of infrared remote control

1.Select the remote control in the smart camera you logged in to from "My Home" to add and operate the remote control. To add a remote control, select "Add (Figure 1)", then select the device you want to add (Figure 2), and select "Quick Match (Figure 3)"

Figure 1 Figure 2 Figure 3

2. Please align the device with the controlled electrical device and click the button below to match it (Figure 4), then follow the prompt to set the button. Each time the button can be controlled, click "Can Control (Figure 5)" to proceed to the next setting page until an additional intelligent infrared remote control label (Figure 6) appears on the "homepage", and the remote control is successfully set.



Figure 4 Figure 5 Figure 6

Attention: The distance between the camera and the controlled infrared device should not exceed 4 meters, otherwise the signal will weaken, which may lead to uncontrollability.

warranty card

Warranty period:6 months from the date of purchase
Model: JS-P195
Product functions:smart camera/infrared remote control/temperature and humidity
Your name:
Your address:
Your phone number:
Cause of malfunction:
Your order number:

Warranty scope

During the warranty period, if there is a malfunction during normal use, it will be repaired free of charge according to the methods specified by our company. According to our company's judgment, the product may be replaced. Please understand in advance.

When a malfunction occurs during the warranty period and free repair is accepted, please send the warranty certificate and receipt along with the product to the manufacturer.

Even within the warranty period, the following situations still require payment for repairs

1. When unable to present the guarantee letter and receipt (or order number);

2. Obstacles and damages caused by voltage and other factors;

3. When dismantling and repairing the machine by oneself, replacing parts, and unable to solve the problem;

4. Malfunctions and damages caused by displacement, transportation, and falling of the installation site after purchase;

5. When other natural disasters such as high temperature, feng shui, and falling are difficult to damage;

6. Malfunctions and damages during use outside of general household use (e.g. commercial use)

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference thatmay cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions,may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

涂鸦智能摄像机用户手册

智能摄像头/红外遥控器/温湿度传感器

谢谢您的购买

使用前请务必阅读本使用说明书，正确使用（读完之后，请小心保管）

重要提示：使用本产品前，请确定您的手机是连接2.4GHz频段的Wi-Fi信号。

各部分名称

使用SD卡时，请注意正面和背面。

关于安装位置

- 请勿安装在信号混乱不稳定的场所、强度较弱的天花板或墙壁、有可能会坠落、前方有玻璃等反射障碍物的地方。
- 请安装在避免阳光直晒，并通风干燥的环境。
- 请确认安装地点是否为 Wi-Fi 信号所能到达的范围。
- 在安装位置1米内需要有供电插口。
- 请在合法范围内使用本产品

安装与固定摄像机的方法

①将卡扣用螺丝固定在摄像机的安装位置

②将主机装入卡扣，旋转

③请确保主机与卡扣已牢固锁紧不会掉落。

下载软件

方法1: 扫描二维码下载

方法2: 在应用商店搜索“涂鸦智能”或“智能生活”进行下载

注册账号

可以使用您的手机号码或电子邮件注册，然后登录

支持的应用程序是免费的，但在应用程序内使用视频保存到云端等付费服务时，将另行收取使用费。

JS-P195 连接配置方法

打开APP，点击“添加设备”或右上角的图标“+”（图一），在设备类型中选择“智能摄像头”（图二），确保指示灯闪烁。

图一　图二　图三

选择2.4GHz Wi-Fi信号，输入您的 Wi-Fi 密码并点击“下一步”（图三），手机屏幕会出现一个二维码（图四），用手机上的二维码对准相机镜头(距离15-20厘米)扫描，当设备有语音提示时，请单击“听到提示声”。等待成功后，APP首页会有一个智能摄像机（图五），单击进入就能看到直播画面（图六）。

图四　图五　图六

应用程序的使用方法（摄像机）

① 点击进入设置
② 分辨率切换
③ 温度/湿度
④ 摄像机扬声器的开与关
⑤ 画面变焦显示切换
⑥ 画面宽屏显示
⑦ 保存照片
⑧ 语音通话按钮
⑨ 保存视频
⑩ 功能菜单

红外遥控器的配置方法

1. 从“我的首页”中选择登录的智能摄像头内的遥控器，即可添加和操作遥控器。要添加遥控器，请选择“添加（图一）”，然后选择要添加的设备（图二），选择“快速匹配（图三）”

图一　图二　图三

2. 请将设备对准被控电器点击下方按键进行匹配（图四），然后根着提示设置按键，每次按键都能够控制，就点击“能控制（图五）”，进到下个设置页面，直至“首页”多出一个智能红外遥控器的标识（图六），遥控器设置成功。



图四　图五　图六

注意：摄像机与受控制的红外电器距离不能超过4米，否则信号减弱，有可能导致无法控制。

保修卡

保修期:自购买之日起6个月
产品型号:JS-P195
产品功能:智能监/红外遥控器/温湿度/三合一
您的姓名:
您的电话:
故障原因:
您的订单号:

保修范围

在保修期间内正常使用发生故障时，将按照本公司指定的方法免费维修。根据本公司的判断，可能会更换产品，敬请事先谅解。

在保修期内发生故障而接受免费维修时，请将保修书和收据随商品一起寄送到生产厂家。即使在保修期内，以下情况仍需付费维修:

1、无法出示保修书和收据(或订单号)时；

2、电压等引起的故障及损伤；

3、自行拆机维修，更换零件，无法解决问题时；

4、购买后安装场所的移位、运输、掉落造成的故障及损伤；

5、高温、风水、击摔等其他天灾地难损坏时；

6、一般家庭用以外(例如，商业用) 使用时的故障及损伤。