PAN'S 平移

User Manual

Slash
Smartphone Camera Grip

● Introduction





❶ Skidproof Stripe ❷ 1/4 Screw Holes with Arri Locating Holes ❸ Slash Adaptive Locating Pins ❹ Magnetic Bluetooth Camera Shutter module ❺ Shutter button ❻ Pairing button ❼ Cold Shoe Mount

● Getting Started

1. Pull out the isolation sticker and indication LED should light on.
2. Press and hold the pairing button for three seconds to get into pairing state, turn on the Bluetooth of the smartphone, find and connect the "Pan's Scheme Shutter".
3. Clamp on the proper position of smartphone depends on the usage.
   * If you want to combine with a phone case with Slash locating holes:
   - Please check the graphical explanation in next page, or scan the following QC code to check guide video.



❶ Put one side of Slash pins to corresponding holes
❷ Pull the clamp ❸ Aim to the other side of Slash holes and clamp on the phone.



❹ Try to sway the grip to make sure the Slash locating is on position. The grip usually generates "click" sound when the locating pins are on location.

● Using

- **Handheld shot**

  Clamp the grip in tail of Smartphone for Handheld shot.





❶ Horizontal shot ❷ Vertical shot

- **Attach on tripod**

  1/4" screw hole can be used to attach tripod and other accessories.





*The depth of 1/4 inch screw hole is 5.5mm. The depth of locating hole is 3mm.

- **Handheld shot**

  The remote shutter is available for original camera app or third-part camera app. Press/press and hold can trigger shutter/record.



* Original camera app or third-part camera app need to support shutter/record trigger by volume +.
* Press and hold trigger requests to be supported by camera apps.

- **Remote Shutter**

  Magnetic Bluetooth Camera Shutter module, which is detachable, can be taken out to remote for record/shutter. The approximate remote range is 10 meters.



● States Indication

- **Connect State**

Light	Current State
Slowly Blink	Disconnect
Fast Blink	Pairing
Continuously lit	Connect

- **Sleep Mode**

- The Magnetic Bluetooth Camera Shutter module has sleep mode that can avoid useless power consumption.
- It would get into sleep mode while the shutter hasn't been operated over one hour on connect state.
- It would get into sleep mode while the shutter hasn't been operated over 15 seconds on disconnect state.
- Press the shutter button would wake it up from sleep mode.

- **Low Power Warning**

- Red light occasionally blinks when the battery power is under 40%.

- **Replace Battery**

- The Magnetic Bluetooth Camera Shutter module can be powered by CR1632 button battery. Please replace battery if it shows low power warning.
- Take out the shutter module from grip, slide out battery cover then replace battery.

- **Warning**

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
  Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
  NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However. there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
--Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
--Consult the dealer or an experienced radio/TV technician for help
NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter
The device has been evaluated to meet general RF exposure requirement. The device
can be used in portable exposure condition without restriction.