Bluetooth Speaker

USER MANUAL



UK CA CE FC RoHS MADE IN CHINA

Thank you

Thank you for purchasing our MAGOLFIN golf magnetic speaker. We sincerely appreciate your support and trust in our brand. X10 speaker boasts several key advantages, such as ultra-strong magnetic, 18W high-fidelity horn, and IP67 waterproof and dustproof rating. We aim to enhance your golfing experience, allowing you to fully enjoy the pleasure of playing golf while enjoying your favorite music. Thank you once again for choosing MAGOLFIN. Should you have any questions or require further assistance, please do not hesitate to contact us. We value your feedback and are committed to providing you with exceptional customer service.

Parameters

Product Model	X10	Input power supply	Type - C 5V/2A
Bluetooth Version	V4.2	Response frequency	115Hz~15KHz
Bluetooth Range	≥18M(without obstruction)	Distortion degree	≤1%
Horn Specification on	φ58MM 18W*1	Playback time	≥18H
Battery Capacity	3 . 7V/1800mAh	Charging time	≤3H

Accessories

A UX Audio Cable * 1

Type-C Cable * 1

Lanyard * 1

Button Function

① Power On/Power Off/TWS
② Play/Pause; Answer/Hang up
③ Volume Down/Previous Song
④ Volume Up/Next Song
⑤ Charging Port
⑥ T F Card Slot
⑦ AUX Audio Input



Button	Operate	Function Description
	Short press	Mode switching.
	Long press	On/off: long press 1S/3S; Reset: long press 8S.
	Double click	Enter/disconnect tws; Disconnect bluetooth
	Short press	Play/Pause: short press when music is playing; Connect the phone: short press when there is an incoming call; Hang up the phone: short press while talking; Dial the last number: double-click quickly when Bluetooth is paired.
	Long press	Reject the call: long press 2S.
	Short press	Volume reduction, 16 levels in total.
	Long press	Previous song: long press 2S.
	Short press	Volume plus, a total of 16 levels
	Long press	Volume plus, a total of 16 levels

How to Use

-Pairing

After powering on, the blue indicator light flashes quickly, indicating that the speaker is in Bluetooth pairing mode. Open the Bluetooth function on your phone and find the Bluetooth name "X10", then click to connect. Once connected successfully, the blue light will stay on continuously.

-TW S Interconnection

When two X10 speakers enter Bluetooth pairing mode at the same time (the blue light flashes), double-click the power button of each speaker. At this time, the speaker's yellow indicator light flashes, indicating that it has entered TWS automatic pairing mode. After waiting for 3 seconds, one of the speakers will become the main speaker with a steady yellow light and a fast flashing blue light, while the other speaker will have a steady yellow light, indicating a successful TWS pairing. Finally, search for the Bluetooth name "X10" in the Bluetooth list and click on it to connect. The steady blue light on the main speaker indicates a successful pairing.

- AUX Audio Cable

Insert the AUX cable into both the phone and the speaker. If the connection is successful, the blue indicator light will flash slowly.

-Type - C Cable (supports simultaneous charging and playing)

Insert the Type-C cable into both the computer and the speaker. If the connection is successful, the blue and red indicator lights will stay on.

-T F card (supports up to 64GB)

Insert the TF card into the speaker, and the speaker will automatically read the card and play the songs. At this time, the blue indicator light will flash slowly. The TF card supports APE/FLAC/WMV/WAV/MP3 format

Safety Precautions

1、Please keep it out of reach of children to prevent accidents.
2、Do not place the device in high-temperature environments, including direct sunlight.
3、Do not place the device near fire or other overheated environments.
4、Do not place the device in damp or excessively humid areas.
5、Do not attempt to charge the device using methods other than the provided charging cable.
6、Do not open or attempt to repair or modify the device in any way.
7、Pay attention to activities that may cause the device to fall, collide, scratch, or otherwise affect its functionality. If any damage occurs, such as overheating, deformation, or corrosion, immediately stop using the product.
8、If the device emits abnormal odors, exceeds normal temperatures, or undergoes abnormal changes in color or shape, immediately stop using the device.
9、Incorrect battery replacement may cause combustion hazards. Only use the same type or equivalent type of battery for replacement.
10、Prolonged use of the device at high volume may cause damage to your hearing.

Note

1、Do not use any type of fast charging that exceeds 5V-3A, such as PD fast charging, Qualcomm Quick Charge, GaN fast charging, etc. The voltage of these chargers may not be recognized and compatible with the mainboard.
2、If the device has not been used for more than 3 months, it needs to be charged before use.
3、When not in use for a long time, it is recommended to charge the device every 3 months to effectively protect the battery.
4、It is recommended to use the device after it has been fully charged upon receipt.

Warranty

We are committed to providing you with the highest quality products. Magolfin X10 Speaker come with a **12-month warranty**, ensuring that they are free from defects in materials and workmanship. In the unlikely event that you experience any issues with your purchased product within the warranty period, please contact us via email at **magolfin_vip@outlook.com**. Our dedicated customer support team will be glad to assist you and resolve any concerns you may have.

RF exposure statement

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.