50x60mm

用户手册

User Manual

功能参数

蓝牙版本:V5.3
传输距离:>10米
通话时间:3-4小时
充电时间:1-2小时
耳机电池:25毫安
机仓电池:200毫安加保护板
喇叭:F13喇叭
充电口:type-c

操作
开机:耳机从充电仓拿出开机
关机:长按触摸键5S或者入仓关机
TWS自动配对模式:首次开机自动TWS配对
暂停/播放:单击左右耳
上一曲:双击左边多功能键
下一曲:双击右边多功能键
音量加:三击右边多功能键
音量减:三击左边多功能键
接听来电:单击左右耳
语音助手:长按2S左右耳
拒接来电:长按2S左右耳
电量显示:仅支持ISO系统设备和部分安卓系统设备
同类此方案其它产品上出现的问题是否重现或规避
智能休眠状态:无连接状态时,约3分钟自动关机
自动回连:耳机重新开机后,蓝牙自动重新连回手机
远距离断开自动回连:远距离断开,回到10米内蓝牙自动连接手机
充电自动关机:播放状态下,休眠,待机,耳机进入充电仓都会关机
充电盒充电:用数据线插入座充充电时,仓指示灯闪烁,充满后指示灯长亮
充电模式:耳机放入充电仓后耳机充电,充电仓灯灭,耳机充满后关机

注意事项

1.请勿暴力对待本产品,也不要用重物挤压,远离高温高湿环境。

2.远离WF1及路由器及其它高频发射设备,这样会影响本机的信号接收,造成声音的卡断及断连。

3.请在有效环境(10m内)中使用本产品,并且蓝牙设备与耳机之间不要有实体阻挡(例如墙等)
4.为了防止因电池休眠而导致无法充电,请尽量将充电仓保持20%的电量以上。

注:本产品可以与任何一款具有蓝牙功能的设备进行连接使用。

User Manual

Function parameter

Bluetooth version : V5.3
Wireless distance : 10 meters
Working time : 3-4 hours
Charging time : 1-2 hours
Earphone battery : 25mAh*2
Charging case battery :200mAh with protection board
Speaker : F13 horn
Charging port : type-c

Instructions:
Power on : Take the earphones out of the charging case
Power off : Long press the multi-function button for 5S or put the earphones back into the charging case
TWS pairing : automatically paired when the product is turned on for the first time.
TWS using : 2 earphones can be used together and can be used alone
Pause/Play : Click the multi-function button
Previous song : Double-click the left multi-function button
Next song : Double-click the right multi-function button
Volume up : Triple-click the right multi-function button
Volume down : Triple-click the left multi-function button
Answer an incoming call : Click the multi-function button
Voice assistant : Long press the multi-function button for 2S
Reject calls : Long press the multi-function button for 2S
Battery display : only supports ISO system devices and some Android system devices

Intelligent dormancy mode : when there is no connection, it will automatically power off in about 3 minutes.
Automatic connection : After the earphones are turned on again, Bluetooth will automatically reconnect to the phone.
Automatic power-off : Earphones will automatically power off when put back into the charging case to charge
Charging case charging: The indicator light of the case will flash when charging . The indicator light stays on when fully charged
Earphone charging: put the earphones back into the charging case to charge.

Precautions

1.Do not treat this product violently , and do not squeeze it with heavy objects , and keep it away from high temperature and high humidity environment.

2 . Keep away from WIFI, routers and other high-frequency transmitting equipment , which will affect the signal reception of this machine , causing sound jamming and disconnection.

3 . Please use this product in an effective environment (within 10m), and there should be no physical obstruction (such as a wall , etc.) between the Bluetooth device and the product.

4 . In order to prevent charging failure due to battery hibernation , please try to keep the charging case above 20% of the power.

Note : This product can be connected with any device with Bluetooth function

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.